



РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ

## STP Configuration Commands

# Table of Contents

CHAPTER 1	STP CONFIGURATION COMMANDS	4
1.1.	SSTP Configuration Commands	4
1.1.1.	spanning-tree	4
1.1.2.	spanning-tree mode sstp	4
1.1.3.	spanning-tree sstp priority	5
1.1.4.	spanning-tree sstp hello-time	5
1.1.5.	spanning-tree sstp max-age	6
1.1.6.	spanning-tree sstp forward-time	7
1.1.7.	spanning-tree sstp cost	7
1.1.8.	spanning-tree cost	8
1.1.9.	spanning-tree sstp port-priority	9
1.1.10.	spanning-tree port-priority	10
1.1.11.	show spanning-tree	10
1.1.12.	spanning-tree management trap	11
1.2.	VLAN STP Configuration Commands	12
1.2.1.	spanning-tree mode pvst	12
1.2.2.	spanning-tree vlan	12
1.2.3.	spanning-tree vlan priority	13
1.2.4.	spanning-tree vlan forward-time	14
1.2.5.	spanning-tree vlan max-age	15
1.2.6.	spanning-tree vlan hello-time	15
1.2.7.	spanning-tree vlan cost	16
1.2.8.	spanning-tree vlan port-priority	17
1.2.9.	show spanning-tree vlan	18
1.2.10.	show spanning-tree pvst instance-list	19
CHAPTER 2	RSTP CONFIGURATION COMMANDS	20
2.1.	RSTP Configuration Commands	20
2.1.1.	spanning-tree mode rstp	20
2.1.2.	spanning-tree rstp forward-time	20
2.1.3.	spanning-tree rstp hello-time	21
2.1.4.	spanning-tree rstp max-age	21
2.1.5.	spanning-tree rstp priority	22
2.1.6.	spanning-tree rstp cost	23
2.1.7.	spanning-tree rstp port-priority	23
2.1.8.	spanning-tree rstp edge	24
2.1.9.	spanning-tree rstp point-to-point	24

2.1.10.	spanning-tree rstp migration-check	25
<b>CHAPTER 3</b>	<b>MSTP CONFIGURATION COMMANDS</b>	<b>26</b>
<b>3.1. MSTP Configuration Command</b>		<b>26</b>
3.1.1.	spanning-tree mode mstp	26
3.1.2.	spanning-tree mstp name	26
3.1.3.	spanning-tree mstp revision	27
3.1.4.	spanning-tree mstp instance	27
3.1.5.	spanning-tree mstp root	28
3.1.6.	spanning-tree mstp priority	29
3.1.7.	spanning-tree mstp hello-time	30
3.1.8.	spanning-tree mstp forward-time	31
3.1.9.	spanning-tree mstp max-age	31
3.1.10.	spanning-tree mstp diameter	32
3.1.11.	spanning-tree mstp max-hops	33
3.1.12.	spanning-tree mstp port-priority	33
3.1.13.	spanning-tree mstp cost	34
3.1.14.	spanning-tree mstp edge	35
3.1.15.	spanning-tree mstp point-to-point	35
3.1.16.	spanning-tree mstp mst-compatible	36
3.1.17.	spanning-tree mstp migration-check	37
3.1.18.	spanning-tree mstp restricted-role	37
3.1.19.	spanning-tree mstp restricted-tcn	38
3.1.20.	show spanning-tree mstp	38
3.1.21.	show spanning-tree mstp region	39
3.1.22.	show spanning-tree mstp detail	40
3.1.23.	show spanning-tree mstp interface	42
3.1.24.	show spanning-tree mstp protocol-migration	44

# CHAPTER 1 STP CONFIGURATION COMMANDS

## 1.1. SSTP Configuration Commands

### 1.1.1. spanning-tree

#### Syntax

**spanning-tree**

**no spanning-tree**

To enable the default STP mode, run **spanning-tree**; to disable the STP, run **no spanning-tree**.

Enable or disable STP in interface configuration mode.

#### Parameter

None

#### Default value

Enable RSTP mode by default.

#### Usage guidelines

None

#### Command Mode

Global configuration mode

Physical port or aggression port configuration mode.

#### Example

None

### 1.1.2. spanning-tree mode sstp

#### Syntax

**spanning-tree mode sstp**

**no spanning-tree mode**

To switch between RSTP and SSTP modes, use the **spanning-tree mode** command.

To return to the default settings, use the no form of this command.

#### Parameter

None

#### Default value

RSTP

#### Usage guidelines

None

## Command Mode

Global configuration

### Example

The following command shows how to enable SSTP mode:

```
Switch_config# spanning-tree mode sstp
Switch_config#
```

#### 1.1.3. spanning-tree sstp priority

### Syntax

To set the sstp bridge priority, use the spanning-tree sstp priority command. To return to the default settings, use the no form of this command.

**spanning-tree sstp priority value**

**no spanning-tree sstp priority**

### Parameter

Parameter	Description
<i>value</i>	Value is from 0 to 61440.

### Default value

32768

### Usage Guidelines

When setting the priority value, you can make the node as the root of the spanning tree. The configuration value takes 4096 as a step and its value is the multiple of 4096. The configurable values are 0, 4096, 8192, 3\*4096, 4\*4096,..... and 15\*4096.

### Command mode

Global configuration

### Example

This example shows how to set the SSTP priority to 4096:

```
Switch(config)# spanning-tree sstp priority 4096
Switch(config)#
```

#### 1.1.4. spanning-tree sstp hello-time

### Syntax

To set the hello-time delay timer, use the spanning-tree sstp hello-time command. To return to the default settings, use the no form of this command.

**spanning-tree sstp hello-time time**

**no spanning-tree sstp hello-time****Parameter**

Parameter	Description
<i>time</i>	Number of seconds to set the hello-time delay timer; valid values are from 1 to 10 seconds.

**Default value**

2s

**Usage Guidelines**

The hello-time configured by the local OLT is valid only when the local OLT is the root OLT.

**Command mode**

Global configuration

**Example**

The following example sets the Sstp hello-time to 8 seconds:

```
Switch(config)# spanning-tree sstp hello-time 8
Switch(config)#
```

**1.1.5. spanning-tree sstp max-age****Syntax**

To set the Sstp max-age timer, use the spanning-tree sstp max-age command. To return to the default settings, use the no form of this command.

**spanning-tree sstp max-age *time*****no spanning-tree sstp max-age****Parameter**

Parameter	Description
<i>seconds</i>	Number of seconds to set the max-age timer; valid values are from 6 to 40 seconds.

**Default value**

20s

**Usage Guidelines**

None

**Command mode**

Global configuration

### Example

This example shows how to set the max-age timer to 24 seconds:

```
Switch(config)# spanning-tree sstp max-age 24
Switch(config)#{/pre}

```

### 1.1.6. spanning-tree sstp forward-time

#### Syntax

To set the forward-delay timer, use the spanning-tree sstp forward-time command in global configuration mode. To return to the default settings, use the no form of this command.

**spanning-tree sstp forward-time *time***

**no spanning-tree sstp forward-time**

#### Parameter

Parameter	Description
<i>time</i>	Number of seconds to set the forward-delay timer; valid values are from 4 to 30 seconds.

#### Default value

15 seconds

#### Usage Guidelines

None

#### Command mode

Global configuration

### Example

The following example shows how to set forward delay timer to 20 seconds:

```
Switch_config# spanning-tree sstp forward-time 20
Switch_config#{/pre}

```

### 1.1.7. spanning-tree sstp cost

#### Syntax

To set the path cost of the interface for SSTP calculations, use the spanning-tree sstp cost command in interface configuration mode. To return to the default value, use the no form of this command.

**spanning-tree sstp cost *value***

**no spanning-tree sstp cost****Parameter**

Parameter	Description
<i>value</i>	Path cost. Valid values are from 1 to 200000000

**Default value**

10M Ethernet:100.

100M Ethernet: 19.

1000M Ethernet: 4.

**Usage Guidelines**

None

**Command mode**

Interface configuration

**Example**

This example shows how to set a path cost value of 100 for the spanning tree VLAN associated with the interface G0/1:

```
Switch_config_g0/1#spanning-tree sstp cost 100
```

```
Switch_config_g0/1#
```

**1.1.8. spanning-tree cost****Syntax**

To set the path cost of the interface for Spanning Tree Protocol (STP) calculations, use the **spanning-tree cost** command in interface configuration mode. To return to the default value, use the **no** form of this command.

**spanning-tree cost *value***

**no spanning-tree cost**

**Parameter**

Parameter	Description
<i>value</i>	Path cost; valid values are from 1 to 200000000

**Default value**

The default path cost is computed from the bandwidth setting of the interface.

**Usage Guidelines**

The configuration result of this command is valid to all spanning-tree modes. In STP mode, the path cost of all VLAN spanning-trees on the interface will be updated. In MSTP mode, the path cost of all spanning-tree examples will be updated.

But the configuration result of the command will not influence the independent configuration in various modes. For example, the OLT respectively configured with the spanning-tree sstp cost 100 and the spanning-tree cost 110 in SSTP mode, the port priority will be 100.

### **Command mode**

Interface configuration

### **Example**

This example shows how to set a path cost value of 24 for the spanning tree VLAN associated with the interface g0/1:

```
Switch(config_f0/0)# spanning-tree cost 24
```

```
Switch_config_g0/1#
```

### **1.1.9. spanning-tree sstp port-priority**

#### **Syntax**

To set the priority value in SSTP mode, use the spanning-tree sstp port-priority command. Use the no form of this command to restore the default value.

**spanning-tree sstp port-priority *value***

**no spanning-tree sstp port-priority**

#### **Parameter**

Parameter	Description
<i>value</i>	Port priority. Value is from 0 to 240.

#### **Default value**

128 (0x80)

#### **Usage Guidelines**

The port priority must be set in increments of 16 only.

### **Command mode**

Interface configuration

### **Example**

The following example sets 32 as the priority value on interface g0/1:

```
Switch_config_g0/1# spanning-tree sstp port-priority 32
```

```
Switch_config_g0/1#
```

### 1.1.10. spanning-tree port-priority

#### Syntax

To prioritize an interface when two bridges compete for position as the root bridge, use the spanning-tree port-priority command. The priority you set breaks the tie. To return to the default value, use the no form of this command.

**spanning-tree port-priority value**

**no spanning-tree port-priority**

#### Parameter

Parameter	Description
<i>value</i>	Port priority. Value is from 0 to 240. Step: 16

#### Default value

Port priority value is 128

#### Usage Guidelines

The configuration result of this command is valid to all spanning-tree modes. In STP mode, the priority of all VLAN spanning-trees on the interface will be updated. In MSTP mode, the priority of all spanning-tree examples will be updated.

But the configuration result of the command will not influence the independent configuration in various modes. For example, the OLT respectively configured with the spanning-tree sstp port-priority 128 and the spanning-tree port-priority 48 in Sstp mode, the port priority will be 128.

#### Command mode

Interface configuration

#### Example

The following example shows how to set the priority value to g0/1:

```
Switch_config_g0/1#spanning-tree port-priority 16
```

```
Switch_config_g0/1#
```

### 1.1.11. show spanning-tree

#### Syntax

To display spanning-tree information for the specified spanning-tree instances, use the show spanning-tree command.

**show spanning-tree [detail | interface *intf-i* | mstp| pvst | interfacevlan]**

#### Parameter

Parameter	Description
<i>intf-i</i>	Interface name, for instance, G5/1.

**Default value**

None

**Usage Guidelines**

Show spanning-tree state.

**Command mode**

EXEC/Global configuration/Interface configuration

**Example**

Switch\_config#show spanning-tree

Spanning tree enabled protocol SSTP

SSTP

Root ID Priority 32768

Address 00E0.0FCC.F775

This bridge is the root

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority 32768

Address 00E0.0FCC.F775

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interface Role Sts Cost Pri.Nbr Type

-----

G5/1 Desg FWD 19 128.16 P2p

Switch\_config#

**1.1.12. spanning-tree management trap****Syntax**

To enable STP Trap, run command **spanning-tree management trap [ newroot | topologychange ]**. To return to the default value, use the no form of this command.

**[no] spanning-tree management trap [ newroot | topologychange ]**

**Parameter**

Parameter	Description
-----------	-------------

<i>newroot</i>	newRoot Trap type
<i>topologychange</i>	topologyChange Trap type

**Default value**

STP Trap is not enabled.

**Usage guidelines**

None

**Command mode**

global configuration configuration mode

**Example**

None

## 1.2. VLAN STP Configuration Commands

### 1.2.1. spanning-tree mode pvst

**Syntax**

**spanning-tree mode pvst**

**no spanning-tree mode**

To enable VLAN-based STP mode, run spanning-tree mode pvst. To disable the function, use the no form of the command.

**Parameter**

None

**Default value**

RSTP mode

**Usage Guidelines**

None

**Example**

The following example shows how to enable pvst on OLT.

```
Switch_config# spanning-tree mode pvst
```

```
Switch_config#
```

### 1.2.2. spanning-tree vlan

**Syntax**

**spanning-tree vlan *vlan-list***

**no spanning-tree vlan *vlan-list***

To designate VLAN to distribute the STP case, run `spanning-tree vlan vlan-list`. To cancel the spanning tree of the designated VLAN, run `no spanning-tree vlan vlan-list`.

### Parameter

Parameter	Description
<code>vlan-list</code>	VLAN number list, for instance, 1,2,3-10,15.

### Default value

OLT only distributes SFP instances for a certain number of VLANs. The outnumbered VLANs will be automatically added to the STP forbidden list.

### Usage Guidelines

None

### Command mode

Global configuration

### Example

The following example shows how to delete the STP of VLAN10, 11, 15-19 and distribute STP for VLAN 40-50.

```
Switch_config#no spanning-tree vlan 10,11,15-19
Switch_config#spanning-tree vlan 40-50
Switch_config#
```

### 1.2.3. `spanning-tree vlan priority`

#### Syntax

```
spanning-tree vlan vlan-list priority value
no spanning-tree vlan vlan-list priority
```

To designate the priority level of the bridge of the VLAN STP, run **`spanning-tree vlan vlan-list priority value`**.

### Parameter

Parameter	Description
<code>vlan-list</code>	VLAN number list, for instance, 1,2,3-10,15.
<code>value</code>	Priority value, range 0 – 61440, step: 4096

### Default value

By default, the priority level of the bridge of each VLAN spanning tree is 32768 plus the VLAN number.

## Usage Guidelines

None

## Command mode

Global configuration

## Example

The following example shows how to configure the bridge priority of VLAN1-3 and 5-10 be 4096:

```
Switch_config#spanning-tree vlan 1-3,5-10 priority 4096
```

```
Switch_config#
```

## 1.2.4. spanning-tree vlan forward-time

### Syntax

**spanning-tree vlan *vlan-list* forward-time *value***

**no spanning-tree vlan *vlan-list* forward-time**

The command is used to designate Forward Delay Parameter of SFP in VLAN. To disable this function, use the no form of this command.

### Parameter

Parameter	Description
<i>vlan-list</i>	VLAN number list, for instance, 1,2,3-10,15.
<i>value</i>	Forward-Delay value; value ranges from 4s to 30s; the default is 15s.

### Default value

The Forward Delay of all VLANs is 15s.

## Usage Guidelines

None

## Command mode

Global Configuration

## Example

The following example shows how to configure the Forward Delay of VLAN1-3,5-10 to be 19s:

```
Switch_config#spanning-tree vlan 1-3,5-10 forward-time 19
```

Switch\_config#

### 1.2.5. spanning-tree vlan max-age

#### Syntax

**spanning-tree vlan *vlan-list* max-age *value***

**no spanning-tree vlan *vlan-list* max-age**

The command is used to designate Max AgeParameter of STP in VLAN. To disable this function, use the no form of this command.

#### Parameter

Parameter	Description
<i>vlan-list</i>	VLAN number list, for instance, 1,2,3-10,15.
<i>value</i>	max-age value; the value range is 6s to 40s; the default is 20s.

#### Default

Max Age of all VLANs is 20s.

#### Usage Guidelines

None

#### Command mode

Global Configuration

#### Example

The following example shows how to configure Max Age of VLAN1-3,5-10 as 19s:

Switch\_config#spanning-tree vlan 1-3,5-10 max-age 19

Switch\_config#

### 1.2.6. spanning-tree vlan hello-time

#### Syntax

**spanning-tree vlan *vlan-list* hello-time *value***

**no spanning-tree vlan *vlan-list* hello-time**

The command is used to configure hello-time Parameter of STP in VLAN. To return to the default setting, use the no form of this command.

#### Parameter

Parameter	Description

<b>vlan-list</b>	VLAN number list, for instance, 1,2,3-10,15.
<b>value</b>	hello-time value, the value ranges from 1s to 10s, the default is 2s.

**Default value**

Hello-Time of all VLANs is 2s.

**Usage Guidelines**

None

**Command mode**

Global Configuration

**Example**

The following example shows how to set Hello Time of VLAN1-3,5-10 to 9s:

```
Switch_config#spanning-tree vlan 1-3,5-10 hello-time 9
```

```
Switch_config#
```

**1.2.7. spanning-tree vlan cost****Syntax**

**spanning-tree vlan *vlan-list cost value***

**no spanning-tree vlan *vlan-list cost***

To set the path cost of the spanning tree in the designated VLAN, run **spanning-tree vlan *vlan-list cost value***. To resume the default value, run **no spanning-tree vlan *vlan-list cost***.

**Parameter**

Parameter	Description
<b>vlan-list</b>	VLAN number list, for instance, 1,2,3-10,15.
<b>value</b>	The port path cost. The value ranges: 1 – 200000000

**Default value**

The path cost of a port depends on the port rate.

The value of the path cost of the 10M Ethernet is 100.

The value of the path cost of the 100M Ethernet is 19.

The value of the path cost of the 1000M Ethernet is 4.

**Usage Guidelines**

None

### Command mode

Interface configuration

### Example

The following example shows how to set the path cost of port G0/1 VLAN1-3,5-10 to 100:

```
Switch_config_g0/1#spanning-tree vlan 1-3,5-10 cost 100
```

```
Switch_config_g0/1#
```

## 1.2.8. spanning-tree vlan port-priority

### Syntax

**spanning-tree vlan *vlan-list* port-priority *value***

**no spanning-tree vlan *vlan-list* port-priority**

To set the priority level of the spanning tree in the designated VLAN, run **spanning-tree vlan *vlan-list* port-priority *value***. To resume the default value, run **no spanning-tree vlan *vlan-list* port-priority**.

### Parameter

Parameter	Description
<i>vlan-list</i>	VLAN number list, for instance, 1,2,3-10,15.
<i>value</i>	Port priority, value ranges 0 – 240, step 16.

### Default value

128

### Usage Guidelines

None

### Command mode

Interface configuration

### Example

The following example shows how to set the priority level of port g0/1 VLAN1-3,5-10 to 32.

```
Switch_config_g0/1#spanning-tree vlan 1-3,5-10 port-priority 32
```

```
Switch_config_g0/1#
```

### 1.2.9. show spanning-tree vlan

#### Syntax

```
show spanning-tree vlan vlan-list [ detail ]
```

To check the state of the spanning tree in the designated VLAN, run the above command.

#### Parameter

Parameter	Description
<i>vlan-list</i>	VLAN number list, for instance, 1,2,3-10,15.
<i>detail</i>	Show detailed information.

#### Default value

None

#### Usage Guidelines

None

#### Command mode

EXEC, Global Configuration or Interface configuration

#### Example

The following example shows how to check the spanning tree in VLAN1-2:

```
Switch_config#show spanning-tree vlan 1-2
Spanning tree enabled protocol PVST
VLAN0001
  Root ID  Priority  32769
    Address  00E0.0FCC.F775
    This bridge is the root
    Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec
  Bridge ID  Priority  32769
    Address  00E0.0FCC.F775
    Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec
  Interface      Role Sts Cost      Pri.Nbr Type
  -----
  G0/1          Desg FWD 19      128.1 P2p
VLAN0002
```

```
Root ID Priority 32770
Address 00E0.0FCC.F775
This bridge is the root
Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
Bridge ID Priority 32770
Address 00E0.0FCC.F775
Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
Interface Role Sts Cost Pri.Nbr Type
-----
G0/1 Desg FWD 19 128.1 P2p
Switch_config#
```

### 1.2.10. show spanning-tree pvst instance-list

#### Syntax

**show spanning-tree pvst instance-list**

The command is used to check the corresponding relationship between PVST instance and VLAN.

#### Parameter

None

#### Default value

None

#### Usage Guidelines

None

#### Command mode

EXEC, Global Configuration or Interface configuration

#### Example

None

# CHAPTER 2 RSTP CONFIGURATION COMMANDS

## 2.1. RSTP Configuration Commands

### 2.1.1. spanning-tree mode rstp

#### Syntax

**spanning-tree mode rstp**

**no spanning-tree mode**

To enable the RSTP function, run `spanning-tree mode rstp`. To disable the RSTP, run `no spanning-tree mode`.

#### Parameter

None

#### Default value

RSTP is enabled.

#### Usage Guidelines

None

#### Example

The following command shows how to enable `rstp` on OLT.

```
Switch_config# spanning-tree mode rstp
```

```
Switch_config#
```

### 2.1.2. spanning-tree rstp forward-time

#### Syntax

**spanning-tree rstp forward-time time**

**no spanning-tree rstp forward-time**

To configure the forwarding delay of RSTP, run `spanning-tree rstp forward-time time`.

To resume the default forwarding delay of RSTP, run `no spanning-tree rstp forward-time`.

#### Parameter

Parameter	Description
<i>time</i>	Time of the forwarding delay whose value ranges between 4 and 30 seconds.

#### Default value

15s

## Usage Guidelines

None

### Example

The following example shows how to set the forwarding delay of RSTP to 20 seconds.

```
Switch_config# spanning-tree rstp forward-time 20
```

```
Switch_config#
```

### 2.1.3. **spanning-tree rstp hello-time**

#### Syntax

**spanning-tree rstp hello-time *time***

**no spanning-tree rstp hello-time**

To configure the update interval of RSTP, run **spanning-tree rstp hello-time *time***.

To resume the default update interval of RSTP, run **no spanning-tree rstp hello-time**.

#### Parameter

Parameter	Description
<i>time</i>	Update interval. The value ranges: 1-10s.

#### Default value

2s

## Usage Guidelines

The Hello-Time configured on the local OLT validates only when the local OLT runs as a root OLT.

### Example

The following example shows how to set the update interval of RSTP to 8 seconds.

```
Switch_config# spanning-tree rstp hello-time 8
```

```
Switch_config#
```

### 2.1.4. **spanning-tree rstp max-age**

#### Syntax

**spanning-tree rstp max-age *time***

**no spanning-tree rstp max-age**

To configure the maximum lifespan of the RSTP BPDU, run **spanning-tree rstp max-age *time***. To resume the default interval time, run **no spanning-tree rstp max-age**.

#### Parameter

Parameter	Description
<i>time</i>	Maximum interval of the lifespan. Value ranges: 6-40s.

**Default value**

20s

**Usage Guidelines**

None

**Example**

The following example shows how to set the maximum lifespan of RSTP to 24 seconds.

```
Switch_config# spanning-tree rstp max-age 24
```

```
Switch_config#
```

**2.1.5. spanning-tree rstp priority****Syntax**

**spanning-tree rstp priority *value***

**no spanning-tree rstp priority**

To configure the RSTP priority value, run **spanning-tree rstp priority *value***. To resume the default value of the RSTP priority value, run **no spanning-tree rstp priority**.

**Parameter**

Parameter	Description
<i>value</i>	Priority level of the bridge. The value ranges: 0-61440, step 4096.

**Default value**

32768

**Usage Guidelines**

None

**Example**

The following example shows how to configure the priority level of the bridge of *rstp* to 4096.

```
Switch_config# spanning-tree rstp priority 4096
```

```
Switch_config#
```

### 2.1.6. **spanning-tree rstp cost**

#### Syntax

To configure the path cost of a port, run **spanning-tree rstp cost value**. To resume the default value, run **no spanning-tree rstp cost**.

**spanning-tree rstp cost value**

**no spanning-tree rstp cost**

#### Parameter

Parameter	Description
<i>value</i>	Value of the path cost. The value ranges: 1-200000000.

#### Default value

The path cost depends on the connection rate of the port.

10 Mbps: 2000000

100 Mbps: 200000

1000 Mbps: 20000

#### Usage Guidelines

None

#### Example

The following example shows how to set the path cost of port g0/1 to 24:

```
Switch_config_g0/1# spanning-tree rstp cost 24
```

```
Switch_config_g0/1#
```

### 2.1.7. **spanning-tree rstp port-priority**

#### Syntax

To configure the priority level of a port, run **spanning-tree rstp port-priority value**. To resume the default value, run **no spanning-tree rstp port-priority**.

**spanning-tree rstp port-priority value**

**no spanning-tree rstp port-priority**

#### Parameter

Parameter	Description
<i>value</i>	Priority level of a port. The value ranges: 0-240, step 16.

#### Default value

128

**Usage Guidelines**

None

**Example**

The following example shows how to set the path cost of port g0/1 to 16:

```
Switch_config_g0/1# spanning-tree rstp port-priority 16
```

```
Switch_config_g0/1#
```

**2.1.8. spanning-tree rstp edge****Syntax**

To configure the edge port, run **spanning-tree rstp edge**. To return to the default setting, run **no spanning-tree rstp edge**.

**spanning-tree rstp edge**

**no spanning-tree rstp edge**

**Parameter**

None

**Default value**

Automatic check

**Usage Guidelines**

None

**Command Mode**

Interface configuration

**Example**

None

**2.1.9. spanning-tree rstp point-to-point****Syntax**

To set the point-to-point connection of a port to force-truce, force-false or auto, run this command.

**spanning-tree rstp point-to-point [ force-true | force-false | auto ]**

**Parameter**

Parameter	Description
<b>force-true</b>	To set the point-to-point connection of a port to force-truce.

<i>force-false</i>	To set the point-to-point connection of a port to force-false.
<i>auto</i>	Sets the point-to-point connection to be automatic check (default).

**Default value**

Automatic check

**Usage Guidelines**

None

**Command Mode**

Interface Configuration

**Example**

None

**2.1.10. spanning-tree rstp migration-check****Syntax**

To restart checking protocol transfer of RSTP, run **spanning-tree rstp migration-check**.

```
spanning-tree rstp migration-check
```

**Parameter**

None

**Default value**

None

**Usage Guidelines**

This command is used to restart the protocol transfer check on a port and to change the port in STP-compatible mode to the RSTP mode, enabling RSTP BPDU to be transmitted.

**Command Mode**

Global and interface configuration

**Example**

The following example shows how to run protocol transfer check on interface G0/1:

```
Switch_config_g0/1#spanning-tree rstp migration-check
```

```
Switch_config_g0/1#
```

# CHAPTER 3 MSTP CONFIGURATION COMMANDS

## 3.1. MSTP Configuration Command

### 3.1.1. spanning-tree mode mstp

#### Syntax

To set the running mode of STP to MSTP, run **spanning-tree mode mstp**. To disable STP, run **no spanning-tree mode**.

**spanning-tree mode mstp**

**no spanning-tree mode**

#### Parameter

None

#### Default value

The MSTP mode is disabled, while the RSTP mode is running.

#### Usage Guidelines

None

#### Example

The following example shows how to enable MSTP protocol on the OLT:

```
switch(config)# spanning-tree mode mstp
switch(config)#
```

### 3.1.2. spanning-tree mstp name

#### Syntax

**spanning-tree mstp name** *string*

**no spanning-tree mstp name**

To configure the regional name of the STP, run **spanning-tree mstp name** *string*. To resume the default name, run **no spanning-tree mstp**.

#### Parameter

Parameter	Description
<i>String</i>	Configures the character string of the name. The character string can have up to 32 characters, capital sensitive. The default value is in the form of character string like the MAC address of the OLT.

#### Default value

Character string form of the OLT's MAC address

### Usage Guidelines

None

### Example

The following example shows how to set the configuration name of the OLT's STP to reg-01.

```
switch(config)# spanning-tree mstp name reg-01
switch(config)#{/pre}

```

### 3.1.3. spanning-tree mstp revision

#### Syntax

To generate the revision number of STP, run **spanning-tree mstp revision value**. To return to the default value, run **no spanning-tree mstp revision**.

**spanning-tree mstp revision value**

**no spanning-tree mstp revision**

#### Parameter

Parameter	Description
<i>Value</i>	Revision number: 0 ~65535 Its default value is 0.

#### Default value

The default value of the revision number is 0.

### Usage Guidelines

None

### Example

The following commands are used to set the regional revision number of STP to 100.

```
switch(config)# spanning-tree mstp revision 100
switch(config)#{/pre}

```

### 3.1.4. spanning-tree mstp instance

#### Syntax

To map the VLAN to the MSTI, run **spanning-tree mstp instance instance-id vlan vlan-list**. To re-map the VLAN to the CIST, run **no spanning-tree mstp instance instance-id**.

**spanning-tree mstp instance instance-id vlan vlan-list**

**no spanning-tree mstp instance *instance-id*****Parameter**

Parameter	Description
<i>instance-id</i>	Instance number of the STP, meaning an MSTI which ranges from 1 to 31.
<i>vlan-list</i>	VLAN list which is mapped to the STP, ranging from 1 to 4094.

**Default value**

All VLANs are mapped to the CIST (MST00).

**Usage Guidelines**

*instance-id* is an unique value representing an STP instance.

*vlan-list* represents a VLAN group, such as “1,2,3”, “1-5” and “1,2,5-10”.

**Example**

The following commands map VLAN1 to instance 1 of STP, and VLAN5,7,10-20 to instance 2 of STP, and then re-map these VLANs to MST00.

```
Switch_config# spanning-tree mstp instance 1 vlan 2
Switch_config# spanning-tree mstp instance 2 vlan 5,7,10-20
Switch_config# no spanning-tree mstp instance 1
Switch_config# no spanning-tree mstp instance 2
```

**3.1.5. spanning-tree mstp root****Syntax**

Configure the specified MSTP instance to the primary/secondary root. Run its negative form to restore the priority of MSTP instance to the default value.

To configure the specified MSTP instance to the primary/secondary root, run **spanning-tree mstp *instance-id* root {primary | secondary}**. To return to the default setting, run the negative form of the above command.

**spanning-tree mstp *instance-id* root {primary | secondary}**

**[ diameter *net-diameter* [ hello-time *seconds* ] ]**

**no spanning-tree mstp *instance-id* root**

Both the diameter command and the hello-time command can modify the network diameter and the HelloTime parameter of the MSTP when they are setting the root.

**Parameter**

Parameter	Description
<i>instance-id</i>	MSTP instance, ranging from 0 to 31.
<i>primary</i>	Sets the MSTP instance to the primary root.
<i>secondary</i>	Sets the MSTP instance to the secondary root.
<i>net-diameter</i>	Network diameter, which is optional When the instance-id parameter is 0, it is effective. It ranges from 2 to 7.
<i>seconds</i>	Hello time, an optional parameter, which ranges from 1 to 10 seconds.

### Default value

The priority value of all default roots of all MSTP instances are 32768, the network diameter is 7 and the HelloTime is 2 seconds.

### Usage Guidelines

Both the diameter command and the hello-time command are valid only when instance-id is 0.

Generally, after you run the command to set the primary root, the protocol automatically checks the ID of the current network root and then sets the priority field of the root identifier to 24576 if this value guarantees the current OLT to be the root of the MSTP instance. If the priority value of the root is smaller than 24576, the protocol will automatically set the MSTP priority of the current root to a value which is 4096 smaller than the root's priority. Here, 4069 is the step of the root priority.

Different from the configuration of the primary root, the protocol directly sets the MSTP priority of the OLT to **28672** after the command for configuring the secondary root is run. Thus, the current OLT can be the secondary root when the priorities of other OLTs are the default value **32768**.

### Example

The following commands are used to set the OLT to the primary root in the CIST and recalculate the time parameter of the MSTP through network diameter 3 and HelloTime3, and at last set the OLT to the secondary root in the MST01.

```
Switch_config# spanning-tree mstp 0 root primary diameter 3 hello-time 3
```

```
Switch_config# spanning-tree mstp 1 root secondary
```

### 3.1.6. spanning-tree mstp priority

#### Syntax

To configure the bridge priority of the MSTP instance, run **spanning-tree mstp instance-id priority value**. To return to the default setting, run **no spanning-tree mstp instance-id priority**.

**spanning-tree mstp instance-id priority value**

**no spanning-tree mstp instance-id priority**

### Parameter

Parameter	Description
<i>instance-id</i>	MSTP instance number, ranging from 0 to 31.
<i>value</i>	Bridge priority, which can be one of the given values: 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, 61440.

### Default value

The default priority of the bridges of all MSTP instances is 32768.

### Usage Guidelines

Each priority value in the MSTP instance is independent and can be configured independently.

### Example

The following commands are used to set the priority of the OLT in the CIST and MST01 to 4096 and 8192 respectively.

Switch\_config# spanning-tree mstp 0 priority 4096

Switch\_config# spanning-tree mstp 1 priority 8192

### 3.1.7. **spanning-tree mstp hello-time**

#### Syntax

**spanning-tree mstp hello-time seconds**

**no spanning-tree mstp hello-time**

It is used to configure the hello-time of the MSTP, and its negative form is used to resume the default settings of the HelloTime.

### Parameter

Parameter	Description
<i>seconds</i>	It ranges from 1 to 10 seconds. Its default value is 2 seconds.

### Default value

2 seconds

### Usage Guidelines

None

### Example

The following commands are used to set the HelloTime of the MSTP to 10.

```
switch(config)# spanning-tree mstp hello-time 10
switch(config)# no spanning-tree mstp hello-time
```

### 3.1.8. **spanning-tree mstp forward-time**

#### Syntax

```
spanning-tree mstp forward-time seconds
no spanning-tree mstp forward-time
```

It is used to configure the Forward Delay of the MTSP. Its negative is used to resume the default settings.

#### Parameter

Parameter	Description
<i>seconds</i>	It ranges from 4 to 30 seconds. Its default value is 15 seconds.

#### Default value

15 seconds

### Usage Guidelines

None

### Example

The following commands are used to set the Forward Delay parameter of the MTSP to 10.

```
Switch_config# spanning-tree mstp forward-time 10
Switch_config# no spanning-tree mstp forward-time
```

### 3.1.9. **spanning-tree mstp max-age**

#### Syntax

To configure the Max Age parameter of the MSTP, run **spanning-tree mstp max-age** *seconds*. To return to the default setting, run the negative form of the command.

```
spanning-tree mstp max-age seconds
no spanning-tree mstp max-age
```

## Parameter

Parameter	Description
<i>seconds</i>	Range: 6 – 40 seconds. The default value is 20 seconds.

## Default value

20 seconds

## Usage Guidelines

None

## Example

The following commands are used to set the MaxAge parameter of the MSTP to 10.

```
Switch_config# spanning-tree mstp max-age 10
```

```
Switch_config# no spanning-tree mstp max-age
```

## 3.1.10. spanning-tree mstp diameter

### Syntax

To configure the network diameter of the MSTP, run **spanning-tree mstp diameter *net-diameter***. To return to the default setting, run **no spanning-tree mstp diameter**.

**spanning-tree mstp diameter *net-diameter***

**no spanning-tree mstp diameter**

## Parameter

Parameter	Description
<i>net-diameter</i>	Range: 2 – 7. Its default value is 7.

## Default value

The default network diameter is 7.

## Usage Guidelines

The net-diameter parameter is not saved as an independent settings in the OLT. The time parameter that is modified through network diameter configuration can be saved. The net-diameter parameter is valid in the CIST. After settings, the three time parameters of the STP can be automatically updated to a relatively advantageous value.

It is recommended to set the time parameters of the STP through root configuration or network diameter configuration. In this way, the reasonability of the time parameters can be assured.

## Example

The following first command is to set the bridge diameter of MSTP to 5. The second command is to resume the default value of the bridge diameter.

```
Switch_config# spanning-tree mstp diameter 5
Switch_config# no spanning-tree mstp diameter
```

### 3.1.11. spanning-tree mstp max-hops

#### Syntax

**spanning-tree mstp max-hops *hop-count***

**no spanning-tree mstp max-hops**

The **spanning-tree mstp max-hops *hop-count*** command is used to set the maximum number of hops of the MSTP BPDU. Its negative is used to resume the default settings.

#### Parameter

Parameter	Description
<i>hop-count</i>	Ranges from: 6-40. Its default value is 20.

#### Default value

The default value of the maximum hop counts is 20.

#### Usage guidelines

None

#### Example

The first command is to set the maximum hop counts of the MSTP BPDU to 6. The second command is to restore the default value of the maximum hop counts.

```
Switch_config# spanning-tree mstp max-hops 6
Switch_config# no spanning-tree mstp max-hops
```

### 3.1.12. spanning-tree mstp port-priority

#### Syntax

To designate the priority of the spanning-tree STP instance, run **spanning-tree mstp *instance-id* port-priority *value***. To return to the default setting, run the no form of the command.

**spanning-tree mstp *instance-id* port-priority *value***  
**no spanning-tree *instance-id* port-priority**

#### Parameter

Parameter	Description
<i>instance-id</i>	Number of the STP instance, ranging from 0 to 31.
<i>Value</i>	Port priority, which is one of the following values: 0, 16, 32, 48, 64, 80, 96, 112 128, 144, 160, 176, 192, 208, 224, 240

#### Default value

The default priority value of the port in all STP instances is 128.

#### Usage Guidelines

None

#### Example

The first command is to set the priority of port G0/1 in the CIST to 16. The second command is to resume the default value.

```
Switch_config_g0/1# spanning-tree mstp 0 port-priority 16
Switch_config_g0/1# no spanning-tree mstp 0 port-priority
```

#### 3.1.13. spanning-tree mstp cost

#### Syntax

The command **spanning-tree mstp *instance-id* cost *value*** is used to set the path cost of the port in the specified STP instance. Its negative is used to resume the default settings.

**spanning-tree mstp *instance-id* cost *value***  
**no spanning-tree mstp *instance-id* cost**

#### Parameter

Parameter	Description
<i>instance-id</i>	Number of the STP instance, ranging from 0 to 31.
<i>Value</i>	Path cost of the port, ranging from 1 to 200000000.

#### Default value

It depends on the connection rate of the port:

10 Mbps: 2000000

100 Mbps: 200000

1000 Mbps: 20000

## Usage Guidelines

None

## Example

The following commands are used to set the path cost of port G0/1 in the CIST to 200.

```
Switch_config_g0/1# spanning-tree mstp 0 cost 200
```

```
Switch_config_g5/1#
```

### 3.1.14. spanning-tree mstp edge

#### Syntax

```
spanning-tree mstp edge
```

```
no spanning-tree mstp edge
```

To configure the edge port, run **spanning-tree mstp edge**. To return to the default setting, run **no spanning-tree mstp edge**.

#### Parameter

None

#### Default value

Automatic check edge port

## Usage Guidelines

None

## Example

None

### 3.1.15. spanning-tree mstp point-to-point

#### Syntax

```
spanning-tree mstp point-to-point { force-true | force-false | auto }
```

```
no spanning-tree mstp point-to-point
```

To configure the connection type of a port, run **spanning-tree mstp point-to-point { force-true | force-false | auto }**. To resume the connection type to auto-check, run **no spanning-tree mstp point-to-point**.

#### Parameter

Parameter	Description
<i>force-true</i>	Sets the port connection mode to point-to-point.
<i>force-false</i>	Sets the port connection mode to sharing.
<i>auto</i>	Sets the port connection mode to auto-check (the default mode).

### Default value

MSTP will automatically check the port connection mode by default.

### Usage Guidelines

None

### Example

The following example shows how to set the connection mode of port G0/1 to sharing.

```
Switch_config_g0/1# spanning-tree mstp point-to-point force-false
```

```
Switch_config_g0/1#
```

### 3.1.16. spanning-tree mstp mst-compatible

#### Syntax

**spanning-tree mstp mst-compatible**

**no spanning-tree mstp mst-compatible**

Enable/disable the MST-compatible mode, the global configuration mode.

**spanning-tree mstp mst-compatible {enable | disable}**

**no spanning-tree mstp mst-compatible**

Enable/disable the MST-compatible mode, the interface configuration mode.

#### Parameter

Parameter	Description
<i>enable</i>	Enable the MST-compatible mode.
<i>disable</i>	Disable the MST-compatible mode.

### Default value

The compatible mode is not activated by default and OLT cannot establish an area with other switches which transmit BPDU in compatible mode.

## Usage Guidelines

After the MST-compatible mode is enabled, configure other connected switches that are running other MSTP protocols to the roots of CIST, ensuring that the OLT can enter the MSTP-compatible mode by receiving the message.

### Example

The following command is to activate the MST-compatible mode in global configuration mode:

```
switch(config)#spanning-tree mstp mst-compatible
```

### 3.1.17. **spanning-tree mstp migration-check**

#### Syntax

**spanning-tree mstp migration-check**

Clear the STP information that is checked by the port, and restart the protocol conversion process.

#### Parameter

None

#### Default value

None

## Usage Guidelines

The command is valid in global configuration mode and in port configuration mode.

### Example

The following commands are used to check the protocol conversion on all ports first, and then check the protocol conversion on port G5/1 again.

```
Switch_config# spanning-tree mstp migration-check
```

```
Switch_config# interface g0/1
```

```
Switch_config_g0/1# spanning-tree mstp migration-check
```

### 3.1.18. **spanning-tree mstp restricted-role**

#### Syntax

**[no] spanning-tree mstp restricted-role**

Enable/disable the role restriction on the port.

#### Parameter

None

#### Default value

Disable the port's role restriction.

## Command Mode

Interface Configuration

## Usage Guidelines

Enable the role restriction and the port will not be chosen as the root port.

## Example

None

### 3.1.19. **spanning-tree mstp restricted-tcn**

## Syntax

[no] **spanning-tree mstp restricted-tcn**

Enable/disable the TCN restriction on the port.

## Parameter

None

## Default value

Disable the TCN restriction on the port.

## Command Mode

Interface Configuration

## Usage Guidelines

Enable the TCN restriction on the port and do not transmit topology changes to other ports.

## Example

None

### 3.1.20. **show spanning-tree mstp**

## Syntax

**show spanning-tree mstp [ instance *instance-id* ]**

The command above is used to check the MSTP information. If you run the command **show spanning-tree mstp**, the information about all STP instances is displayed.

## Parameter

Parameter	Description
<i>instance-id</i>	Number of the STP instance, ranging from 0 to 15.

## Default

None

## Usage Guidelines

It is valid in monitoring mode, global configuration mode or port mode.

### Example

The following shows how to view all STP instances through the command. Here, MST00 stands for CIST, and the Type field stands for the port connection type.

```
Switch#show spanning-tree mstp
```

```
MST00    Vlans Mapped: 1,4-4094
```

```
Root    Address 00E0.0F64.8365 Priority 32768 (32768 mst-id 0)
```

```
Root    This root is the CIST and regional root
```

```
Configured Hello Time 2, Forward Delay 15, Max Age 20, Max Hops 20
```

```
Root Times Hello Time 2, Forward Delay 15, Max Age 20
```

```
Interface    Role Sts Cost    Pri.Nbr Type
```

---

```
F0/1        Desg FWD 200000  128.1  P2p
```

```
F0/3        Back BLK 200000  128.3  P2p
```

```
F0/47       Desg FWD 200000  128.47 Edge
```

```
MST01    Vlans Mapped: 2
```

```
Root    Address 00E0.0F64.8365 Priority 32769 (32768 mst-id 1)
```

```
Root    This root for MST01
```

```
Interface    Role Sts Cost    Pri.Nbr Type
```

---

```
F0/1        Desg FWD 200000  128.1  P2p
```

```
MST02    Vlans Mapped: 3
```

```
Root    Address 00E0.0F64.8365 Priority 32770 (32768 mst-id 2)
```

```
Root    This root for MST02
```

```
Interface    Role Sts Cost    Pri.Nbr Type
```

---

```
F0/1        Desg FWD 200000  128.1  P2p
```

### 3.1.21. show spanning-tree mstp region

#### Syntax

```
show spanning-tree mstp region
```

Check the regional configuration information about the MSTP.

#### Parameter

None

**Default value**

None

**Usage Guidelines**

None

**Example**

See the following information. MST Config Table shows the relation between VLAN and STP instance.

```
switch(config)# show spanning-tree mstp region
```

MST Region:

Name: [reg01]

Revision:[0]

MST Config Table:

Instance	VLAN IDs
0	1,4-4094
1	2
2	3

**3.1.22. show spanning-tree mstp detail****Syntax**

```
show spanning-tree mstp detail
```

The command above is used to check the detailed information about MSTP.

**Parameter**

None

**Default value**

None

**Usage Guidelines**

None

**Example**

The following example shows the detailed STP information after the command is run, including the port connection type and optional characteristics:

```
Switch#show spanning-tree mstp detail
```

```
MST00    Vlans Mapped: 1,4-4094
```

Root Address 00E0.0F64.8365 Priority 32768 (32768 mst-id 0)  
Root This root is the CIST and regional root  
Configured Hello Time 2, Forward Delay 15, Max Age 20, Max Hops 20  
Root Times Hello Time 2, Forward Delay 15, Max Age 20  
FastEthernet0/1 of MST00 is designated forwarding  
Port Info Port ID 128.1 Priority 128 Cost 200000  
Designated Root Address 00E0.0F64.8365 Priority 32768 Cost 0  
CIST Regional Root Address 00E0.0F64.8365 Priority 32768 Cost 0  
Designated Root Address 00E0.0F64.8365 Priority 32768 Port ID 128.1  
Edge Port: disabled Link Type: point-to-point (auto)  
Bpdu Guard: disabled (default) Root Guard: disabled (default)  
Loop Guard: disabled (default)  
Timers: message expires in 0 sec, forward delay 0 sec, up time 662 sec  
Number of transitions to forwarding state: 1  
Bpdu sent 335, received 5  
FastEthernet0/3 of MST00 is backup blocking  
Port Info Port ID 128.3 Priority 128 Cost 200000  
Designated Root Address 00E0.0F64.8365 Priority 32768 Cost 0  
CIST Regional Root Address 00E0.0F64.8365 Priority 32768 Cost 0  
Designated Root Address 00E0.0F64.8365 Priority 32768 Port ID 128.1  
Edge Port: disabled Link Type: point-to-point (auto)  
Bpdu Guard: disabled (default) Root Guard: disabled (default)  
Loop Guard: disabled (default)  
Timers: message expires in 5 sec, forward delay 15 sec, up time 662 sec  
Number of transitions to forwarding state: 0  
Bpdu sent 5, received 335  
FastEthernet0/47 of MST00 is designated forwarding  
Port Info Port ID 128.47 Priority 128 Cost 200000  
Designated Root Address 00E0.0F64.8365 Priority 32768 Cost 0  
CIST Regional Root Address 00E0.0F64.8365 Priority 32768 Cost 0  
Designated Root Address 00E0.0F64.8365 Priority 32768 Port ID 128.47  
Edge Port: enabled (auto) Link Type: point-to-point (auto)  
Bpdu Guard: disabled (default) Root Guard: disabled (default)

Loop Guard: disabled (default)

Timers: message expires in 0 sec, forward delay 0 sec, up time 1485 sec

Number of transitions to forwarding state: 1

Bpdu sent 744, received 0

MST01 Vlans Mapped: 2

Root Address 00E0.0F64.8365 Priority 32769 (32768 mst-id 1)

Root This root for MST01

FastEthernet0/1 of MST01 is designated forwarding

Port Info Port ID 128.1 Priority 128 Cost 200000

Designated Root Address 00E0.0F64.8365 Priority 32769 Cost 0

Desingated Root Address 00E0.0F64.8365 Priority 32769 Port ID 128.1

Timers: message expires in 0 sec, forward delay 0 sec, up time 662 sec

Number of transitions to forwarding state: 1

MST Config Message transmitted 335, received 0

MST02 Vlans Mapped: 3

Root Address 00E0.0F64.8365 Priority 32770 (32768 mst-id 2)

Root This root for MST02

FastEthernet0/1 of MST02 is designated forwarding

Port Info Port ID 128.1 Priority 128 Cost 200000

Designated Root Address 00E0.0F64.8365 Priority 32770 Cost 0

Desingated Root Address 00E0.0F64.8365 Priority 32770 Port ID 128.1

Timers: message expires in 0 sec, forward delay 0 sec, up time 662 sec

Number of transitions to forwarding state: 1

MST Config Message transmitted 335, received 0

### 3.1.23. show spanning-tree mstp interface

#### Syntax

**show spanning-tree mstp interface *interface-id***

The command above is used to check the information about the port which is run under MSTP.

#### Parameter

Parameter	Description
-----------	-------------

<i>instance-id</i>	Port name, such as “G5/1”, “GigaEthernet5/2”.
--------------------	---

**Default value**

None

**Usage Guidelines**

None

**Example**

The following example shows the information about port G0/1 after you run the command Switch#show spanning-tree mstp interface g0/1:

GigaEthernet0/1 of MST00 is designated forwarding

Port Info      Port ID 128.1      Priority 128   Cost 200000

Designated Root      Address 00E0.0F64.8365   Priority 32768   Cost 0

CIST Regional Root      Address 00E0.0F64.8365   Priority 32768   Cost 0

Designated Bridge      Address 00E0.0F64.8365   Priority 32768   Port ID 128.1

Edge Port: disabled      Link Type: point-to-point (auto)

Bpdu Guard: disabled (default)      Root Guard: disabled (default)

Loop Guard: disabled (default)

Timers: message expires in 0 sec, forward delay 0 sec, up time 851 sec

Number of transitions to forwarding state: 1

Bpdu sent 430, received 5

GigaEthernet0/1 of MST01 is designated forwarding

Port Info      Port ID 128.1      Priority 128   Cost 200000

Designated Root      Address 00E0.0F64.8365   Priority 32769   Cost 0

Desingated Bridge      Address 00E0.0F64.8365   Priority 32769   Port ID 128.1

Timers: message expires in 0 sec, forward delay 0 sec, up time 851 sec

Number of transitions to forwarding state: 1

MST Config Message transmitted 430, received 0

GigaEthernet0/1 of MST02 is designated forwarding

Port Info      Port ID 128.1      Priority 128   Cost 200000

Designated Root      Address 00E0.0F64.8365   Priority 32770   Cost 0

Desingated Bridge      Address 00E0.0F64.8365   Priority 32770   Port ID 128.1

Timers: message expires in 0 sec, forward delay 0 sec, up time 851 sec

Number of transitions to forwarding state: 1

MST Config Message transmitted 430, received 0

Instance	Role	Sts	Cost	Pri.	Nbr	Vlans	Mapped
0	Desg	FWD	200000	128.1	1,4	4094	
1	Desg	FWD	200000	128.1	2		
2	Desg	FWD	200000	128.1	3		

### 3.1.24. show spanning-tree mstp protocol-migration

#### Syntax

The command above is used to check the protocol conversion information when the port is running under MSTP.

**show spanning-tree mstp protocol-migration**

#### Parameter

None

#### Default value

None

#### Usage Guidelines

None

#### Example

The following example shows the information about protocol conversion after the command show spanning-tree mstp protocol-migration is run. Note that port G5/1 has transferred to the 802.1D STP mode.

Switch#show spanning-tree mstp protocol-migration

MSTP Port Protocol Migration

Interface	Protocol
G0/1	802.1D