



QTECH
МИР ДОСТУПНЕЕ

ИНТЕЛЛЕКТУАЛЬНЫЕ КОММУТАТОРЫ УРОВНЯ ДОСТУПА И АГРЕГАЦИИ

QSW-3200-24EC

ТЕХНИЧЕСКОЕ ОПИСАНИЕ

Content

CHAPTER 1 ACCESSING SWITCH	1
1.1. COMMAND LINE INTERFACE.....	1
1.1.1. Command Line Configuration Mode	1
1.1.2. Command Syntax Comprehension	3
1.1.3. Syntax Help	3
1.1.4. History command.....	4
1.1.5. Symbols in command.....	4
1.1.6. Command Parameter Categories	5
1.2. USER MANAGEMENT	5
1.2.1. System default user name.....	5
1.2.2. Add user	5
1.2.3. Modify password.....	6
1.2.4. Modify privilege.....	6
1.2.5. Remove user name	7
1.2.6. View system user information	7
1.3. REMOTE AUTHENTICATION OF ADMINISTRATOR	7
1.3.1. Start RADIUS/TACACS+ remote authentication.....	7
1.3.2. Display authentication configuration	8
1.3.3. TACACS+ remote server configuration	8
1.3.4. Show TACACS+	8
1.4. WAYS OF MANAGING SWITCH.....	8
1.4.1. Manage switch by hyper terminal.....	8
1.4.2. Manage switch by telnet.....	9
CHAPTER 2 PORT CONFIGURATION	10
2.1 PORT CONFIGURATION INTRODUCTION.....	10
2.2 PORT CONFIGURATION	10
2.2.1 Port related configuration	10
2.2.2 Enter interface configuration mode	10
2.2.3 Enable/disable specified interface	10
2.2.4 Configure port-control mode	11
2.2.5 Configure interface duplex mode and speed rate	11
2.2.6 Interface Priority Configuration	11
2.2.7 Interface description configuration.....	12
2.2.8 Ingress/egress bandwidth-control configuration.....	12
2.2.9 Enable/disable VLAN filtration of receiving packet of interface	12
2.2.10 Interface ingress acceptable-frame configuration	12

2.2.11 Enable/disable interface flow-control.....	13
2.2.12 Port mode configuration	13
2.2.13 The default vlan-id of port configuration	13
2.2.14 Add port to specified VLAN	14
2.2.15 Display interface information.....	14
2.2.16 Display/ clear interface statistics information.....	14
2.3 INTERFACE MIRROR	15
2.3.1 Brief introduction of interface mirror	15
2.3.2 Interface mirror configuration.....	15
2.4 PORT LACP CONVERGENT CONFIGURATION.....	16
2.4.1 Brief introduction of port convergence.....	16
2.4.2 Interface convergent configuration.....	17
2.5 INTERFACE CAR CONFIGURATION	19
2.5.1 Brief introduction of interface CAR	19
2.5.2 Port CAR configuration command list	20
2.5.3 Enable/disable interface globally	20
2.5.4 Enable/disable interface CAR on a port	20
2.5.5 Configure the reopen time of the port shutdown by port-car	20
2.5.6 Configure the port-car-rate	21
2.5.7 Display port-car information	21
2.6 PORT ALARM CONFIGURATION	21
2.6.1 Brief introduction of port alarm configuration	21
2.6.2 Port alarm configuration list	21
2.6.3 Enable/disable port alarm globally	21
2.6.4 Enable/disable port alarm on the port.....	22
2.6.5 Configure the exceed threshold and normal threshold of port alarm	22
2.6.6 Display port alarm.....	22
2.7 INTERFACE SHUTDOWN-CONTROL CONFIGURATION.....	23
2.7.1 Brief introduction of shutdown-control	23
2.7.2 Interface shutdown-control Configuration list	23
2.7.3 shutdown-control Configuration	23
2.7.4 Configure shutdown-control open-time.....	23
2.7.5 Display shutdown-control	23
2.7.6 Recover shutdown-control.....	24
CHAPTER 3 VLAN CONFIGURATION	25
3.1 BRIEF INTRODUCTION OF VLAN	25
3.2 VLAN INTERFACE TYPE	25
3.3 DEFAULT VLAN.....	25
3.4 VLAN CONFIGURATION.....	25

3.4.1	VLAN configuration list	25
3.4.2	Create/delete VLAN.....	26
3.4.3	Add/delete VLAN interface	26
3.4.4	Specify/restore VLAN description	27
3.4.5	Configure interface type.....	27
3.4.6	Configure interface default vlan ID.....	27
3.4.7	Configure tag vlan	27
3.4.8	Display VLAN information.....	28
3.5	PVLAN	28
3.6	GVRP CONFIGURATION	28
3.6.1	Brief introduction of GVRP	28
3.6.2	GVRP Configuration list	28
3.6.3	Enable/disable global GVRP	29
3.6.4	Enable/disable GVRP on a port	29
3.6.5	Display GVRP	29
3.6.6	Add/delete vlan that can be dynamic learnt by GVRP	29
3.6.7	Display vlan that can be learnt by GVRP	30
3.6.8	Examples for GVRP configuration	30
3.7	QINQ CONFIGURATION	30
3.7.1	Brief introduction of QinQ.....	30
3.7.2	QinQ configuration list	30
3.7.3	Configure global QinQ.....	30
3.7.4	Configure QinQ mode of interface	30
3.8	L2-TUNNEL.....	31
3.8.1	Brief introduction of I2-tunnel.....	31
3.8.2	L2-tunnel configuration list.....	31
3.8.3	Enable/disable I2-tunnel	31
3.8.4	Show port I2-tunnel status	31
3.8.5	Configure /cancel I2-tunnel drop threshold.....	31
3.8.6	Show I2-tunnel drop threshold	32
3.9	VPRB	32
3.9.1	Brief introduction of VPRB.....	32
3.9.2	VPRB configuration list.....	32
3.9.3	Configure/delete VPRB port backup	32
3.9.4	Show VPRB	33
CHAPTER 4 ARP CONFIGURATION.....		34
4.1	BRIEF INTRODUCTION OF ARP	34
4.2	ARP CONFIGURATION.....	34
4.2.1	ARP configuration list	34

4.2.2 Delete ARP table item	34
4.2.3 Display ARP table item	34
CHAPTER 5 MULTICAST PROTOCOL CONFIGURATION.....	35
5.1 BRIEF INTRODUCTION OF GMRP	35
5.2 GMRP CONFIGURATION	35
5.2.1 GMRP Configuration list.....	35
5.2.2 Enable/disable global GMRP.....	35
5.2.3 Enable/disable GMRP on a port.....	35
5.2.4 Display GMRP	36
5.2.5 Add/delete multicast that can be dynamic learnt by GMRP	36
5.2.6 Display multicast that can be learnt by GMRP	36
5.3 IGMP SNOOPING CONFIGURATION	36
5.3.1 Brief introduction of IGMP Snooping	36
5.3.2 IGMP Snooping configuration	37
5.3.3 IGMP Snooping multicast interface aging time configuration	37
5.3.4 IGMP Snooping max-response-time configuration.....	37
5.3.5 IGMP Snooping interface fast-leave configuration	37
5.3.6 Configure the number of the multicast group allowed learning	38
5.3.7 IGMP Snooping permit/deny group configuration	38
5.3.8 IGMP Snooping route-port forward configuration	38
5.3.9 Enable/disable IGMP Snooping querier	38
5.3.10 Configure IGMP Snooping query-interval.....	39
5.3.11 Configure IGMP Snooping querier vlan	39
5.3.12 Configure IGMP Snooping query max response.....	39
5.3.13 Configure IGMP Snooping query source IP.....	39
5.3.14 Configure IGMP Snooping route port aging	40
5.3.15 Add IGMP Snooping route port	40
5.3.16 Configure IGMP Snooping multicast VLAN	40
5.3.17 Enable/disable IGMP Snooping preview	40
5.3.18 IGMP Snooping preview parameter.....	41
5.3.19 IGMP Snooping Multicast preview group configuration.....	41
5.3.20 Display IGMP Snooping multicast preview.....	41
5.3.21 IGMP Snooping profile	42
5.3.22 IGMP Snooping profile configuration.....	42
5.3.23 IGMP Snooping profile refer configuration.....	43
5.3.24 Show IGMP Snooping profile.....	43
5.3.25 igmp-snooping record-host	43
5.3.26 igmp-snooping drop query	43
5.3.27 igmp-snooping drop report.....	44

5.3.28 show igmp-snooping record-host	44
5.3.29 show multicast interface	44
5.4 STATIC MULTICAST CONFIGURATION	44
5.4.1 Brief introduction of Static Multicast	44
5.4.2 Static Multicast Configuration	44
5.5 CROSS-VLAN MULTICAST CONFIGURATION	46
5.5.1 Brief Introduction of Cross-Vlan multicast	46
5.5.2 Cross-VLAN Multicast Configuration	46
CHAPTER 6 DHCP CONFIGURATION	47
6.1 BRIEF INTRODUCTION OF DHCP	47
6.2 DHCP CONFIGURATION	47
6.2.1 DHCP Configuration list	47
6.2.2 Enable DHCP relay	47
6.2.3 Configre DHCP servers for each VLAN	47
6.3 DHCP SNOOPING	48
6.3.1 Enable DHCP Snooping	48
6.3.2 Configure trust ports	48
6.3.3 Configure max host number	48
6.3.4 Configure IP source guard	48
6.3.5 Show DHCP Snooping configuration of ports	49
6.3.6 Show DHCP Snooping configuration of VLANs	49
6.3.7 Show information of clients	49
CHAPTER 7 ACL CONFIGURATION	50
7.1 BRIEF INTRODUCTION OF ACL	50
7.1.1 Introduction of ACL	50
7.1.2 Matching order configuration	50
7.1.3 ACL support	50
7.2 ACL CONFIGURATION	51
7.2.1 Configuration list	51
7.2.2 Configure time range	51
7.2.3 Define ACL	52
7.2.4 Activate ACL	57
7.3 MONITOR AND MAINTANENCE OF ACL	57
CHAPTER 8 QOS CONFIGURATION	58
8.1 BRIEF INTRODUCTION OF QOS	58
8.2 QOS CONFIGURATION	60
8.2.1 QoS Configuration list	60
8.2.2 Priority configuration	60

8.2.3 Queue-scheduler configuration	61
8.2.4 The cos-map relationship of hardware priority queue and priority of IEEE802.1p protocol	61
8.2.5 Flow mirror configuration	61
8.2.6 Flow statistic configuration	62
8.2.7 Traffic rewrite vlan configuration	62
8.2.8 Traffic-insert-vlan configuration	62
8.3 MONITOR AND MAINTENANCE OF QoS.....	63
8.4 PORT ISOLATION	63
8.4.1 Brief introduction of port isolation	63
8.4.2 Port isolation configuration	64
8.5 STORM CONTROL.....	64
8.5.1 Brief introduction of storm control	64
8.5.2 Storm control configuration.....	64
CHAPTER 9 STP CONFIGURATION	66
9.1 BRIEF INTRODUCTION OF STP CONFIGURATION	66
9.2 STP CONFIGURATION	66
9.2.1 STP Configuration list	66
9.2.2 Enable/disable STP.....	66
9.2.3 Enable/disable interface STP	67
9.2.4 Configure STP priority.....	67
9.2.5 Configure switch Forward Delay	67
9.2.6 Configure Hello Time	68
9.2.7 Configure Max Age	68
9.2.8 Configure path cost of specified interfaces	68
9.2.9 Configure STP priority of specified port	69
9.2.10 Configure spanning-tree root-guard	69
9.2.11 Configure interface to force to send rstp packet	69
9.2.12 Configure link type of specified interface.....	69
9.2.13 Configure the current port as an edge port	70
9.2.14 Configure the speed limit of sending BPDU of specified interface	70
9.2.15 STP monitor and maintenance	70
9.2.16 Enable/disable STP remote-loop-detect.....	71
9.3 BRIEF INTRODUCTION OF MSTP	71
9.4 MSTP CONFIGURATION.....	72
9.4.1 MSTP configuration list.....	72
9.4.2 Configure MSTP timer parameter	72
9.4.3 Configure MSTP configuration mark.....	72
9.4.4 Configure MSTP netbridge priority	73

9.4.5 Configure MSTP interface edge interface status	73
9.4.6 Configure MSTP interface link type.....	73
9.4.7 Configure MSTP interface path cost	73
9.4.8 Configure MSTP interface priority.....	74
9.4.9 Configure spanning-tree mst root-guard.....	74
9.4.10 Display MSTP configuration information.....	74
9.4.11 Enable/disable digest snooping	75
9.4.12 Configure Ignore of VLAN	75
CHAPTER 10 802.1X CONFIGURATION COMMAND	76
10.1 BRIEF INTRODUCTION OF 802.1X CONFIGURATION	76
10.2 802.1X CONFIGURATION.....	76
10.2.1 AAA configuration mode.....	76
10.2.2 RADIUS Server Configuration.....	76
10.2.3 Domain Configuration	78
10.2.4 802.1X Configuration	80
CHAPTER 11 SNTP CLIENT CONFIGURATION	82
11.1 BRIEF INTRODUCTION OF SNTP PROTOCOL.....	82
11.2 SNTP CLIENT CONFIGURATION.....	82
11.2.1 Enable/disable SNTP client.....	82
11.2.2 SNTP client working mode configuration	82
11.2.3 SNTP client unicast server configuration	83
11.2.4 SNTP client broadcast delay configuration	83
11.2.5 SNTP client multicast TTL configuration	83
11.2.6 SNTP client poll interval configuration	83
11.2.7 SNTP client retransmit configuration.....	84
11.2.8 SNTP client valid server configuration	84
11.2.9 SNTP client MD5 authentication configuration	84
CHAPTER 12 SYSLOG CONFIGURATION.....	85
12.1 BRIEF INTRODUCTION OF SYSLOG.....	85
12.2 SYSLOG CONFIGURATION.....	85
12.2.1 Enable/disable Syslog	86
12.2.2 Syslog sequence number configuration.....	86
12.2.3 Syslog time stamps configuration	86
12.2.4 Syslog terminal outputting configuration.....	86
12.2.5 Syslog logging buffered outputting configuration.....	87
12.2.6 Syslog Flash storage outputting configuration.....	87
12.2.7 Syslog logging host outputting configuration	88
12.2.8 Syslog SNMP Agent outputting configuration	89

12.2.9 Module debug configuration.....	89
CHAPTER 13 SSH CONFIGURATION.....	90
13.1 BRIEF INTRODUCTION OF SSH.....	90
13.2 SSH CONFIGURATION	90
13.2.1 Enable/disable SSH function of the device.....	90
13.2.2 SSH key configuration.....	90
13.2.3 Others	91
CHAPTER 14 SWITCH MANAGE AND MAINTENANCE.....	92
14.1 CONFIGURATION FILES MANAGEMENT	92
14.1.1 Edit configuration files	92
14.1.2 Modify and save current configuration	92
14.1.3 Erase configuration	92
14.1.4 Execute saved configuration	92
14.1.5 Display saved configuration	92
14.1.6 Display current configuration	93
14.1.7 Configure file executing mode shift	93
14.2 ONLINE LOADING UPGRADE PROGRAM.....	93
14.2.1 Upload and download files by TFTP.....	93
14.2.2 Upload and download files by FTP.....	94
14.2.3 Download files by Xmodem	95
14.3 FACILITY MANAGEMENT	95
14.3.1 MAC address table management.....	95
14.3.2 Reboot.....	98
14.4 SYSTEM MAINTENANCE.....	98
14.4.1 Use show command to check system information.....	98
14.4.2 Basic Configuration and Management.....	98
14.4.3 Network connecting test command.....	99
14.4.4 Loopback test command.....	99
14.4.5 Administration IP address restriction	100
14.4.6 The number of Telnet user restriction.....	100
14.4.7 Routing tracert command	101
14.4.8 cpu-car command	101
14.5 MONITOR SYSTEM BY SNMP.....	101
14.5.1 Brief introduction of SNMP	101
14.5.2 Configuration	102
14.6 SYSTEM IP CONFIGURATION	107
14.6.1 Configure and manage VLAN	107
14.6.2 Configuration ip address by manual operation.....	108
14.6.3 BOOTP	108

14.6.4 DHCP	108
14.6.5 Examples for IP address configuration.....	108
14.6.6 Display ip address	108
14.7 ENABLE/DISABLE DLF FORWARD PACKET	109
14.8 CPU ALARM CONFIGURATION.....	109
14.8.1 Brief introduction of CPU alarm	109
14.8.2 CPU alarm configuration list.....	109
14.8.3 Enable/disable CPU alarm.....	109
14.8.4 Configure CPU busy or unbusy threshold.....	110
14.8.5 Display CPU alarm information	110
14.9 ANTI-DOS ATTACK	110
14.9.1 IP segment anti-attack.....	110
CHAPTER 15 LLDP CONFIGURATION.....	111
15.1 BRIEF INTRODUCTION OF LLDP PROTOCOL.....	111
15.2 LLDP CONFIGURATION	111
15.2.1 LLDP configuration list.....	111
15.2.2 Enable/disable global LLDP	111
15.2.3 Configure LLDP hello-time.....	111
15.2.4 Configure LLDP hold-time.....	112
15.2.5 Interface LLDP packet receiving/sending mode configuration.....	112
15.2.6 Display LLDP information	112
CHAPTER 16 ERRP COMMAND CONFIGURATION.....	114
16.1 BRIEF INTRODUCTION OF ERRP	114
16.2 ERRP CONFIGURATION	114
16.2.1 ERRP Configuration list	114
16.2.2 ERRP configuration	114
16.2.3 Configure ERRP timer	114
16.2.4 Enter ERRP configuration mode	115
16.2.5 Configure ERRP domain working mode	115
16.2.6 Configure control-vlan of ERRP domain.....	115
16.2.7 Create ERRP ring	116
16.2.8 Enable/disable ERRP ring	116
16.2.9 Display ERRP domain and ring information.....	117
16.2.10 ERRP Query Solicitation	117
CHAPTER 17 PPPOE PLUS CONFIGURATION	118
17.1 BRIEF INTRODUCTION OF PPPoE PLUS	118
17.2 PPPoE PLUS CONFIGURATION	118
17.2.1 PPPoE Plus Configuration list.....	118

17.2.2 Enable/disable PPPoE Plus.....	118
17.2.3 Configure PPPoE Plus type	118
CHAPTER 18 CFM CONFIGURATION	119
18.1 BRIEF INTRODUCTION OF CFM	119
18.2 CFM CONFIGURATION	119
18.2.1 CFM Configuration list.....	119
18.2.2 Create/delete MD	119
18.2.3 Configure MD parameter	119
18.2.4 Create/delete MA	120
18.2.5 Configure MA parameter	120
18.2.6 Create/delete MEP	121
18.2.7 Create/delete RMEP	121
18.2.8 Create/delete MIP	121
18.2.9 Loopback	122
18.2.10 Linktrace	122
18.2.11 Show MD.....	123
18.2.12 Show MA.....	123
18.2.13 Show MP(MEP/MIP/RMEP)	123
18.2.14 Show/clear CCM statistics	123
18.2.15 Show/clear CCM database	124
18.2.16 Show cfm error.....	124
CHAPTER 19 FLEX LINKS CONFIGURATION	125
19.1 BRIEF INTRODUCTION OF FLEX LINKS	125
19.2 FLEX LINKS CONFIGURATION	125
19.2.1 Flex links Configuration list.....	125
19.2.2 Enable or disable Flex links of interface(or convergent interface).....	125
19.2.3 Configure Flex links preemption mode.....	125
19.2.4 Configure Flex links preemption mode delay.....	126
19.2.5 Display Flex links information	126
19.2.6 Configure MacMoveUpdate of Flex links	126
CHAPTER 20 EFM CONFIGURATION.....	128
20.1 EFM OVERVIEW.....	128
20.2 EFM CONFIGURATION	128
20.2.1 EFM configuration list	128
20.2.2 Enable/disable EFM	128
20.2.3 Configure EFM working mode	128
20.2.4 Configure EFM pdu-timeout.....	129
20.2.5 Configure link timeout.....	129

20.2.6 Configure response timeout	129
20.2.7 Configure link monitoring	130
20.2.8 Enable/disable remote failure indication	131
20.2.9 Enable/disable link monitoring	131
20.2.10 Enable/disable remote MIB variable obtaining	131
20.2.11 Enable/disable remote loopback	131
20.2.12 Enable/stop remote loopback	132
20.2.13 Configure handling remote loopback querying packet	132
20.2.14 Show EFM status	132
20.2.15 Show EFM info	133
20.2.16 Show EFM discovery	133
20.2.17 Show/clear EFM statistics	133
20.2.18 Show remote MIB	134

Chapter 1 ACCESSING SWITCH

This chapter is the basic knowledge for system management, including:

- Command line interface
- Command syntax comprehension
- Syntax help
- History command
- Symbols in command
- Parameter in command
- User management
- Ways for switch management

1.1. Command Line Interface

System provides a series of configuration command and command line interface. User can configure and manage switch by command line. Command line interface has the features as following:

- Local configuration by Console interface
- Local or remote configuration by TelNet
- Configure command classification protection to guarantee unauthorized user illegal accessing.
- Input “?” at any moment to obtain help information
- Provide such network test command as ping to diagnose network fault
- Provide FTP, TFTP, Xmodem to download and upload files
- Keywords partial matching searching is adopted by command line convertor for user to input non-conflicting key words, such as: interface command can only input “interf”

1.1.1. Command Line Configuration Mode

System command line adopts classification protection to prevent illegal accessing of unauthorized user. Each command mode is for different configuration with the connection and distinction. For example, after successful accessing, user of all level can enter common user mode which can only see the system operation information; administrator can input “enable” to enter privileged mode; input “configure terminal” to enter global configuration mode from privileged mode which can enter related configuration mode according to inputting different configuration command. For example:

Command line provides command mode as following:

- User mode
- Privileged mode
- Global configuration mode
- Interface configuration mode
- VLAN configuration mode
- AAA configuration mode
- RADIUS configuration mode
- Domain configuration mode

The function and details of each command mode are as following:

Table 1-1 Command Line Configuration Mode

Command line mode	Function	Prompt character	Command for entering	Command for exiting
User mode	See switch operation information	QTECH>	Connect with switch after inputting user name and password	exit disconnect with switch
Privileged mode	See switch operation information and manage system	QTECH#	Input enable in user mode	exit return to user mode quit disconnect with switch
Global configuration mode	Configure global parameter	QTECH(config)#	Input configure terminal in privileged mode	exit, end return to privileged mode quit disconnect with switch
Interface configuration mode	Configure interface parameter	QTECH(config-if-ethernet-0/1)#	Input “interface Ethernet 0/1” in global configuration mode, interface configuration can enter other interface mode and VLAN configuration mode without inputting “exit”.	end return to privileged mode exit return to global configuration mode quit disconnect with switch
VLAN configuration mode	Configure VLAN parameter	QTECH(config-if-vlan)#	Input “vlan 2” in global configuration mode, VLAN configuration mode can enter other VLAN mode and interface configuration mode without inputting “exit”.	
AAA configuration mode	Create domain	QTECH(config-aaa)#	Input “aaa” in global configuration mode	
RADIUS configuration mode	Configure RADIUS server parameter	QTECH(config-radius-default)#	Input “radius host default” in global configuration mode	end return to privileged mode exit return to AAA configuration mode
Domain configuration mode	Configure domain parameter	QTECH(config-aaa-test.com)#	Input “domain test.com” in AAA configuration mode	quit disconnect with switch

1.1.2. Command Syntax Comprehension

This chapter describes the steps needed for command configuration. Please read this section and related detail information of command line interface in the following sections carefully.

The logging in identity verification of the system console of this switch is used to verify the identity of the operating user. It permits and refuses the logging in by matching recognizing user name and password.

Step 1: Following are showed when entering command line interface,

Username(1-32 chars):

Please input user name, press Enter button, and then the prompt is as following:

Password (1-16 chars):

Input password. If it is correct, enter the user mode with the following prompt:

QTECH>

In switch system, there are 2 different privileges. One is administrator, and the other is common user. Common user only can see the configuration information of switch without right to modify it but administrator can manage and configure the switch by specified command.

Logging in as administrator can enter privileged mode from user mode.

QTECH>enable

Step 2: Input command

Skip to step 3, if the command needs input the parameter. Continue this step if the command need input the parameter.

If the command needs a parameter, please input it. When inputting a parameter, keyword is needed.

The parameter of the command is specified which is the number or character string or IP address in a certain range. Input “?” when you are uncomprehending, and input the correct keyword according to the prompt. Keyword is what is to be operated in command.

If more than one parameter are needed, please input keywords and each parameter in turn according to the prompt until “<enter>”is showed in prompt to press enter button.

Step 3: Press enter button after inputting complete command.

For example:

! User need not input parameter

QTECH#quit

“quit” is a command without parameter. The name of the command is quit. Press enter button after inputting it to execute this command.

! User need input parameter

QTECH(config)#vlan 3

“vlan 3”is a command with parameter and keyword, vlan of which is command keyword and 3 of which is parameter.

1.1.3. Syntax Help

There is built-in syntax help in command line interface. If you are not sure about the syntax of some command, obtain all command and its simple description of the current mode by inputting “?” or help command; list all keywords beginning with the current character string by inputting “?” closely after the command character string; input “?” after space, if “?” is in the same location of the keyword, all keywords and its simple description will be listed, if “?”is in the same location of parameter, all the parameter description will be listed, and you can continue to input command according to the prompt until the prompt command is “<enter>” to press enter button to execute

command.

For example:

Directly input “?” in privileged mode

QTECH#?

System mode commands:

cls clear screen

help description of the interactive help

ping ping command

quit disconnect from switch and quit

.....

Input “?” closely after keyword

QTECH(config)#interf?

interface

Input “?” after command character string and space

QTECH(config)#spanning-tree ?

forward-time config switch delaytime

hello-time config switch hellotime

max-age config switch max agingtime

priority config switch priority

<enter> The command end.

4. Parameter range and form

QTECH(config)#spanning-tree forward-time ?

INTEGER<4-30> switch delaytime: <4-30>(second)

Command line end prompt

QTECH(config)#spanning-tree ?

<enter> The command end.

1.1.4. History command

Command line interface will save history command inputted by user automatically so that user can invoke history command saved by command line interface and re-execute it. At most 100 history commands can be saved by command line interface for each user. Input “Ctrl+P” to access last command, and “Ctrl+N” for next command.

1.1.5. Symbols in command

There are all kinds of symbols in command syntax which is not a part of command but used to describe how to input this command. Table 1-2 makes a brief description of these symbols.

Table 1-2 Command Symbols Description

Symbol	Description
Vertical bars	Vertical bars () means coordinate, together using with braces ({ }) and square brackets ([]).
Square brackets []	Square brackets ([]) mean optional elements. For example: show vlan [<i>vlan-id</i>]
Braces { }	Braces ({ }) group required choices, and vertical bars () separate the alternative elements. Braces and vertical bars within square brackets ([{ }]) mean a required choice within an optional element.

1.1.6. Command Parameter Categories

There are 5 categories command parameter as following:

- scale

Two numerical value linked by hyphen in angle brackets (< >) means this parameter is some number in the range of those two numbers.

For example: INTEGER<1-10> means user can input any integer between 1 and 10 (include 1 and 10), such as 8 is a valid number.

- IP address

The prompt which is in the form of A.B.C.D. means the parameter is an IP address. A valid IP address is needed to input.

For example: 192.168.0.100 is a valid IP address.

- MAC address

The prompt which is in the form of H:H:H:H:H:H means the parameter is a MAC address. A valid MAC address is needed to input. If a multicast MAC address is needed, there will be related prompt.

For example: 01:02:03:04:05:06 is a valid MAC address.

- Interface list

The prompt of interface list is STRING<3-4>. Interface parameter interface-num is in the form of interface-type + interface-number. Interface-type is Ethernet and interface-number is slot-num/port-num, in which slot-num is in the range of 0 to 2, and port-num is in the range of 1 to 24. Seriate interfaces with the same type can be linked by to keyword, but the port number to the right of the to keyword must be larger than the one to the left of the keyword, and this argument only can be repeated for up to 3 times. The special declaration of interface parameter interface list will be displayed in the command.

For example: show spanning-tree interface ethernet 0/1 ethernet 0/3 to ethernet 0/5 means displaying spanning-tree information of interface ethernet 0/1 ethernet 0/3 to ethernet 0/5

- Character string

The prompt which is in the form of STRING<3-4> means the parameter is a character string which is in the form of 1 to 19 characters. "?" can be inputted to display the concrete command description.

1.2. User management

There are 2 privileges for user:

- administrator
- normal user

Normal user can only enter user mode not privileged mode after logging in, so that he can only see system information but not to configure it. Administrator has the right to enter all modes, and query and configure all parameters.

1.2.1. System default user name

There is a system default built-in user name called admin, and the initial password is 123456. It is suggested modifying password when logging in switch for the first time to avoid leaking it. This user name cannot be deleted and the privilege cannot be modified either. It also possesses the right to manage other users. Please remember your modified password.

1.2.2. Add user

Log in with the identity of system administrator admin to enter privileged mode, then global configuration mode by using username command. Input user name, user's privilege, password to add new user according to system prompt or by using the following command.

```
username username [ privilege level ] { password encryption-type password }
```

username: User name of new users and existed users ranges from 1 to 32 printable characters excluding such wildcards as '/', ':', '*', '?', '\\', '<', '>', '|', '"' etc.

privilege: Privilege of new user ranges from 0 to 15. 0 to 1 means user while 2 to 15 means administrator.

encryption-type: the value of it is 0 or 7. 0 means non-encryption and 7 means encryption (It is not supported now).

Password: Log in password for new user and modified password of the existed user ranges from 1 to 16 characters or numbers.

If the privilege doesn't configure, the default privilege is ordinary user. At most 8 users are supported.

Caution: User name supports case insensitivity while password doesn't support case sensitivity.

! Add a new administrator "QTECH", configure privilege to be 3, and password to be 1234

```
QTECH(config)#username QTECH privilege 3 password 0 1234
```

1.2.3. Modify password

In global configuration mode, system administrator admin can use the following command to modify password of his or other user. Other user can only modify his own password.

```
username change-password
```

For example:

! Modify the password of user "QTECH" to be 123456

```
QTECH(config)#username change-password
```

```
please input you login password: *****
```

```
please input username :QTECH
```

```
Please input user new password: *****
```

```
Please input user confirm password: *****
```

```
change user QTECH password success.
```

1.2.4. Modify privilege

In global configuration mode, only administrator admin can use following command to modify the privilege of other user.

```
username username [ privilege level ] { password encryption-type password }
```

username: User name of new users and existed users ranges from 1 to 32 printable characters excluding such wildcards as '/', ':', '*', '?', '\\', '<', '>', '|', '"' etc.

privilege: Privilege of new user or the modified privilege of existed user ranges from 0 to 15. 0 to 1 means user while 2 to 15 means administrator. Caution: the privilege of administrator cannot be modified.

encryption-type: the value of it is 0 or 7. 0 means non-encryption and 7 means encryption (It is not supported now).

Password: Log in password for new user and modified password of the existed user ranges from 1 to 16 characters or numbers.

If inputting nothing to modify the privilege of existed user, the privilege doesn't modify.

Caution: User name supports case insensitivity while password doesn't support case sensitivity.

For example:

! Modify the privilege of administrator "QTECH" to be 1, and password to be 1234

```
QTECH(config)#username QTECH privilege 1 password 0 1234
```

1.2.5. Remove user name

System administrator admin can use following command to remove user name in global configuration mode

```
no username username
```

Username is the user name to be deleted.

For example:

! Remove user QTECH

```
QTECH(config)#no username QTECH
```

1.2.6. View system user information

View user list, and input show username command or show username [username] command in any configuration mode to display information of all users.

For example:

! Display information of user qtech

```
QTECH(config)#show username qtech
```

display user information

```
user name      role
```

```
qtech          ADMIN
```

1.3. Remote authentication of administrator

Switch administrators can be saved in local database and also in RADIUS/TACACS+ server. The user is authenticated to RADIUS/TACACS+ server through RADIUS/TACACS+ protocol.

After authentication, user's default privilege is normal user. Only when there is Service-Type field in authentication accepting packet the value of which is Administrative, user's privilege is administrator.

If it is TACACS+ remote authentication, when the authorization is not used, the privilege after authentication is administrator; when the authorization is used, the privilege after authentication is determined by the replied priv_lvl from remote server, if there is no reply, it is administrator; if the authorization fails, it is normal user.



Caution: Admin user only supports local database authentication.

1.3.1. Start RADIUS/TACACS+ remote authentication

Use following command in global configuration mode:

```
muser { local | { radius radiusname { pap | chap } [ local ] } } {tacacs+ [author] [account] [local]}
```

It can be configured to authenticate only by RADIUS/TACACS+ remote authentication or by local database authentication after no response of RADIUS/TACACS+ server caused by failing connection.

The accounting of TACACS+ is from the beginning to the end.

1.3.2. Display authentication configuration

Use following command to display authentication configuration.
show muser

1.3.3. TACACS+ remote server configuration

Use following command in global configuration mode:

```
tacacs+ { primary | secondary } server ipaddress [key keyvalue] [port portnum] [timeout timevalue]
```

The default port number is 49 and the timeout is 5 seconds.

1.3.4. Show TACACS+

Use following command in any configuration mode:

```
show tacacs+
```

1.4. Ways of managing switch

System provides following ways of management:

- By hyper terminal accessing command-line interface (CLI)
- By telnet managing system
- By SNMP managing software management system
- By Web browser, such as Internet Explorer managing system

1.4.1. Manage switch by hyper terminal

Use hyper terminal (or simulation terminal software) connect to Console to access system command line interface (CLI) by hyper terminal.

Configuration: Open “file” -> “attribute” menu, popping up a window. Enter configuration to restore it to default value, and click “setting” and then choose “auto-detect” in the pulldown list of “terminal simulation” and click [ok]. After the successful connection and seeing logging in interface of operation system in terminal, configure switch by command line interface. The steps are as following:

Step 1: Connect switch Console with computer serial port;

Step 2: After the switch power on and system successful booting, logging in prompt can be seen:

Username(1-32 chars):

Step 3: Input correct user name, press enter button, then input corresponding password. If it is the first time to logging in switch, use default user name admin and its password 123456 to log in and operate as system administrator. If your own user name and password exist, log in with your own user name and password;

Step 4: After successfully logging in, following information is displayed:

```
QTECH>
```

Step 5: As administrator, after entering privileged mode, use copy running-config startup-config command to save configuration.

```
QTECH#copy running-config startup-config
```

When following information is displayed:

```
Startup config in flash will be updated, are you sure(y/n)? [n]y
```

```
Building, please wait...
```

It means system is saving configuration. Please wait, then the prompt is:

Build successfully.

It means current configuration is saved successfully.

Following information is displayed when system booting:

Ready to load startup-config, press ENTER to run or CTRL+C to cancel:

Press enter button to make saved configuration be effective, and press CTRL+C to restore system default configuration.

Step 6: Administrator can use stop connection when overtime, while normal user can use this function in user mode. Input timeout command to configure the overtime of user's logging in to be 20 minutes. And use no timeout command to configure overtime to be non-over timing.

Step 7: Input following command after finishing operation to switch:

QTECH#quit

It is used to exit user interface.

1.4.2. Manage switch by telnet

Step 1: Establish configuration environment by connecting computer by network to switch interface;

Step 2: Run Telnet program in computer;

Step 3: After switch is power on, input switch IP address to connect to switch, and input configured logging in password according to the prompt, then the command line prompt is displayed (such as QTECH>). It will be disconnected after 1 minute when there is not any input before successfully logging in or wrong inputting of user name and password for 5 times. If

there is such prompt as "Sorry, session limit reached.", please connect later (At most 2 telnet users are allowed to log in at the same time.);

Step 4: Use related command to configure switch system parameter or view switch operation. If you want to enter privileged mode, user must possess the privilege of administrator. If you need any help, please input "?" at any moment. For concrete command, please refer to following chapters.

Step 5: If you want to exit telnet, use quit or exit command to exit in user mode, and quit command or "ctrl+] to exit in other mode. Administrator can use stop username command in privileged mode to exit logging in.

Chapter 2 PORT CONFIGURATION

2.1 Port configuration introduction

System can provide 24 10/100Base-T Ethernet interfaces, 2 100Base-TX Ethernet interfaces and a Console interface. Ethernet interface can work in half duplex and full duplex mode, and can negotiate other working mode and speed rate with other network devices to option the best working mode and speed rate automatically to predigest system configuration and management.

2.2 Port Configuration

2.2.1 Port related configuration

Configure related feature parameter of ports should enter interface configuration mode first, and then configure.

Interface configuration list is as following:

- Enter interface configuration mode
- Enable /disable specified interface
- Configure port-control mode
- Configure duplex mode and speed rate
- Configure interface privilege
- Configure interface limited speed
- Configure type of receiving frame
- Configure interface type
- Configure default VLAN ID of trunk port
- Add access port to specified VLAN
- Display interface information

2.2.2 Enter interface configuration mode

Enter interface configuration mode before configuration.

Configure as following in global configuration mode:

- Enter interface configuration mode

interface ethernet interface-num

Interface-num is Ethernet interface number which is in the form of slot-num/port-num, in which slot-num is in the range of 0 to 2, and port-num is in the range of 1 to 24.

2.2.3 Enable/disable specified interface

After system booting, all the interfaces are defaulted to be enable, and each interface can be configured according to real situation.

Use following commands to enable/disable an Ethernet port.

shutdown

no shutdown

Shutdown means disable a port, while no shutdown means enable a port.

For example:

! Enable Ethernet interface 1

```
QTECH(config-if-ethernet-0/1)#no shutdown
```

```
! Disable Ethernet interface 25
```

```
QTECH(config-if-ethernet-1/1)#shutdown
```

When interface is shutdown, the physical link is working for diagnosis.

2.2.4 Configure port-control mode

After booting, by default, all ports are slave mode. Configure mode of each port.

Configure master/slave mode in interface configuration mode:

```
port-control mode { master | slave }
```

```
no port-control mode
```

no port-control mode is used to restore port to slave mode.

Example:

```
! Configure e1/1 to be master
```

```
QTECH(config-if-ethernet-1/1)# port-control mode master
```

```
! Restore port control mode of e1/1(default mode is slave)
```

```
QTECH(config-if-ethernet-1/1)# no port-control mode
```

Caution: Only extended GE TX can configure port control mode to work the configuration of two GE TX with mode being force.

Show port-control mode in any configuration mode (only GE TX needs showing):

```
show port-control mode
```

2.2.5 Configure interface duplex mode and speed rate

10/100/1000Base-T supports 10Mbps, 100Mbps, 1000Mbps and full duplex, half duplex auto-negotiation. 1000Base-X only supports 1000Mbps, full duplex and auto-negotiation. By default, the port is in auto mode. User can configure the working mode by himself. Use speed command to configure the speed and duplex command to configure duplex.

- Command form in interface mode

```
speed { 10 | 10auto | 100 | 100 auto | 1000 | 1000 auto | auto }
```

```
no speed
```

```
duplex { auto | full | half }
```

```
no duplex
```

For example:

```
!Configure the speed of Ethernet 0/1 to 100Mbps and duplex mode to be full duplex
```

```
QTECH(config-if-ethernet-0/1)#speed 100
```

```
QTECH(config-if-ethernet-0/1)#duplex full
```

In system, if one of speed and duplex is set to be auto, the other will also be auto.

2.2.6 Interface Priority Configuration

There are 8 priorities from 0 to 7, and the default interface priority is 0. The larger the priority value is, the higher the priority is. And the packet with the higher priority will be quickly handled. If there are too much packet to be handled in some interface or the packet is urgent to be handled, priority of this interface can be configured to be high-priority.

Use following command in interface configuration mode:

- Configure priority of Ethernet 0/5 to be 1

```
QTECH(config-if-ethernet-0/5)#priority 1
```

- Restore the default priority of Ethernet 0/5

QTECH(config-if-ethernet-0/5)#no priority

2.2.7 Interface description configuration

Use following command to describe interface to distinguish each interface from others. Configure it in interface configuration mode.

description description-list

For example:

! Configure description string "QTECH" for the Ethernet 0/3

QTECH(config-if-ethernet-0/3)#description QTECH

! Display description of Ethernet 0/3

QTECH(config)#show description interface ethernet 0/3

2.2.8 Ingress/egress bandwidth-control configuration

Egress/ingress bandwidth-control is to restrict the total speed rate of all sending and receiving packets.

Use following command to configure engress/ingress bandwidth-control.

Configure it in interface configuration mode:

Interface engress/ingress bandwidth-control

bandwidth-control { ingress | egress } target-rate

Cancel engress/ingress bandwidth-control

no bandwidth-control { ingress | egress }

Detailed description of this command please refer to the corresponding command reference.

2.2.9 Enable/disable VLAN filtration of receiving packet of interface

When enabling VLAN ingress filtration, received 802.1Q packet which doesn't belong to the VLAN where the interface locates will be dropped. The packet will not be dropped if it is disabled.

Use this command in interface configuration mode.

ingress filtering

no ingress filtering

Example:

! Enable VLAN ingress filtration of e0/5

QTECH(config-if-ethernet-0/5)#ingress filtering

! Disable VLAN ingress filtration of e0/5

QTECH(config-if-ethernet-0/5)#no ingress filtering

2.2.10 Interface ingress acceptable-frame configuration

Configure ingress acceptable frame mode to be all types or only tagged.

Use following command in interface configuration mode to configure or cancel the restriction to ingress acceptable-frame:

ingress acceptable-frame { all | tagged }

no ingress acceptable-frame

For example:

! Configure Ethernet 0/5 only to receive tagged frame

```
QTECH(config-if-ethernet-0/5)#ingress acceptable-frame tagged
```

2.2.11 Enable/disable interface flow-control

If the port is crowded, it needs controlling to avoid congestion and data loss. Use flow-control command to control the flow. Use following command to enable/disable flow-control on current Ethernet port.

```
flow-control
```

```
no flow-control
```

For example:

```
! Enable flow control on Ethernet 0/5
```

```
QTECH(config-if-ethernet-0/5)#flow-control
```

```
! Disable flow control on Ethernet 0/5
```

```
QTECH(config-if-ethernet-0/5)#no flow-control
```

Use following command in any configuration mode to display interface flow-control:

```
show flow-control [ interface-num ]
```

For example:

```
! Display flow-control of Ethernet 0/5
```

```
QTECH(config-if-ethernet-0/5)#show flow-control ethernet 0/5
```

2.2.12 Port mode configuration

This command is for configuring port type. Port can be trunk, hybrid and access, trunk port is tagged in the vlan it belongs to, so the packets sent by this port is tagged; hybrid port can be tagged and untagged in the vlan it belongs to, so it allows packets of multiple VLANs to be sent with or without the Tag label; access only port belongs to one VLAN and it is untagged in VLAN. Configure it in interface configuration mode:

Configure port mode

```
switchport mode { trunk | hybrid | access }
```

Restore to default mode, hybrid port

```
no switchport mode
```

For example:

```
! Configure port 1 to be trunk
```

```
QTECH(config-if-ethernet-0/1)#switchport mode trunk
```

Shift to other port mode:

1) to access: keep default VLAN to be untagged vlan and deleted from other VLANs;

2) to hybrid: All vlan tagged status to be untagged;

3) to trunk: All vlan tagged status to be tagged;

2.2.13 The default vlan-id of port configuration

Use this command to configure the default vlan-id. Use the no command to restore it to default vlan ID. When received untagged packets, this port will forward it to default vlan. Packets sending and receiving is with IEEE 802.1Q standard. Configure it in interface configuration mode:

- Configure default VLAN ID

```
switchport default vlan vlan-id
```

- Restore default VLAN ID

```
no switchport default vlan
```

For example:

! Configure default vlan id of Ethernet0/1 to be 5

QTECH(config-if-ethernet-0/1)# switchport default vlan 5

2.2.14 Add port to specified VLAN

Use this command to add port to specific . Use no command to delete it from specific vlan. Configure it in interface configuration mode:

- Add trunk port to specific VLAN
switchport trunk allowed vlan { all | vlan-list }
- Delete trunk port from specific VLAN
no switchport trunk allowed vlan { all | vlan-list }
- Add hybrid port to specific tagged vlan list
switchport hybrid tagged vlan { all | vlan-list }
- Add hybrid port to specific untagged vlan list
switchport hybrid untagged vlan { all | vlan-list }
- Delete hybrid port from specific VLAN
no switchport hybrid vlan { all | vlan-list }
- Add access port to specific VLAN
switchport access vlan vlan-id

2.2.15 Display interface information

Use show interface [interface-num] to display information of specified interface or all interfaces:

- Interface state (enable/disable)
- Connection
- Working mode (full duplex, half duplex or auto-negotiation)
- Default VLAN ID
- Interface priority
- Port mode (trunk/access port)

If no parameter is input in show interface [interface-num] command, information of all interfaces will be displayed.

2.2.16 Display/ clear interface statistics information

Use show statistics interface [interface-num] command in any configuration mode to display information of specified interface or all interfaces:

- Byte receiving
- Unicast packet receiving
- Non-unicast packet receiving
- Unicast packet sending
- Non-unicast packet sending

Use clear interface [interface-num | slot-num] command in global configuration mode to clear information of specified interface or all interfaces in specified slot or all interfaces. Use clear interface command in interface configuration mode to clear information of current interface.

2.3 Interface mirror

2.3.1 Brief introduction of interface mirror

System provides mirror based on interface, that is, copy packet in a or more specified interface to monitor interface to analyze and monitor packet. For example, copy packet of Ethernet 0/2 to specified monitor interface Ethernet 0/3 so that test and keep record by protocols linked by monitor interface Ethernet 0/3.

System also provides packet mirror for specified source/destination MAC address. For example, mirror packet from Ethernet 0/3 with the destination MAC address of 00:1f:ce:00:00:01.

System also provides mirror divider, that is, sample packet that can be mirrored and send it to mirror destination interface to reduce the number of packet to mirror destination interface.

2.3.2 Interface mirror configuration

Interface Mirror configuration command includes:

- Configure mirror destination interface
- Configure mirror source interface
- Display interface mirror

Configure mirror interface

Configure mirror destination interface in global configuration mode:

- Configure mirror interface

mirror destination-interface interface-num

This command will cancel original mirror destination interface.

- Remove mirror interface

no mirror destination-interface interface-num

For example:

! Configure Ethernet 0/0/1 to be mirror interface

```
QTECH(config)# mirror destination-interface ethernet 0/0/1
```

Configure mirror source interface

Configure mirror source-interface of switch in global configuration mode:

- Configure mirror source-interface

```
mirror source-interface { interface-list | cpu } { both | egress | ingress }
```

interface-list is in the form of interface-num [to interface-num], which can be repeated for 3 times. Cpu interface is in the form of character string "cpu"

both means mirroregress and ingress interfaces, egress means mirror interface egress and ingress means mirror interface ingress.

- Remove mirror source interface

```
no mirror source-interface { interface-list | cpu }
```

For example:

! Configure Ethernet 0/0/1 to Ethernet 0/0/12 to be mirror source interfaces

```
QTECH(config)# mirror source-interface ethernet 0/0/1 to ethernet 0/0/12 both
```

! Remove Ethernet 0/0/10 to Ethernet 0/0/12 from mirror source interfaces

```
QTECH(config)#no mirror source-interface ethernet 0/0/10 to ethernet 0/0/12
```

Display interface mirror

- Display interface mirror

Use show mirror command to display system configuration of current mirror interface, including monitor port and mirrored port list. Use this command in any configuration mode:

```
show mirror
```

For example:

! Display monitor port and mirrored port list

```
QTECH#show mirror
```

Delete all port and traffic mirror:

```
no mirror all
```

For example:

! Delete all port and traffic mirror

```
QTECH(config)#no mirror all
```

2.4 Port LACP convergent configuration

2.4.1 Brief introduction of port convergence

Port convergence is a channel group formed by many ports convergence to realize flow load sharing for each member. When a link cannot be used, flow of this link will be transferred to another link to guarantee the smoothness of the flow.

Basic configurations are:

1. 2 static or dynamic channel groups can be configured and at most 12 interface members can be configured in each group, and at most 8 interfaces can be convergent at the same time in each group which is determined by up/down status, interface number, LACP priority. Each group is defined to be a channel group, and the command line is configured around it.
2. Load balance strategy of each group can be divided into source MAC, destination MAC, source and destination MAC, source IP, destination IP, and source and destination IP. The default strategy is source MAC.
3. System and interface LACP priority can be configured. The default system priority is 32768, and interface priority is 128. To remove system and interface priority is to restore them to default ones.
4. LACP protocol of each interface can be configured. In static mode, interface is static convergent, and LACP protocol does not run; in active mode, interface will initiate LACP negotiation actively; in passive mode, interface only can response LACP negotiation. When interconnecting with other device, static mode only can interconnect with static mode; active can interconnect with active and passive mode, but passive mode only can interconnect with active mode. The default mode of interface is ACTIVE mode.

Each convergent interface need same layer 2 features, so there are following restrictions to interfaces in a channel group:

Static convergent interfaces and dynamic convergent interfaces can not be in a same channel group, but there can be static convergent channel as well as dynamic convergent channel.

1. Each interface in a same channel group must possess the same features as following: interface speed rate, working mode of full duplex, STP/GVRP/GMRP function, STP cost, STP interface priority, VLAN features (interface mode, PVID, VLAN belonged to, tag vlan list of access interface, allowed vlan list of trunk interface) and layer 2 multicast group belonged to.
2. If modifying the feature of one interface in the channel group, other interfaces will be modified automatically in the same place. The feature refers to point 2.

3. After convergence, static hardware item (ARL, MARL, PTABLE, VTABLE) will be modified, but there will be delay.
4. After convergence, only host interface can send CPU packet. If STP changes status of some interface, the status of the whole channel group will be changed.
5. After convergence, when transferring layer 2 protocol packet, STP/GARP/GNLINK will not transfer packet to the current channel group. If transferring to other channel group, only one packet will be transferred.

If there are members in the channel group, this channel group cannot be deleted. Delete interface members first.

Influence on choosing link redundancy caused by LACP system and interface priority. LACP provides link redundancy mechanism which needs to guarantee the redundancy consistency of two interconnected switches and user can configure redundancy link which is realized by system and interface priority. The redundancy choosing follows the following steps:

First, determine which switch is the choosing standard. For LACP packets interaction, each of the two switches knows each other's LACP system priority and system MAC and compares the LACP system priority to choose the smaller one; if the system priority is the same, compare MAC and choose the smaller one.

Then, choose redundancy link according to the interface parameter of the chosen switch. Compare interface LACP priority, and choose the inferior one to be redundant. If the priorities are the same, choose the interface whose interface number is larger to be redundant.

2.4.2 Interface convergent configuration

Port LACP configuration command includes:

- Channel group configuration

Please configure it in global configuration mode:

```
channel-group channel-group-number
```

Parameter "channel-group-number" is range from 0 to 5.

For example:

! Create a channel group with the group number being 0

```
QTECH(config)#channel-group 0
```

- Delete channel group
- no channel-group channel-group-number
- Add add port members to the group

```
channel-group channel-group-number mode {active | passive | on}
```

In interface configuration mode, add current interface to channel group and specify the mode of interface. If the channel group doesn't exist, create it.

For example:

! Add Ethernet 0/3 to channel-group 3 and specify the port to be active mode

```
QTECH(config-if-ethernet-0/0/3)#channel-group 3 mode active
```

- Delete interface member in channel group

no channel-group channel-group-number

In interface configuration mode, delete current interface from channel group.

For example:

! Delete interface Ethernet 0/0/3 from channel group 3

QTECH(config-if-ethernet-0/0/3)#no channel-group 3

- Configure load balance of switch
channel-group load-balance
{dst-ip|dst-mac|src-dst-ip|src-dst-mac|src-ip|src-mac}
choose physical link program when packet sending.

For example:

! Specify load-balance of channel-group 0 is destination mac

QTECH(config)#channel-group load-balance dst-mac

- Configure system LACP priority
lacp system-priority priority

For example:

! Configure LACP system priority is 40000

QTECH(config)#lacp system-priority 40000

- Delete system LACP priority
no lacp system-priority

Use this command to restore system default LACP priority to be 32768.

- Configure interface LACP priority
lacp port-priority priority

Use this command in interface configuration mode to configure LACP priority of the current interface

For example:

! Configure lacp port-priority of Ethernet 0/2 to be 12345

QTECH(config-if-ethernet-0/0/2)#lacp port-priority 12345

- Delete interface LACP priority
- no lacp port-priority
- Use this command to restore interface default LACP priority to be 128.
- Display system LACP ID

show lacp sys-id

System id is in the form of 16 characters of system priority and 32 characters of system MAC address.

For example:

! Display lacp system id

QTECH(config)#show lacp sys-id

- Display local information of channel group
show lacp internal [channel-group-number]

Use show lacp interval command to display the information of group members, if there is no keywords, all groups are displayed.

For example: Display the member information of channel group 2.

```
QTECH#show lacp internal 2
```

- Display information of neighbour interface of channel group
show lacp neighbor [channel-group-number]

Use show lacp neighbor command to display the information of the neighbour port in the group. If there is no keyword, the neighbor ports of all the groups are displayed.

For example: Display the information of the neighbour port of the group 2

```
QTECH#show lacp neighbor 2
```

- Show channel-group statistics
show statistics channel-group [channel-group-number]

Use this command to show channel-group statistics. If channel-group-number is not specified, show all.

Example: Show statistics of channel-group 2

```
QTECH#show statistics channel-group 2
```

- Clear channel-group statistics
clear channel-group [channel-group-number]

Use this command to clear channel-group statistics. If channel-group-number is not specified, clear all.

Example: Clear statistics of channel-group 2

```
QTECH#clear channel-group 2
```

- Show dynamic channel-group statistics
show statistics dynamic channel-group

Example: show dynamic statistics of all channel-group

```
QTECH(config)# show statistics dynamic channel-group
```

- Show utilization channel-group statistics
show utilization channel-group

Example: Show utilization channel-group statistics

```
QTECH(config)# show utilization channel-group
```

2.5 Interface CAR configuration

2.5.1 Brief introduction of interface CAR

Interface CAR is used to restrict the speed rate impacted CPU of single interface. CPU can make speed rate statistics of each interface. If the speed rate is larger than the configured threshold (it is defaulted to be 300 packet/second), disable this interface and send trap of interface being abnormal. After a certain time (it is defaulted to be 480 seconds), re-enable the interface. If this interface will not be re-disabled by interface CAR in 2 seconds, the storm of impacting CPU by interface is over, and the interface recovers, and sends the trap of interface

being normal. Caution: If the re-enabled interface is disabled again by impacting CPU packet in 2 seconds, no trap of interface being abnormal is sent.

2.5.2 Port CAR configuration command list

Port CAR configuration command includes:

- Enable/disable interface CAR globally
- Enable/disable interface CAR on a port
- Configure interface CAR re-enable time
- Configure interface CAR
- Display interface CAR status

2.5.3 Enable/disable interface globally

Configure it in global configuration mode

- Enable global interface
- port-car
- Disable global interface

no port-car

By default, port-car globally enables

For example:

! Enable port-car globally

```
QTECH(config)#port-car
```

2.5.4 Enable/disable interface CAR on a port

Please configure it in interface configuration mode:

- Enable interface CAR
- port-car
- Disable interface CAR

no port-car

For example:

! Enable port-car of Ethernet 0/8

```
QTECH(config-if-ethernet-0/8)#port-car
```

2.5.5 Configure the reopen time of the port shutdown by port-car

Please configure it in global configuration mode:

- Configure the reopen time of the port shutdown by port-car
- ```
port-car-open-time port-car-open-time
```

By default, port-car-open-time is 480 seconds

For example:

! Configure port-car-open-time to be 10 seconds

```
QTECH(config)#port-car-open-time 10
```

## 2.5.6 Configure the port-car-rate

Please configure it in global configuration mode:

- Configure the port-car-rate  
port-car-rate port-car-rate

Default port-car-rate is 30 packet/second

For example:

! Configure port-car-rate to be 100 packet/second

QTECH(config)#port-car-rate 100

## 2.5.7 Display port-car information

Input following command in any configuration mode to display port-car information:

show port-car

For example:

! Display port-car information

QTECH(config)#show port-car

## 2.6 Port Alarm Configuration

### 2.6.1 Brief introduction of port alarm configuration

System can monitor port packet receiving rate. If the rate of receiving packet is beyond the interface flow exceed threshold, send alarm of large interface flow and the interface is in the status of large interface flow. In this status, if the rate of receiving packet is lower than the interface flow normal threshold, send alarm of normal interface flow. This function can actively report the rate of receiving packet to user.

### 2.6.2 Port alarm configuration list

Port alarm configuration command includes:

- Enable/disable port alarm globally
- Enable/disable port alarm on the port
- Configure the exceed threshold and normal threshold of port alarm
- Display port alarm

### 2.6.3 Enable/disable port alarm globally

Please configure it in global configuration mode:

- Enable port alarm globally  
alarm all-packets

- Disable port alarm globally  
no alarm all-packets

By default, alarm all-packets enable.

For example:

! Enable global alarm all-packets

```
QTECH(config)#alarm all-packets
```

## 2.6.4 Enable/disable port alarm on the port

Please configure it in interface configuration mode:

- Enable port alarm on the port
  - alarm all-packets
  - Disable port alarm on the port
- ```
no alarm all-packets
```

For example:

! Enable alarm all-packets of Ethernet 0/0/8

```
QTECH(config-if-ethernet-0/0/8)# alarm all-packets
```

2.6.5 Configure the exceed threshold and normal threshold of port alarm

Please configure it in global configuration mode:

Configure the exceed threshold and normal threshold of port alarm

```
alarm all-packets threshold [ exceed exceed ] [ normal normal ]
```

Caution: Exceed > normal. By default, 100 BASE exceed threshold is 85, normal threshold is 60

For example:

! Configure alarm all-packets exceed threshold to be 500, and normal threshold to be 300

```
QTECH(config)#alarm all-packets threshold exceed 500 normal 300
```

2.6.6 Display port alarm

- Input following command in any configuration mode to display global interface alarm:

```
show alarm all-packets
```

For example:

! Display global alarm all-packets information

```
QTECH(config)#show alarm all-packets interface ethernet 0/0/1
```

- Input following command in any configuration mode to display interface alarm on the port:

```
show alarm all-packets interface [ interface-list ]
```

Keyword “interface-list” is alternative. If there is no keyword, the alarm all-packets of all the interfaces are displayed, or the information of specified port is displayed.

For example:

! Display the alarm all-packets interface information of Ethernet 0/0/1

```
QTECH(config)#show alarm all-packets interface ethernet 0/0/1
```

```
e0/1 port alarm information
```

```
Port alarm status: enable
```

```
Port alarm exceed threshold(Mbps) : 85
```

Port alarm normal threshold(Mbps) : 60

Total entries: 1.0

2.7 Interface shutdown-control Configuration

2.7.1 Brief introduction of shutdown-control

Interface shutdown-control is used to restrict the speed rate of unicast\ multicast\broadcast of single interface. If the rate is beyond the configured restricted value (that can be configured), the interface will be shut down and failure trap will be sent. After a while (it is defaulted to be 480 seconds, which can be configured), it may reopen. If the interface will not reshutdown-control in 2 seconds, it turns normal and normal trap will be sent. If the interface reshutdown-control in 2 seconds, the failure trap will not be sent.

2.7.2 Interface shutdown-control Configuration list

Interface shutdown-control Configuration list is as following:

- shutdown-control Configuration
- Configure shutdown-control open-time
- Display shutdown-control
- Recover shutdown-control

2.7.3 shutdown-control Configuration

Configure it in interface configuration mode:

- Enable shutdown-control
- shutdown-control [broadcast | multicast | unicast] target-rate
- Disable shutdown-control

no shutdown-control [broadcast | multicast | unicast]

By default, shutdown-control is disabled.

Example:

! Enable shutdown-control of e0/8 for broadcast and speed rate is 100pps.

```
QTECH(config-if-ethernet-0/8)#shutdown-control broadcast 100
```

2.7.4 Configure shutdown-control open-time

Configure it in global configuration mode:

- Configure shutdown-control open-time

```
shutdown-control-open-time
```

The default shutdown-control open-time is 480 seconds.

Example:

! Configure shutdown-control-open-time of CAR is 20 seconds

```
QTECH(config)# shutdown-control-open-time 20
```

2.7.5 Display shutdown-control

- Configure it in any configuration mode:

```
show shutdown-control interface
```

Example:

! Display interface shutdown-control information
QTECH(config)#show shutdown-control interface

2.7.6 Recover shutdown-control

Configure it in global configuration mode:

- Restore shutdown-control to be manual:
no shutdown-control-recover mode
- Restore shutdown-control time to be 480s:
no shutdown-control-recover automatic-open-time

Example:

! Restore shutdown-control to be manual
QTECH(config)# no shutdown-control-recover mode

Chapter 3 VLAN CONFIGURATION

3.1 Brief introduction of VLAN

System supports IEEE 802.1Q. There are 2 kinds of VLAN: tagged and untagged.

3.2 VLAN interface type

System supports IEEE 802.1Q which possesses two types of VLAN interfaces. One is tagged, and the other is untagged.

Tagged interface can add VLAN ID, priority and other VLAN information to the head of the packet which is out of the interface. If the packet has included IEEE 802.1Q information when entering the switch, the mark information will not be changed; if the packet has not included IEEE 802.1Q mark information, system will determine the VLAN it belongs to according to the default VLAN ID of the receiving interface. Network devices supported IEEE 802.1Q will determine whether or not to transmit this packet by the VLAN information in the mark.

Untagged interface can drop the mark information from all the packets which are out of the interface. When a frame is out of an untagged interface, it will not contain IEEE 802.1Q mark information. The function of dropping the mark makes the packet can be transferred from the network device supported mark to the one which doesn't support it.

Now, only the switch supported IEEE 802.1Q can recognize IEEE 802.1Q frame so only a port linking to a switch supported IEEE 802.1Q can be configured to be Tagged port.

3.3 Default VLAN

There is a default VLAN of production, which possesses following features:

- The name of this VLAN is Default which can be modified.
- It includes all ports which can be added and deleted.
- All the port mode of default VLAN is untagged which can be modified to be tagged.
- VLAN ID of default VLAN is 1 which cannot be deleted.

3.4 VLAN configuration

3.4.1 VLAN configuration list

Configure VLAN should create VLAN according to the need first, then configure VLAN interface and its parameter.

VLAN configuration list is as following:

- Create/delete VLAN
- Add/delete VLAN interface
- Specify/delete VLAN description
- Configure interface type
- Configure interface default vlan ID
- Configure tag vlan
- Display VLAN information

3.4.2 Create/delete VLAN

Configure it in global configuration mode:

- Enter VLAN configuration mode or create VLAN and enter it
vlan vlan-list

- Delete created VLAN or specified VLAN except VLAN 1

```
no vlan { vlan-list | all }
```

VLAN-ID allowed to configure by system is in the range of 1 to 4094. vlan-list can be in the form of discrete number, a sequence number, or the combination of discrete and sequence number, discrete number of which is separate by comma, and sequence number of which is separate by subtraction sign, such as: 2,5,8,10-20. Use the vlan command to enter VLAN configuration mode. If the vlan identified by the vlan-id keyword exists, enter VLAN configuration mode. If not, this command creates the VLAN and then enters VLAN configuration mode. For example, if VLAN 2 is not existed, system will create VLAN 2 first, then enter VLAN configuration mode; if VLAN 2 has existed, enter VLAN configuration mode.

When deleting VLAN, if the vlan-list is specified, delete corresponding VLAN. If choosing all, delete all existed VLAN except default VLAN. If deleting interface in VLAN, and default VLAN id is the same as the VLAN to be deleted, restore interface default VLAN ID to be default VLAN ID.isted VLAN except default VLAN. orresponding VLAN. has existed, enter VLAN configuration mode..

If the VLAN to be removed exists in the multicast group, remove the related multicast group first.

3.4.3 Add/delete VLAN interface

Use the switchport command to add a port or multiple ports to current VLAN. Use the no switchport command to remove a port or multiple ports from current VLAN. Use following commands in VLAN configuration mode:

- Add interface to specified VLAN

```
switchport { interface-list | all }
```

- Delete some interface from specified VLAN

```
no switchport { interface-list | all }
```

Interface-list is the optioned interface list which means a or more interfaces. If choose all, add all ports to current VLAN; if choosing all when deleting interface, all ports in current VLAN will be deleted. When deleting interface from VLAN 1, if the PVID of interface is 1, modify the PVID to be other VLAN ID before deleting this interface. When deleting interface in other VLAN ID, port PVID should be the same as the VLAN ID, and the port is also in VLAN 1, delete it. If this port is not in VLAN 1, modify port PVID to be other VLAN ID, delete the port.

There are two status of the interface in VLAN, one is tagged and the other is untagged. If the port is access port, add it to VLAN with the status of being untagged. If it is trunk port, change it to be tagged in VLAN.

For example:

! Add Ethernet 1, 3, 4, 5, 8 to current VLAN

```
QTECH(config-if-vlan)#switchport ethernet 0/0/1 ethernet 0/0/3 to ethernet 0/0/5 ethernet 0/0/8
```

! Remove Ethernet 3, 4, 5, 8 from current VLAN

```
QTECH(config-if-vlan)#no switchport ethernet 0/0/3 to ethernet 0/0/5 ethernet 0/0/8
```

Command switchport access vlan and its no command can also add and delete port to or from VLAN. Please refer to interface configuration of chapter 2.

3.4.4 Specify/restore VLAN description

The description string is used to distinguish each VLAN. Please configure it in VLAN configuration mode:

- Specify a description string to specified VLAN

description string

- Delete description string of specified VLAN

no description

string: It is in the range of 1 to 32 characters to describe the current VLAN. The characters can be printable, excluding such wildcards as '/', ':', '*', '?', '\\', '<', '>', '|', '"' etc.

For example:

! Specify the description string of the current VLAN as “market”

```
QTECH(config-if-vlan)#description market
```

! Delete the description string of VLAN

```
QTECH(config-if-vlan)#no description
```

3.4.5 Configure interface type

Use switchport mode command to configure port type. Please refer to interface configuration in chapter 2.

```
switchport mode { trunk | hybrid | access }
```

3.4.6 Configure interface default vlan ID

System supports IEEE 802.1Q. When receiving a untagged packet, system will add a tag to the packet, in which the VLAN ID is determined by the default VLAN ID of the receiving port. The command to configure default VLAN of trunk port is switchport trunk native vlan; for access port, use switchport access vlan command to configure default VLAN of specified interface. The detailed introduction of the corresponding no command is in chapter 2.

For example:

! Configure default vlan-id of Ethernet interface 1 to be 2

```
QTECH(config-if-ethernet-0/1)#switchport mode access
```

```
QTECH(config-if-ethernet-0/1)#switchport access vlan 2
```



Caution: To use switchport trunk native vlan vlan-id must guarantee the specified interface to be trunk, and belongs to specified VLAN, and the VLAN ID is not 1. Use switchport access vlan vlan-id to configure interface default VLAN and add it to the VLAN. The specified interface is access, and the VLAN is existed and is not the default VLAN.

3.4.7 Configure tag vlan

When port is hybrid without tag vlan configuration, it can only send untagged packets. If tagged packets is need, you can use command switchport hybrid tagged vlan {vlan-list|all}.

For example:

! Configure Ethernet interface 1 to send IEEE 802.1Q packet with tag VLAN 5, VLAN 7-10

```
QTECH(config-if-ethernet-0/1)#switchport hybrid tagged vlan 5,7-10
```

3.4.8 Display VLAN information

VLAN information is VLAN description string, vlan-id, VLAN status and interface members in it, tagged interfaces, untagged interfaces and dynamic tagged interfaces. Interface members consist of tagged and untagged members.

show vlan [vlan-id]

If the VLAN with specified keyword exists, this command displays the information of the specified VLAN. If no keyword is specified, this command displays the list of all the existing VLANs

For example:

! Display the information of existed VLAN 2.

```
QTECH(config)#show vlan 2
```

3.5 PVLAN

PVLAN means private VLAN which is used to realize interface isolation function. These private VLANs are unknown to uplink devices to save the resource of public VLAN. Nowadays, factories in this field use SVL to realize PVLAN and provide corresponding configuration command. But there is some shortage by using SVL, such as: the uplink and downlink interfaces are access, and MAC address wasting. Our company uses redirection technology to realize PVLAN and overcome the shortage of SVL, any interface can be access or trunk, which entirely realize PVLAN. The detailed information of PVLAN configuration can refer to interface isolation configuration.

3.6 GVRP configuration

3.6.1 Brief introduction of GVRP

GVRP, GARP VLAN Registration Protocol is a kind of application of GARP. It is based on GARP working mechanism to maintain VLAN dynamic register information in switch and transfer it to other switch. All switch that support GVRP can receive VLAN register information from other switches and dynamically upgrade local VLAN register information which includes: current VLAN members, and by which interface can reach VLAN members. And all switches supported GVRP can transfer local VLAN register information to other switches to make the consistency of the VLAN information of devices which support GVRP. VLAN register information transferred by GVRP includes local manual configuration of static register information and the dynamic register information of other switch.

3.6.2 GVRP Configuration list

In all configurations, enable global GVRP first before enable GVRP on a port. GVRP must be enabled in the two ends of trunk link which follows IEEE 802.1Q standard.

GVRP Configuration list is as following:

GVRP Configuration list is as following:

- Enable/disable global GVRP
- Enable/disable GVRP on a port
- Display GVRP
- Add/delete vlan that can be dynamic learnt by GVRP
- Display vlan that can be learnt by GVRP

3.6.3 Enable/disable global GVRP

Please configure it in global configuration mode:

- Enable global GVRP

```
gvrp
```

- Disable global GVRP

```
no gvrp
```

By default, GVRP globally disables

For example:

! Enable GVRP globally

```
QTECH(config)#gvrp
```

3.6.4 Enable/disable GVRP on a port

Please configure it in interface configuration mode:

- Enable GVRP on a port

```
gvrp
```

- Disable GVRP on a port

```
no gvrp
```

For example:

! Enable GVRP on Ethernet port 8

```
QTECH(config-if-ethernet-0/8)#gvrp
```



Caution: Enable global GVRP before enable GVRP on a port. By default, global GVRP deisables and GVRP on a port can be enabled in trunk mode interface.

3.6.5 Display GVRP

- Use following command in any configuration mode to display global GVRP:

```
show gvrp
```

- Use following command in any configuration mode to display GVRP on a port:

```
show gvrp interface [ interface-list ]
```

Interface-list keyword is optional. If this keyword unspecified, the command displays GVRP information for all the Ethernet ports. If specified, the command displays GVRP information on specified Ethernet port.

For example:

! Display GVRP information on interface Ethernet 0/1

```
QTECH(config)#show gvrp interface ethernet 0/1
```

3.6.6 Add/delete vlan that can be dynamic learnt by GVRP

Use garp permit vlan command to add configured static vlan to GVRP module for other switches to learn. Configure it in global configuration mode:

```
garp permit vlan vlan-list
```

```
no garp permit vlan [ vlan-list ]
```

For example: !Add vlan 2, 3, 4 to GVRP

```
QTECH(config)#garp permit vlan 2-4
```

3.6.7 Display vlan that can be learnt by GVRP

Use show garp permit vlan command to display current static vlan permitted learning by GVRP
show garp permit vlan

For example:

Display current static vlan permitted learning by GVRP

```
QTECH(config)#show garp permit vlan
```

3.6.8 Examples for GVRP configuration

! Enable GVRP on Ethernet port 2

```
QTECH(config-if-ethernet-0/0/2)#gvrp
```

! Disable GVRP on Ethernet port 2

```
QTECH(config-if-ethernet-0/0/2)#no gvrp
```

3.7 QinQ configuration

3.7.1 Brief introduction of QinQ

QinQ is used for the communication between discrete client vlan whose service model is the interconnection of one or more switches supported QinQ by service provider interfaces which are in service provider vlan. The interface linking client vlan is called customer interface. Packet with client vlan tag will add a tag head with the vlan id being service provider vlan when passing through the customer interface. The tag head will be stripped when passing through service provider vlan.

3.7.2 QinQ configuration list

- Configure global QinQ
- Configure interface QinQ

3.7.3 Configure global QinQ

QTECH QSW-3200-24TC can only support static QinQ:

1, static 802.1q in 802.1q. Vlan protocol number in this mode can be configured but can only be 0x8100 or 0x88a8 and there will be a new tag inserted between the 12th and 13th bit;

!Use dtag command to enable/disable QinQ globally in global configuration mode.

```
dtag { [ flexible-qinq ] | outer-tpid tpid }
```

```
no dtag
```

For example:

!Configure QinQ global TPID to be 0x88a8

```
QTECH(config)dtag outer-tpid 88A8
```

3.7.4 Configure QinQ mode of interface

There are two kinds of interface modes: one is service provider port, the other is customer port. The former do not permit ignoring tag head of ingress packet and the latter permits.

! It is in the interface configuration mode.

```
dtag mode { customer | service-provider }
```

Example:

Configure interface to be customer

QTECH(config-if-ethernet-0/1)#dtag mode customer

3.8 I2-tunnel

3.8.1 Brief introduction of I2-tunnel

In VPN network, some protocol packets received by service-provider network edge need to be encapsulated in a certain form. The internal devices of SP network can recognize and transparent transmit this encapsulated packets, and restore it in the other side of SP network.

3.8.2 L2-tunnel configuration list

- Enable/disable I2-tunnel
- Show port I2-tunnel status
- Configure/cancel I2-tunnel drop threshold
- Show I2-tunnel drop threshold

3.8.3 Enable/disable I2-tunnel

Configure protocols which need to enable I2-tunnel. Configure it in interface configuration mode:

- Enable port I2-tunnel

I2-tunnel [cdp | pagp | lacp | stp | udld | vtp]

- Disable port I2-tunnel

no I2-tunnel [cdp | pagp | lacp | stp | udld | vtp]

Parameter:

cdp: cisco's cdp packets

pagp: cisco's pagp packet

lacp: lacp packet

stp: stp packet

udld: cisco's udld packet

vtp: cisco's vtp packet

Example:

! Configure I2-tunnel for STP packet on e0/1.

QTECH(config-if-ethernet-0/1)#I2-tunnel stp

3.8.4 Show port I2-tunnel status

In any configuration mode:

- Show I2-tunnel

show I2-tunnel interface [interface-list]

Example:

! Show I2-tunnel for all ports

QTECH(config)#show I2-tunnel interface

3.8.5 Configure /cancel I2-tunnel drop threshold

Configure in global configuration mode:

- Configure speed rate for I2-tunnel packet up to cpu

I2-tunnel drop-threshold [cdp | pagp | lacp | stp | udld | vtp] target-rate

- Cancel I2-tunnel packet up to cpu
no I2-tunnel drop-threshold [cdp | pagp | lacp | stp | udd | vtp]
Example:
! Configure the speed of cpu receiving stp packet to be 10pps
QTECH(config)#I2-tunnel drop-threshold stp 10

3.8.6 Show I2-tunnel drop threshold

Show in any configuration mode:

- Show I2-tunnel drop threshold
show I2-tunnel drop-threshold

Example:

! Show I2-tunnel drop-threshold
QTECH(config)#show I2-tunnel drop-threshold

3.9 VPRB

3.9.1 Brief introduction of VPRB

VPRB (vlan port redundancy backup) is for vlan port backup. If there are multiple ports in a vlan, one of them can be specified to be a major-port, another is the backup port for the major-port. Generally, if major and backup-ports work normal, major-port is forwarding and backup-port is discarding, and all business packets will be sent by major-port. If major-port works abnormal and unable to forward packets, the backup-port will turn forwarding immediately and start sending business packets until the major-port works normal.

In order to achieve backup and load balance in batch, VPRB needs to work with MSTP. First, add backup vlan to MSTP instance, then configure the major-port and backup-port of this MSTP instance.

3.9.2 VPRB configuration list

- Configure/delete VPRB port backup
- Show VPRB

3.9.3 Configure/delete VPRB port backup

Configure it in global configuration mode:

- Configure VPRB port backup
vprb major-port ethernet port-id bak-port ethernet port-id instance inst-id
- Delete VPRB port backup
no vprb major-port ethernet port-id

Parameter:

port-id: major-port or backup port

inst-id: MSTP instance id

Example:

! Add vlan 1-10 to MSTP instance 1

QTECH(config)#spanning-tree mst instance 1 vlan 1-10

! Specify major-port is e0/1, backup port is e0/2

QTECH(config)#vprb major-port ethernet 0/1 bak-port ethernet 0/2 instance 1

3.9.4 Show VPRB

Configure it in any mode:

```
show vprb
```

Example:

```
! Show VPRB
```

```
QTECH(config)#show vprb
```

Chapter 4 ARP CONFIGURATION

4.1 Brief Introduction of ARP

ARP table is a table of the relationship between IP and MAC, including dynamic and static. Dynamic ARP table item is learnt by ARP protocol. Static ARP table item is added manually.

4.2 ARP configuration

4.2.1 ARP configuration list

Configuration list is as following:

- Delete ARP table item
- Display ARP table item

4.2.2 Delete ARP table item

Use this command can delete an ARP table item. ARP table item not only include corresponding relations of IP and MAC, but also the local VLAN and port number the frame with keyword MAC being destination address has passed.

Delete the corresponded ARP table item of IP address 192.168.0.100:

```
QTECH(config)#no arp 192.168.0.100
```

Delete all ARP table item:

```
QTECH(config)#no arp all
```

4.2.3 Display ARP table item

Use this command to display static, dynamic, specified IP address or all ARP table item.

Display all ARP table item:

```
QTECH(config)#show arp all
```

Display all ARP table item with the IP address being 192.168.0.100:

```
QTECH(config)#show arp 192.168.0.100
```

Chapter 5 MULTICAST PROTOCOL CONFIGURATION

5.1 Brief introduction of GMRP

GMRP (GARP Multicast Registration Protocol) is a kind of application of GARP (Generic Attribute Registration Protocol) which is based on GARP working mechanism to maintain the dynamic multicast register information in switch. All switches supported GMRP can receive multicast register information from other switches and upgrade local multicast register information dynamically and transfer it to other switches to make the consistency of multicast information of devices supported GMRP in the same switching network. Multicast register information transferred by GMRP includes local manual configuration of static multicast register information and the dynamic multicast register information of other switch.

5.2 GMRP Configuration

5.2.1 GMRP Configuration list

In all configurations, enable global GMRP first before enable GMRP on a port. GMRP Configuration list is as following:

- Enable/disable global GMRP
- Enable/disable GMRP on a port
- Display GMRP
- Add/delete multicast that can be dynamic learnt by GMRP
- Display multicast that can be learnt by GMRP

5.2.2 Enable/disable global GMRP

Please configure it in global configuration mode:

- Enable global GMRP

gmrp

- Disable global GMRP

no gmrp

By default, GMRP globally disables

For example:

! Enable GMRP globally

QTECH(config)#gmrp

5.2.3 Enable/disable GMRP on a port

Enable global GMRP before enable GMRP on a port. Please configure it in interface configuration mode:

- Enable GMRP on a port

gmrp

- Disable GMRP on a port

no gmrp

For example:

! Enable GMRP on Ethernet port 3

```
QTECH(config-if-ethernet-0/3)#gmrp
```



Caution: Enable global GMRP before enable GMRP on a port. By default, global GMRP deisables and GMRP on a port can be enabled in trunk mode interface.

5.2.4 Display GMRP

- Use following command in any configuration mode to display global GMRP:

```
show gmrp
```

- Use following command in any configuration mode to display GMRP on a port:

```
show gmrp interface [ interface-list ]
```

Interface-list keyword is optional. If this keyword unspecified, the command displays GMRP information for all the Ethernet ports. If specified, the command displays GMRP information on specified Ethernet port.

For example:

! Display GMRP information of Ethernet 0/2 to ethernet 0/4 ethernet 2/1

```
QTECH(config)#show gmrp interface ethernet 0/2 to ethernet 0/4 ethernet 2/1
```

```
port GMRP status
```

```
e0/2 enable
```

```
e0/3 enable
```

```
e0/4 enable
```

```
e2/1 enable
```

```
Total entries: 4.
```

5.2.5 Add/delete multicast that can be dynamic learnt by GMRP

Add configured static multicast group to GMRP for other switch learning it.

```
garp permit multicast [ mac-address mac vlan vlan-id ]
```

Example:

Add multicast group 01:00:5e:00:01:01 vlan 1 to GMRP

```
QTECH(config)#garp permit multicast mac-address 01:00:5e:00:01:01 vlan 1
```

5.2.6 Display multicast that can be learnt by GMRP

Display multicast group can be statically learnt by GMRP.

```
show garp permit multicast
```

For example: Display multicast group that can be statically learnt by GMRP

```
QTECH(config)#show garp permit multicast
```

5.3 IGMP Snooping Configuration

5.3.1 Brief introduction of IGMP Snooping

IGMP (Internet Group Management Protocol) is a part of IP protocol which is used to support and manage the IP multicast between host and multicast router. IP multicast allows transferring IP data to a host collection formed by multicast group. The relationship of multicast group member is dynamic and host can dynamically add or exit this group to reduce network load to the minimum to realize the effective data transmission in network.

IGMP Snooping is used to monitor monitor IGMP packet between host and routers. It can dynamically create, maintain and delete multicast address table according to the adding and leaving of the group members. At that time, multicast frame can transfer packet according to his own multicast address table.

5.3.2 IGMP Snooping configuration

Use following command to control IGMP Snooping to establish the MAC address multicast transmission table in layer 2.

Use following command in global configuration mode:

- Enable IGMP Snooping

```
igmp-snooping
```

- Disable IGMP Snooping

```
no igmp-snooping
```

By default, IGMP Snooping disables.

- Display IGMP Snooping

Use following command in any mode to see IGMP Snooping:

For example:

! Display IGMP snooping information

```
QTECH(config)#show igmp-snooping
```

5.3.3 IGMP Snooping multicast interface aging time configuration

Use following command in global configuration mode to configure host-aging-time dynamic multicast group learnt by igmp-snooping:

```
igmp-snooping host-aging-time
```

Use following command to display host-aging-time dynamic multicast group learnt by igmp-snooping:

```
show igmp - snooping
```

For example:

! Configure host-aging-time of the dynamic multicast group learnt by igmp-snooping to be 10 seconds

```
QTECH(config)#igmp-snooping host-aging-time 10
```

5.3.4 IGMP Snooping max-response-time configuration

Configure the max response time to delete group interface when receiving a leave packet:

```
igmp-snooping max-response-time seconds
```

Use this command in global configuration mode.

For example:

! Configure the max-response-time of igmp-snooping is 13 seconds

```
QTECH(config)#igmp-snooping max-response-time 13
```

5.3.5 IGMP Snooping interface fast-leave configuration

Configure interface fast-leave when fast-leave enables, if the fast-leave packet is received, the interface leaves the aging group, or the time to leave is determined by the max-response-time:

```
igmp-snooping fast-leave
```

Use this command in interface configuration mode.

For example:

! Enable igmp-snooping fast-leave

```
QTECH(config-if-ethernet-0/1)#igmp-snooping fast-leave
```

5.3.6 Configure the number of the multicast group allowed learning

Use igmp-snooping group-limit command to configure the number of the multicast group allowed learning.

```
igmp-snooping group-limit limit
```

Use this command in global configuration mode.

For example:

! Configure the igmp-snooping group-limit to be 10

```
QTECH(config-if-ethernet-0/1)#igmp-snooping group-limit 10
```

5.3.7 IGMP Snooping permit/deny group configuration

Configure igmp-snooping permit/deny group and default group learning regulation.

Configure igmp-snooping permit/deny group in interface configuration mode:

```
igmp-snooping permit/deny group group-address
```

```
igmp-snooping permit/deny group-range group-address multi-count <1-64> vlan vlan-id
```

Configure igmp-snooping default group learning regulation in global configuration mode:

```
igmp-snooping deny/permit group all
```

For example:

! Configure Ethernet 0/1 not to learn multicast 01:00:5e:00:01:01

```
QTECH(config-if-ethernet-0/1)#igmp-snooping deny group 01:00:5e:00:01:01
```

! Configure Ethernet 0/1 not to learn the first 32 serial MAC address of multicast 01:00:5e:00:01:01

```
QTECH(config-if-ethernet-0/0/1)#igmp-snooping deny group-range 01:00:5e:01:01:01 multi-count 32 vlan 1
```

! Configure the learning regulation of default group to allow all multicast group

```
QTECH(config)#igmp-snooping permit group all
```

5.3.8 IGMP Snooping route-port forward configuration

Multicast routers interface is the interface received IGMP inquiring packet (It is also called mix router interface.).

Use igmp-snooping route-port forward command to configure whether to add router interface to IGMP snooping learning group. By default, router interface to IGMP snooping learning group is not added.

Use following command in global configuration mode:

```
igmp-snooping route-port forward
```

```
no igmp-snooping route-port forward
```

For example:

! Enable igmp-snooping route-port forward

```
QTECH(config)#igmp-snooping route-port forward
```

5.3.9 Enable/disable IGMP Snooping querier

To set up multicast route table, send IGMP query packet. The unit to send the packet is called querier.

Enable or disable querier sending IGMP query packet. It is defaulted not to send.

Configure it in global configuration mode:

```
igmp-snooping querier
```

```
no igmp-snooping querier
```

Example:

```
! Enable igmp-snooping querier
```

```
QTECH(config)# igmp-snooping querier
```

5.3.10 Configure IGMP Snooping query-interval

Configure interval of sending IGMP query. It is defaulted to be 60s.

Configure it in global configuration mode:

```
igmp-snooping query-interval seconds
```

```
no igmp-snooping query-interval
```

Example:

```
! Configure interval of sending IGMP query to be 90s
```

```
QTECH(config)# igmp-snooping querier 90
```

5.3.11 Configure IGMP Snooping querier vlan

Sending IGMP query must specify vlan. Packet will be transferred to all ports of this vlan.

Configure vlan which IGMP query sent by querier to be sent to. It is defaulted to be vlan 1

Configure it in global configuration mode:

```
igmp-snooping querier-vlan vlanID
```

```
no igmp-snooping querier-vlan
```

Example:

```
! Configure querier sending query to vlan 10
```

```
QTECH(config)# igmp-snooping querier-vlan 10
```

5.3.12 Configure IGMP Snooping query max response

Configure the max response after receiving query, that is the response value in IGMP query. It is defaulted to be 10s.

Configure it in global configuration mode:

```
igmp-snooping query-max-respon second
```

```
no igmp-snooping query-max-respon
```

Example:

```
! Configure the max response after receiving query to be 15s
```

```
QTECH(config)# igmp-snooping query-max-respon 150
```

5.3.13 Configure IGMP Snooping query source IP

Configure IGMP query source IP to demonstrate the destination IP to response to. It is defaulted to be 0.0.0.0

Configure it in global configuration mode:

```
igmp-snooping general-query source-ip ipaddress
```

```
no igmp-snooping general-query source-ip
```

Example:

```
! Configure IGMP query source IP to be 1.1.1.111
```

```
QTECH(config)# igmp-snooping general-query source-ip 1.1.1.111
```

5.3.14 Configure IGMP Snooping route port aging

The port receiving IGMP query is called multicast route port.

Configure the aging of route port. It is defaulted to be aging.

Configure it in global configuration mode:

```
no igmp-snooping router-port-age
```

```
igmp-snooping router-port-age
```

Example:

Configure the route port aging

```
no igmp-snooping router-port-age
```

5.3.15 Add IGMP Snooping route port

Added route port demonstrates the transferred port of leave or report packet of the host in the same multicast.

Configure uplink route port of host responding packet.

Configure it in global configuration mode:

```
igmp-snooping route-port vlan vlanID interface port-number
```

```
no igmp-snooping route-port vlan vlanID interface port-number
```

Example:

Configure e0/0/1 of vlan 2 to be route port of current group (determined by source IP of querier)

```
igmp-snooping route-port vlan 2 interface ethernet 0/1
```

5.3.16 Configure IGMP Snooping multicast VLAN

This command is for specify a vlan for a port. All IGMP packets detected by IGMP snooping are considered from this vlan. And the Vlan ID in the IGMP packets will be ignored.

This function will be effective as soon as the multicast vlan is created. Configure it in interface configuration mode:

```
igmp-snooping multicast vlan vlan-id
```

```
no igmp-snooping multicast vlan
```

Example:

! Configure igmp-snooping multicast vlan of Ethernet 0/1 to be vlan 2

```
QTECH(config-if-ethernet-0/1)#igmp-snooping multicast vlan 2
```

5.3.17 Enable/disable IGMP Snooping preview

IGMP Snooping provides multicast preview. Use following command to enable/disable IGMP Snooping preview.

Configure following commands in global configuration mode:

- Enable IGMP Snooping preview

```
igmp-snooping preview
```

- Disable IGMP Snooping preview

```
no igmp-snooping preview
```

By default, IGMP Snooping preview is disabled.

Example:

! Enable IGMP Snooping preview

QTECH(config)#igmp-snooping preview

5.3.18 IGMP Snooping preview parameter

IGMP Snooping preview can configure preview time, time interval, reset time and preview times. Use following commands to configure IGMP Snooping preview parameter.

Use these commands in global configuration mode:

- Configure IGMP Snooping preview parameter

```
igmp-snooping preview { time-once time-once time-interval time-interval time-reset time-reset permit-times preview-times }
```

- Restore to default IGMP Snooping preview parameter

```
no igmp-snooping preview { time-once time-interval time-reset permit-times }
```

Parameter :

time-once: preview time for one time which is 60-300s. The default is 180s.

time-interval: preview interval which is 180-600s. The default is 300s.

time-reset: preview reset time which is 1800-7200s. The default is 3600s.

preview-times: permitted preview times which is 1-10. The default is 5

For example:

! Configure IGMP Snooping preview time to be 60s, preview interval to be 180s and permitted preview times to be 8

```
QTECH(config)#igmp-snooping preview time-once 60 time-interval 180 permit-times 8
```

5.3.19 IGMP Snooping Multicast preview group configuration

IGMP Snooping multicast preview is for specific group. Use following commands to add or delete IGMP Snooping multicast preview.

Use these commands in global configuration mode:

- Add IGMP Snooping multicast preview group

```
igmp-snooping preview group-ip A.B.C.D vlan vlan-id interface ethernet port-id
```

- Delete IGMP Snooping multicast preview group

```
no igmp-snooping preview group-ip A.B.C.D vlan vlan-id interface ethernet port-id
```

Parameter :

A.B.C.D: Multicast ip address which is in the range of 224.0.0.1-239.255.255.254

vlan-id: multicast vlan which is in the range of 1-4094

port-id: multicast port number the range is determined by device type

For example:

! Add an IGMP Snooping multicast preview group

```
QTECH(config)#igmp-snooping preview group-ip 224.0.0.9 vlan 20 interface ethernet 0/1
```

5.3.20 Display IGMP Snooping multicast preview

Display IGMP Snooping multicast preview in any mode:

- Display current multicast preview configuration

```
show igmp-snooping preview
```

- Display current multicast preview status

```
show igmp-snooping preview status
```

For example:

! Display current IGMP Snooping preview configuration

```
QTECH(config)#show igmp-snooping preview
```

5.3.21 IGMP Snooping profile

IGMP Snooping can provide profile for permit and deny. Create profile first and configure profile in interface configuration mode.

Use following commands in global configuration mode:

- Create profile and enter profile configuration mode
igmp-snooping profile profile-id
- Delete specific profile, which is not been used by port
no igmp-snooping profile [profile-list]

Parameter:

profile-id: profile id ranges from 1-16

profile-list: profile list ranges from 1-16

Example:

```
! Create IGMP Snooping profile 1
QTECH(config)#igmp-snooping profile 1
```

5.3.22 IGMP Snooping profile configuration

Use following command in profile configuration mode to configure IGMP Snooping profile permit or deny multicast IP or MAC.

- Configure profile type. Permit is by default. Profile which is used by port cannot be modified.

```
profile limit { permit | deny }
```

- Multicast IP addr range. If vlan is not specified, it is for all vlan

```
ip range start-ip end-ip [ vlan vlan-id ]
```

- Multicast MAC addr range. If vlan is not specified, it is for all vlan

```
mac range start-mac end-mac [ vlan vlan-id ]
```

- Delete IP range

```
no ip range [ start-ip end-ip [ vlan vlan-id ] ]
```

- Delete MAC range

```
no mac range [ start-mac end-mac [ vlan vlan-id ] ]
```

Parameter:

Profile type: permit and deny. When profile is permit, it can only learn the multicast group in profile. When it is deny, it is not permitted learning multicast group in profile.

start-ip: IP ranges from 224.0.0.1-239.255.255.254

end-ip: IP ranges from 224.0.0.1-239.255.255.254

start-mac: MAC ranges from 01:00:5e:H:H:H and it should start with 01:00:5e

end-mac: MAC ranges from 01:00:5e:H:H:H, and it should start with 01:00:5e

vlan-id: multicast used vlan ranges from 1-4094

Example:

```
! Configure IP and MAC addr of IGMP Snooping profile 1 and specify the type is deny
QTECH(config-igmp-profile-1)#ip range 224.0.0.1 224.0.0.10 vlan 1
QTECH(config-igmp-profile-1)#mac range 01:00:5e:00:00:22 01:00:5e:00:00:33
QTECH(config-igmp-profile-1)#profile limit deny
```

5.3.23 IGMP Snooping profile refer configuration

IGMP Snooping profile can only be effective after it is referred by port. When there are multiple profiles are referred, they must be with the same type, that is, there can be only permit or only deny. If there is no profile referred by this port, it can learn all multicast groups.

Configure it in interface configuration mode:

- Specify the profile list for port
igmp-snooping profile refer profile-list
- Cancel port referred profile list
no igmp-snooping profile refer [profile-list]

Parameter:

profile-list: profile list ranges from 1-16

Example:

! Configure port 1 referring profile 1 and 3

```
QTECH(config-if-ethernet-0/1)#igmp-snooping profile refer 1,3
```

5.3.24 Show IGMP Snooping profile

Use following command in any configuration mode:

- Show profile info in profile list
show igmp-snooping profile [profile-list]
- Show profile info in port list
show igmp-snooping profile interface [port-list]

Parameter:

profile-list: profile list ranges from 1-16

port-list: port list

Example:

! Show profile 1, 2, 3

```
QTECH(config)#show igmp-snooping profile 1-3
```

5.3.25 igmp-snooping record-host

Use following command to record host mac.

```
igmp-snooping record-host
```

```
no igmp-snooping record-host
```

[Command configuration mode]

Global configuration mode or interface mode

[Example]

! Enable record host

```
QTECH(config)#igmp-snooping record-host
```

5.3.26 igmp-snooping drop query

Use this command to configure drop igmp query.

```
igmp-snooping drop query
```

```
no igmp-snooping drop query
```

[Command configuration mode]

Interface configuration mode

[Example]

! Configure drop igmp query packet in port 1
QTECH(config-if-ethernet-0/1)#igmp-snooping drop query

5.3.27 igmp-snooping drop report

Use this command to drop igmp report packet.

igmp-snooping drop report

no igmp-snooping drop report

[Command configuration mode]

Interface configuration mode

[Example]

! Configure port 1 to drop igmp report packet

QTECH(config-if-ethernet-0/1)#igmp-snooping drop report

5.3.28 show igmp-snooping record-host

Use this command to show igmp record-host.

show igmp-snooping record-host

[Command configuration mode]

Any mode

[Example]

! Show igmp record host

QTECH(config)#show igmp-snooping record-host

5.3.29 show multicast interface

Use this command to show multicast group learnt by port.

show multicast interface

[Command configuration mode]

Any mode

[Example]

! Show multicast group learnt by port 1

QTECH(config)#show multicast interface ethernet 0/1

5.4 Static Multicast Configuration

5.4.1 Brief introduction of Static Multicast

Static multicast configuration command is used to create multicast group and add interfaces to it. If the switch supports multicast, when receiving multicast packet, detect whether there is multicast group. If it doesn't exist, transfer the multicast packet as broadcast packet. If it exists, transfer the multicast packet to all interface members of this multicast group.

5.4.2 Static Multicast Configuration

Static Multicast Configuration list

Configure static multicast in following turns:

- Create multicast group
- Add interfaces to multicast group

- Display multicast group information
- Delete interface members from multicast group
- Delete multicast group

Create multicast group

Use following command in global configuration mode to create a multicast group:

```
multicast mac-address mac vlan vlan-id
```

mac: The mac address of multicast group displayed in the form of multicast address, such as: 01:00:5e:**:**.vlan-id ranges from 1 to 4094. If the VLAN doesn't exist, the multicast group adding fails.

Example:

```
! Create a multicast group to VLAN 1 with the mac address being 01:00:5e:01:02:03
```

```
QTECH(config)#multicast mac-address 01:00:5e:01:02:03 vlan 1
```

Add interfaces to multicast group

Use multicast mac-address vlan interface command in global configuration mode to add interface to existed multicast group:

```
multicast mac-address mac vlan vlan-id interface { all | interface-list }
```

mac: Means mac address of existed multicast which is in the form of multicast mac-address, such as: 01:00:5e:**:**. Vlan-id ranges from 1 to 4094. Multicast group is assembled by vlan-id and mac-address. Interface-list is optional. If all is chosen, all interfaces in system in multicast mac-address vlan interface command. If the VLAN doesn't exist, the multicast group adding fails.

For example:

```
! Add interface Ethernet 0/2 to ethernet 0/4 ethernet 0/8 to existed multicast group
```

```
QTECH(config)#multicast mac-address 01:00:5e:01:02:03 vlan 1 interface ethernet 0/2  
ethernet 0/4 ethernet 0/8
```

Display multicast group information

Use show multicast command to display the information of the specified or all existed multicast group which includes multicast group interface information, IGMP interface list information:

```
show multicast [ mac-address mac ]
```

Mac is the mac address existed in multicast group. If mac-address is not specified, input show multicast command, information of the entire multicast group is displayed.

For example:

```
! Display the information of multicast group with the MAC address to be 01:00:5e:01:02:03
```

```
QTECH(config)#show multicast mac-address 01:00:5e:01:02:03
```

```
show multicast table information
```

```
MAC Address: 01:00:5e:01:02:03
```

```
VLAN ID: 1
```

```
Static port list: e0/2,e0/3,e0/4,e0/8.
```

```
IGMP port list
```

```
Dynamic port list
```

```
Total entries: 1.
```

Delete interface members from multicast group

Use following command in global configuration mode to delete multicast interface member:

```
no multicast mac-address mac vlan vlan-id interface { all | interface-list }
```

The meaning of mac, vlan-id and interface-list is the same as that in adding interfaces. Interface in interface-list means the interface member existed in multicast group. All means all the members in multicast group.

For example:

! Delete interface ethernet 5, 6 from existed multicast group.

```
QTECH(config)#no multicast mac-address 01:00:5e:01:02:03 vlan 1 interface ethernet 0/5  
ethernet 0/6
```

Delete multicast group

Use following command in global configuration mode to delete specified mac address and the multicast group of specified VLAN ID or all multicast groups:

```
no multicast [ mac-address mac vlan vlan - id ]
```

The meaning of mac, vlan-id and interface-list is the same as that above. They are corresponded to be existed multicast group.

For example:

! Delete multicast group with the mac address being 01:00:5e:01:02:03 and VLAN ID being 1

```
QTECH(config)#no multicast mac-address 01:00:5e:01:02:03 vlan 1
```

5.5 Cross-VLAN multicast Configuration

5.5.1 Brief Introduction of Cross-Vlan multicast

Use this command to enable/disable cross-vlan multicast and configure tag/untag attribution of multicast packet transmission and vlan-id of the tagged attribution. If this function is enabled, multicast packet transmission will not be restricted by vlan.

! Caution: Only when it is layer 3 packet and in the MAC address learning mode of SVL, it can multicast according to the regular.

5.5.2 Cross-VLAN Multicast Configuration

Cross-VLAN Multicast Configuration includes:

- Enable/disable cross-vlan multicast
- Display cross-vlan multicast

Enable/disable cross-vlan multicast

Use this command in configuration mode:

```
cross-vlan multicast
```

Example:

! enable Cross-VLAN multicast

```
QTECH(config)# cross-vlan multicast
```

```
Display cross-vlan multicast
```

Use this command to display cross vlan configuration and specified interface configuration.

```
show cross-vlan multicast [interface]
```

Example:

! Display configuration of cross vlan multicast of e0/1

```
QTECH(config)#show cross-vlan multicast interface ethernet 0/1
```

Chapter 6 DHCP CONFIGURATION

6.1 Brief introduction of DHCP

DHCP messages are usually broadcast packets. So to use DHCP to allocate IP for hosts in a three-level architected network, there need be a DHCP server in every broadcast domain. In a three-level architected network constructed with QTECH 3650, a DHCP server is put in each VLAN. This is a great waste of resources. A solution to this is to use the DHCP relay feature of QTECH QSW-3200, which relays DHCP messages to DHCP servers. Thus only one DHCP server is needed at least.

The system support following DHCP features:

DHCP Relay;

Configure DHCP servers for every VLAN;

DHCP client.

6.2 DHCP Configuration

6.2.1 DHCP Configuration list

DHCP Configuration list is as following:

- Enable DHCP Relay
- Configure DHCP server for each VLAN
- Show DHCP relay status

6.2.2 Enable DHCP relay

By default, DHCP relay is disabled. To enable DHCP relay, use the following command:

- Enable DHCP relay

```
dhcp-relay
```

- Disable DHCP relay

```
no dhcp-relay
```

To show DHCP relay status, try the command in any configuration mode:

- Show DHCP relay status

```
show dhcp-relay
```

Example:

```
! Enable DHCP relay
```

```
QTECH(config)#dhcp-relay
```

```
! Disable DHCP relay
```

```
QTECH(config)#no dhcp-relay
```

```
! Show DHCP relay status
```

```
QTECH(config)#show dhcp-relay
```

6.2.3 Configure DHCP servers for each VLAN

After creation of VLAN, DHCP servers can be configured for it. Thus DHCP messages of this VLAN will be relayed to the specified DHCP servers of this VLAN. Two DHCP servers can be configured for each VLAN. Please use the following commands in VLAN configuration mode:

- Configure the first DHCP server for a VLAN

dhcpserver ip ip-address

- Delete the first DHCP server for the current VLAN

no dhcpserver ip

- Configure the second DHCP server for a VLAN

dhcpserver backupip ip-address

- Delete the second DHCP server for the current VLAN

no dhcpserver backupip

Example:

! Configure the first DHCP server for VLAN 1

QTECH(config-if-vlan)#dhcp-server ip 192.168.1.1

! Delete the first DHCP server for VLAN 1

QTECH(config-if-vlan)#no dhcp-server ip

6.3 DHCP Snooping

It is a feature of level 2. It allow the switch to listen to DHCP messages and record IP information of hosts. This feature cannot be enabled when DHCP relay is on. When this feature is enabled, all the DHCP messages will be filtered through CPU and then be forwarded .

To make hosts obtain Ips through valid DHCP servers, DHCP snooping divide ports into trust ones and untrust ones. Only messages from servers coming from the trust ports will be forwarded. Thus invalid servers are kept off.

For security, DHCP snooping can limit the max number of hosts for a port or for a VLAN in order to avoid animus attacktion.

6.3.1 Enable DHCP Snooping

By default, DHCP Snooping is disabled. Enable it in global configuration mode

- Enable DHCP SNOOPING

dhcp-snooping

6.3.2 Configure trust ports

Specify some port as trust port. In general, vlnid servers are connected to the trust ports.

- Specify port as trust port

dhcp-snooping trust

6.3.3 Configure max host number

With max host number specified for ports or VLAN, we can avoid animus hosts'ip abtian attacktin by DOS and protect servers.

- Configre port/VLAN max host number

dhcp-snooping max-clients num

6.3.4 Configure IP source guard

Prevent IP address stolen through IP source guard.

- Configure interface IP source guard

ip-source-guard

6.3.5 Show DHCP Snooping configuration of ports

DHCP SNOOPING of ports configuration can be displayed by this command.

- Show DHCP snooping configuration of ports
`show dhcp-snooping interface [interface-num]`

6.3.6 Show DHCP Snooping configuration of VLANs

DHCP SNOOPING configuration of VLANs can be displayed by this command.

- Show DHCP snooping configuration of VLANs
`show dhcp-snooping vlan`

6.3.7 Show information of clients

Show clients' information of ip address, mac address and port number.

- Show information of clients
`show dhcp-snooping clients`

Chapter 7 ACL CONFIGURATION

7.1 Brief introduction of ACL

7.1.1 Introduction of ACL

In order to filtrate data packet, it needs configuring a series of matching rules to recognize the object which needs filtration. After recognizing special object, it can configure to permit or deny corresponded data packet passing according to the scheduled strategy. Access Control List (ACL) is used to realize this function.

ACL can classifies data packet according to a series of matching condition which can be source address, destination address and interface number. Switch detects data packet according to the specified condition of ACL to determine to transmit or drop.

Data packet matching rules defined by ACL can be introduced to other situation which needs distinguish flow, such as the flow classification in QoS.

7.1.2 Matching order configuration

An ACL rule consists of many “permit | deny” syntax, and the range of data packet specified by each syntax is different. When matching a data packet and ACL rule, there should be order. Use following command to configure ACL matching order:

```
access-list access-list-number match-order { config | auto }
```

Parameter:

access-list-number: the number of ACL rule which is in the range of 1 to 399.

Config: Specify user configured order when matching this rule.

Auto: Specify auto-sequencing when matching this rule. (according to the deep precedency) It is defaulted to specify user configured order, that is “config”. Once user configures the matching order of an ACL rule, it cannot be changed unless delete the content of the rule and re-configure its order.

The deep precedency used by auto means locating the syntax with the smallest data range at the end, which can be realized by comparing address wildcard. The smaller the wildcard value is, the smaller range the host has. For example, 192.168.3.1 0 specifies a host: 192.168.3.1, while 192.168.3.1 0.0.255.255 specifies a network interface: 192.168.3.1 ~ 192.168.255.255.

The former is before the latter in ACL. The concrete rule is: For standard ACL syntax, compare source address wildcard, if their wildcard is the same, use config order; for layer 2 ACL, the rule with “any” is in the front, others use config order; for extended ACL, compare source address wildcard, if they are the same, compare destination address wildcard, if they are the same, compare interface number range, the smaller is in the back, if the interface number range is the same, use config order; for user-defained ACL, compare the length of mask, the longer is in the back, if they are the same, use config order.

7.1.3 ACL support

ACL can be classified as following:

ACL is the command control list applied to switch. These command is used to tell switch which data packet to receive and which to refuse. It consists of a series of judging syntax. After activating an ACL, switch will examine each data packet entering switch according to the judging condition given by ACL. The one which satisfies the ACL will be permit or dropped according to ACL. QOS introduces the permit rule configuration.

In system, the ACL can be classified as following:

- Standard ACL based on number ID
- Standard ACL based on name ID
- Extended ACL based on number ID
- Extended ACL based on name ID
- Layer 2 ACL based on number ID
- Layer 2 ACL based on name ID
- User-defined ACL based on number ID
- User-defined ACL based on name ID

The restriction to every ACL and number of QOS action is as following table:

Table 13-1 ACL number restriction

Standard ACL based on number ID	1-99	99
Extended ACL based on number ID	100-199	100
Layer 2 ACL based on number ID	200-299	100
User-defined ACL based on number ID	300-399	100
Standard ACL based on name ID	--	1000
Extended ACL based on name ID	--	1000
Layer 2 ACL based on name ID	--	1000
User-defined ACL based on name ID	--	1000
Sub-rule number which can be configured by an ACL	0-127	128
The max sub-rule number which can be configured	--	3000
Time range	--	128
The absolute time range which can be configured by a time range	--	12
The periodic time range which can be configured by a time range	--	32
Sub-item of activating ACL	--	1416

7.2 ACL configuration

7.2.1 Configuration list

ACL configuration includes:

- Configure time range
- Define ACL
- Activate ACL

Above three steps should be in order. Configure time range at first, then define ACL which will introduce defined time range and activate ACL.

7.2.2 Configure time range

- Enter time-range configuration mode

Use time-range command to enter time-range configuration mode. In this mode, you can configure time range.

Configure it in global configuration mode.

Command:

time-range time-range-name

There are two kinds of configuration: configure absolute time range and periodic time range. Configuring absolute is in the form of year, month, date, hour and minute. Configuring periodic time range is in the form of day of week, hour and minute.

- Create absolute time range

Use following command to configure it.

Configure it in time-range configuration mode.

Configure absolute time range:

```
absolute [ start time date ] [ end time date ]
```

Delete absolute time range:

```
no absolute [ start time date ] [ end time date ]
```

If the start time is not configured, there is no restriction to the start time.; if endtime is not configured, the end time can be the max time of system. The end time must be larger than start time.

Absolute time range determines a large effective time and restricts the effective time range of periodic time. It can configure 12 absolute time range.

- Create periodic time range

Use following command to configure periodic time range.

Configure it in time-range configuration mode.

Command:

```
periodic days-of-the-week hh:mm:ss to [ day-of-the-week ] hh:mm:ss
```

```
no periodic days-of-the-week hh:mm:ss to [ day-of-the-week ] hh:mm:ss
```

The effective time range of periodic time is a week. It can configure at most 32 periodic time range.

7.2.3 Define ACL

Switch supports many ACL. Followings are how to define it:

- Define standard ACL

Switch can define at most 99 standard ACL with the number ID (the number is in the range of 1 to 99), at most 1000 standard ACL with the name ID and totally 3000 sub-rules. It can define 128 sub-rules for an ACL (this rule can suit both ACL with name ID and number ID). Standard ACL only classifies data packet according to the source IP information of IP head of data packet and analyse the matching data packet. The construction of IP head refers to RFC791.

(1) Define standard ACL based on number ID

Standard ACL based on number ID is using number to be ID of standard ACL. Use following command to define standard ACL based on number ID.

Configure it in global configuration mode.

Command:

```
access-list access-list-number { deny | permit } { source-addr source-wildcard | any } [ fragments ] [ time-range time-range-name ]
```

Define the matching order of ACL:

```
access-list access-list-number match-order { config | auto }
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs.

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use access-list command repeatedly to define more rules for the same ACL.

If parameter time-range is not used, this ACL will be effective at any time after activation.

Concrete parameter meaning refers to corresponded command line.

(2) Define standard ACL with name ID.

Standard ACL with name ID is using name ID to identify standard ACL.

Instruction:

Defining standard ACL with name ID should enter specified configuration mode: use access-list standard in global configuration mode which can specify matching order of ACL. Use exit command to be back from this mode.

Use following commands to define standard ACL with name ID. Configure it incorresponded mode.

Command:

Enter standard ACL with name ID configuration mode (global configuration mode)

```
access-list standard name [ match-order { config | auto } ]
```

Defining standard ACL rule (standard ACL with name ID configuration mode)

```
{ permit | deny } { source-addr source-wildcard | any } [ fragments ] [ time-range time-range-name ]
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs. (global configuration mode)

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use { permit | deny } command repeatedly to define more rules for the same ACL. Specifying matching order cannot be modified.

By default, the matching order is user configured order (config).

Concrete parameter meaning refers to corresponded command line.

- Define extended ACL

Switch can define at most 100 extended ACL with the number ID (the number is in the range of 100 to 199), at most 1000 extended ACL with the name ID and totally 3000 sub-rules. It can define 128 sub-rules for an ACL (this rule can suit both ACL with name ID and number ID). Extended ACL classifies data packet according to the source IP, destination IP, used TCP or UDP interface number, packet priority information of IP head of data packet and analyse the matching data packet. Extended ACL supports three types of packet priority handling: TOS(Type Of Service) priority, IP priority and DSCP. The construction of IP head refers to RFC791.

(1) Define extended ACL with number ID

Extended ACL based on number ID is using number to be ID of extended ACL. Use following command to define extended ACL based on number ID.

Configure it in global configuration mode.

Define extended ACL based on number ID

```
access-list access-list-number2 { permit | deny } [ protocol ] [ established ] { source-addr source-wildcard | any } [ port [ portmask ] ] { dest-addr dest-wildcard | any } [ port [ portmask ] ] [ icmp-type [ icmp-code ] ] [ fragments ] { [ precedence precedence ] [ tos tos ] | [ dscp dscp ] } [ time-range time-range-name ]
```

Define the matching order of ACL

```
access-list access-list-number match-order { config | auto }
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs.

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use access-list command repeatedly to define more rules for the same ACL.

Number ID of extended ACL is in the range of 100 to 199.

Caution: parameter port means TCP or UDP interface number used by all kinds of superior levels. For some common interface number, use corresponded mnemonic symbol to replace

the real number, such as using “bgp” to instead of the TCP interface number 179 of BGP protocol. Details refer to corresponded command line.

(2) Define extended ACL with name ID

Extended ACL with name ID is using name ID to identify extended ACL.

Instruction:

Defining standard ACL with name ID should enter specified configuration mode: use access-list extended in global configuration mode which can specify matching order of ACL. Use exit command to be back from this mode.

Configure it in corresponded mode. Enter extended ACL with name ID (global configuration mode).

```
access-list extended name [ match-order { config | auto } ]
```

Define extended ACL (extended ACL with name ID configuration mode)

```
{ permit | deny } [ protocol ] [ established ] { source-addr source-wildcard | any } [ port [ portmask ] ] { dest-addr dest-wildcard | any } [ port [ portmask ] ] [ icmp-type [ icmp-code ] ] { [ precedence precedence ] [ tos tos ] | [ dscp dscp ] } [ fragments ] [ time-range time-range-name ]
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs. (global configuration mode)

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use { permit | deny } command repeatedly to define more rules for the same ACL. Specifying matching order cannot be modified.

Caution: parameter port means TCP or UDP interface number used by all kinds of superior levels. For some common interface number, use corresponded mnemonic symbol to replace the real number, such as using “bgp” to instead of the TCP interface number 179 of BGP protocol. Details refer to corresponded command line.

▪ Define layer 2 ACL

Switch can define at most 100 layer 2 ACL with the number ID (the number is in the range of 200 to 299), at most 1000 layer 2 ACL with the name ID and totally 3000 sub-rules. It can define 128 sub-rules for an ACL (this rule can suit both ACL with name ID and number ID). Layer 2 ACL only classifies data packet according to the source MAC address, source VLAN ID, layer protocol type, layer packet received and retransmission interface and destination MAC address of layer 2 frame head of data packet and analyze the matching data packet.

(1) Define layer 2 ACL based on number ID

Layer 2 ACL based on number ID is using number to be ID of layer 2 ACL. Use following command to define layer 2 ACL based on number ID.

Configure it in global configuration mode.

Define layer 2 ACL based on number ID

```
access-list access-list-number3 { permit | deny } [ protocol ] [ cos vlan-pri ] ingress { { [ source-vlan-id ] [ source-mac-addr source-mac-wildcard ] [ interface interface-num ] } | any } egress { { [ dest-mac-addr dest-mac-wildcard ] [ interface interface-num | cpu ] } | any } [ time-range time-range-name ]
```

Define the matching order of ACL:

```
access-list access-list-number match-order { config | auto }
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs.

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use access-list command repeatedly to define more rules for the same ACL.

The number ID of layer 2 ACL is in the range of 200 to 299.

Interface parameter in above command specifies layer 2 interface, such as Ethernet interface. Concrete parameter meaning refers to corresponded command line.

(2) Define layer 2 ACL with name ID.

Layer 2 ACL with name ID is using name ID to identify layer 2 ACL.

Instruction:

Defining layer 2 ACL with name ID should enter specified configuration mode: use access-list link in global configuration mode which can specify matching order of ACL. Use exit command to be back from this mode.

Use following commands to define layer 2 ACL with name ID. Configure it in corresponded mode.

Enter layer 2 ACL with name ID configuration mode (global configuration mode)

access-list link name [match-order { config | auto }]

Defining layer 2 ACL rule (layer 2 ACL with name ID configuration mode)

{ permit | deny } [protocol] ingress { { [source-start-vlan-id source-end-vlan-id] [interface interface-num] } | any } [time-range time-range-name]

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs. (global configuration mode)

no access-list { all | { access-list-number | name access-list-name } [subitem] }

Use { permit | deny } command repeatedly to define more rules for the same ACL. Specifying matching order cannot be modified.

By default, the matching order is user configured order (config).

Concrete parameter meaning refers to corresponded command line.

- User-defined ACL

Switch can define at most 100 user-defined ACL with the number ID (the number is in the range of 300 to 399), at most 1000 user-defined ACL with the name ID and totally 3000 sub-rules. It can define 128 sub-rules for an ACL (this rule can suit both ACL with name ID and number ID). User-defined ACL can match any byte in the first 64 byte of data frame according to the user's definition and match ingress and egress to make corresponded handling to data packet. Using user-defined ACL correctly should be better understanding the construction of layer 2 data frame. In switch system, packet is in the form of 802.3 frame of SNAP + tag, so user-defined ACL should be configured as the form of 802.3 frame of SNAP + tag. The corresponded relationship between offset value and description of 802.3 frame of SNAP + tag are as following:

Description	Offset value	Description	Offset value
Destination MAC address	0	TTL field	34
Source MAC address	6	Protocol number (6 means TCP, 17 means UDP)	35
VLAN tag field	12	IP checksum	36
Length field of dataframe	16	Source IP address	38
DSAP (destination service accessing point) field	18	Destination IP address	42
SSAP (source service accessing point) field	19	TCP source interface	46
Ctrl field	20	TCP destination interface	48
org code field	21	Sequence number	50
Encapsulated data type	24	Confirm field	54
IP version number	26	Length of IP head and	58

		reserved byte	
TOS field	27	Reserved byte and flags byte	59
Length of IP packet	28	Window Size field	60
ID number	30	Others	62
Flags field	32		

In user-defined ACL, user can using rule mask and offset value to extract any byte of the first 64 bytes from data frame to compare with user-defined rule to filtrate matched data frame to make corresponded handling. User-defined rule can be some fixed attribution of data, such as: user can define rule to be "06", rule mask to be "FF", offset value to be 35. rule mask and offset value can extract TCP protocol byte content of received data frame to compare with rule to match all TCP packet.

(1) Define user-defined ACL based on number ID

User-defined ACL based on number ID is using number to be ID of user-defined ACL. Use following command to define user-defined ACL based on number ID.

Use following command to define user-defined ACL with number ID.

Configure it in global configuration mode.

Define user-defined ACL with number ID.

```
access-list access-list-number4 { permit | deny } { rule-string rule-mask offset }&<1-20> [
ingress interface interface-num ] [ egress interface interface-num | cpu ] [ time-range time-
range-name ]
```

Define the matching order of ACL:

```
access-list access-list-number match-order { config | auto }
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs.

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use access-list command repeatedly to define more rules for the same ACL.

The number ID of user-defined ACL is in the range of 300 to 399. Concrete parameter meaning refers to corresponded command line.

(2) Define standard ACL with name ID.

Standard ACL with name ID is using name ID to identify standard ACL.

Instruction:

Defining user-defined ACL with name ID should enter specified configuration mode: use access-list user in global configuration mode which can specify matching order of ACL. Use exit command to be back from this mode.

Use following commands to define user-defined ACL with name ID. Configure it in corresponded mode.

Enter user-defined ACL with name ID configuration mode (global configuration mode)

```
access-list user name [ match-order { config | auto } ]
```

Defining user-defined ACL rule (user-defined ACL with name ID configuration mode)

```
{ permit | deny } { rule-string rule-mask offset }&<1-20> [ ingress interface interface-num ] [
egress interface interface-num | cpu ] [ time-range time-range-name ]
```

Delete all the subitems or one subitem in one ACL with number ID or name ID or all ACLs. (global configuration mode)

```
no access-list { all | { access-list-number | name access-list-name } [ subitem ] }
```

Use { permit | deny } command repeatedly to define more rules for the same ACL. Create a user-defined ACL with the name of access-list-name and enter it. access-list-name is character string parameter with initial English letters (that is [a-z,A-Z]) with any kind, excluding

space and quotation mark; all , any are not allowed. Use match-order to specify the matching order, whether it is according to user configuration or deep precedence (precedent to match the rule with the small range). If it is not specified, it is defaulted to be user configuration order. Once user specifies the matching order of an ACL, it cannot be changed, unless delete all subitems of this ACL before respecify the order.

Concrete parameter meaning refers to corresponded command line.

7.2.4 Activate ACL

After activating ACL, it can be effective. Use access-group command to activate accessing control list.

Configure it in global configuration mode.

Activate ACL

```
access-group { user-group { access-list-number | access-list-name } [ subitem subitem ] | { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } }
```

Cancel activating ACL

```
no access-group { all | user-group { access-list-number | access-list-name } [ subitem subitem ] | { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } }
```

Instruction:

This command supports activating accessing control list of layer 2 and layer 3 at the same time, but the action of each accessing control list should not be conflict, if there is conflict (such as one is permit, the other is deny), the activation fails. Switch uses straight through to activate layer 2 and layer 3 ACL, that is, subitem 1 of layer 2 ACL and layer 3 ACL combine together, and the rest may be deduced by analogy; if the number of two groups of ACL is not the same, the rest subitem can activate separately.

7.3 Monitor and maintenance of ACL

Configure followings in any configuration mode except user mode.

Display time information

```
show time-range [ all | statistic | name time-range-name ]
```

Display detail information of ACL

```
show access-list config { all | access-list-number | name access-list-name }
```

Display statistic information of ACL

```
show access-list config statistic
```

Display runtime information of ACL

```
show access-list runtime { all | access-list-number | name access-list-name }
```

Display runtime statistic information of ACL

```
show access-list runtime statistic
```

Concrete configuration refers to command line configuration.

Chapter 8 QOS CONFIGURATION

8.1 Brief introduction of QOS

In traditional packet network, all packets are equal to be handled. Each switch and router handles packet by FIFO to make best effort to send packets to the destination and not to guarantee the transmission delay and delay variation.

With the fast development of computer network, the requirement of network is higher. More and more voice, image and important data which are sensitive about bandwidth, delay and jittering transferred through network, which greatly enrich network service resources and the requirement of quality of service is higher for the network congestion. Now, Ethernet becomes the leading technology in every independent LAN, and many LAN in the form of Ethernet have become a part of internet. With the development of Ethernet technology, Ethernet connecting will become one of main connecting for internet users. To realize end-to-end QoS solution has to consider the service guarantee of Ethernet QoS, which needs Ethernet device applies to Ethernet technology to provide different levels of QoS guarantee for different types of service flow, especially the service flow highly requiring delay and jitter.

1. Flow

Flow is traffic which means all packets through switch.

2. Traffic classification

Traffic classification means adopting certain regulation to recognize packet with some features. Classification rule means the filtration regulation configured by the administrator according to managing need which can be simple, such as realizing flow with the feature of different priority according to the ToS field of IP packet head and can be complicated, such as information of integrated link layer (layer 2), network layer (layer 3), transmission layer (layer 4), such as MAC address, IP protocol, source address, destination address or application program interface number to classify packet. General classification is limited in the head of encapsulation packet. Use packet content to be classification standard is singular.

3. Access control list

To classify flow is to provide service distinctively which must be connected resource distributing. To adopt which kind of flow control is related to the stage it is in and the current load of the network. For example: monitor packet according to the promised average speed rate when the packet is in the network and queue scheduling manage the packet before it is out of the node.

4. Packet filtration

Packet filtration is to filtrate service flow, such as deny, that is, deny the service flow which is matching the traffic classification and permit other flows to pass. System adopts complicated flow classification to filtrate all kinds of information of service layer 2 packets to deny useless, unreliable, and doubtful service flow to strengthen network security.

Two key points of realizing packet filtration:

Step 1: Classify ingress flows according to some regulation;

Step 2: Filtrate distinct flow by denying. Deny is default accessing control.

5. Flow monitor

In order to serve customers better with the limited network resources, QoS can monitor service flow of specified user in ingress interface, which can adapt to the distributed network resources.

6. Interface speed limitation

Interface speed limitation is the speed limit based on interface which limits the total speed rate of interface outputting packet.

7. Redirection

User can re-specify the packet transmission interface based on the need of its own QoS strategies.

8. Priority mark

Ethernet switch can provide priority mark service for specified packet, which includes: TOS, DSCP, 802.1p. These priority marks can adapt different QoS model and can be defined in these different models.

9. Choose interface outputting queue for packet

Ethernet switch can choose corresponding outputting queue for specified packets.

10. Queue scheduler

It adopts queue scheduler to solve the problem of resource contention of many packets when network congestion. There are three queue scheduler matchings: Strict-Priority Queue (PQ), Weighted Round Robin (WRR) and WRR with maximum delay.

(1)PQ

PQ (Priority Queueing) is designed for key service application. Key service possesses an important feature, that is, require the precesent service to reduce the response delay when network congestion. Priority queue divides all packets into 4 levels, that is, superior priority, middle priority, normal priority and inferior priority (3, 2, 1, 0), and their priority levels reduce in turn.

When queue schedulering, PQ precedently transmits the packets in superior priority according to the priority level. Transmit packet in inferior priority when the superior one is empty. Put the key service in the superior one, and non-key service (such as email)in inferior one to guarantee the packets in superior group can be first transmitted and non-key service can be transmitted in the spare time.

The shortage of PQ is: when there is network congestion, there are more packets in superior group for a long time, the packets in inferior priority will wait longer.

(2)WRR

WRR queue scheduler divides a port into 4 or 8 outputting queues (QSW-3200 has 4 queues, that is, 3, 2, 1, 0) and each scheduler is in turn to guarantee the service time for each queue. WRR can configure a weighted value (that is, w_3 , w_2 , w_1 , w_0 in turn) which means the percentage of obtaining the resources. For example: There is a port of 100M. Configure its WRR queue scheduler value to be 50, 30, 10, 10 (corresponding w_3 , w_2 , w_1 , w_0 in turn) to guarantee the inferior priority queue to gain at least 10Mbit/s bandwidth, to avoid the shartage of PQ queue scheduler in which packets may not gain the service.

WRR possesses another advantage. The scheduler of many queues is in turn, but the time for service is not fixed - if some queue is free, it will change to the next queue scheduler to make full use of bandwidth resources.

(3) WRR with maximum delay

Compared with WRR, WRR with maximum delay can guarantee the maximum time from packets entering superior queue to leaving it will not beyond the configured maximum delay.

11. The cos-map relationship of hardware priority queue and priority of IEEE802.1p protocol System will map between 802.1p protocol priority of packet and hardware queue priority. For each packet, system will map it to specified hardware queue priority according to 802.1p protocol priority of packet.

12. Flow mirror

Flow mirror means coping specified data packet to monitor interface to detect network and exclude failure.

13. Statistics based on flow

Statistics based on flow can statistic and analyse the packets customer interested in.

14. Copy packet to CPU

User can copy specified packet to CPU according to the need of its QoS strategies.

System realizes QoS function according to accessing control list, which includes: flow monitor, interface speed limit, packet redirection, priority mark, queue scheduler, flow mirror, flow statistics and coping packet to CPU.

8.2 QOS Configuration

8.2.1 QoS Configuration list

QOS Configuration includes:

- Packet redirection configuration
- Priority configuration
- Queue-scheduler configuration
- The cos-map relationship of hardware priority queue and priority of IEEE802.1p protocol

(1) Packet redirection configuration

Packet redirection configuration is redirecting packet to be transmitted to some egress.

Use following command to configure it.

Configure it in global configuration mode.

Redirection

```
traffic-redirect { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } { interface interface-num }
```

Cancel redirection

```
no traffic-redirect { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] }
```

Instruction:

Use this command to redirect the data packet which matched specified accessing list regulations (it is only be effective for permit rules of accessing list).

Details of this command refers to corresponded command.

8.2.2 Priority configuration

Traffic priority configuration is the strategy of remark priority for matching packet in ACL, and the marked priority can be filled in the domain which reflect priority in packet head.

Use following command to configure priority mark configuration.

Configure it in global configuration mode.

Mark packet priority

```
traffic-priority { user-group { access-list-number | access-list-name } [ subitem subitem ] | { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } } { cos { pre-value | background | best-effort | controlled-load | excellent-effort | network-management | spare | video | voice } }
```

Cancel packet priority configuration

```
no traffic-priority { user-group { access-list-number | access-list-name } [ subitem subitem ] | { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } }
```

Switch can support to mark 802.1p priority to the packet (the cos value of traffic-priority).

Details of this command refers to corresponded command.

8.2.3 Queue-scheduler configuration

When network congestion, it must use queue-scheduler to solve the problem of resource competition.

Use following command to configure queue-scheduler.

Configure it in global configuration mode.

Configure queue-scheduler

```
queue-scheduler { strict-priority | wrr queue1-weight queue2-weight queue3-weight queue4-weight queue5-weight queue6-weight queue7-weight queue8-weight | sp-wrr queue1-weight queue2-weight queue3-weight }
```

Disable queue-scheduler

```
no queue-scheduler
```

System supports three types of queue-scheduler mode: Strict-Priority Queue, Strict-Priority Queue and Weighted Round Robin (SP+WRR) and Weighted Round Robin (WRR).

By default, switch uses Strict-Priority Queue.

The detailed command refers to the corresponding command line reference.

8.2.4 The cos-map relationship of hardware priority queue and priority of IEEE802.1p protocol

There are 4 hardware priority queues which are from 0 to 3, of which 3 is the

The default mapping is the mapping defined by 802.1p:

```
802.1p: 0 1 2 3 4 5 6 7
```

```
packed-priority: 0 0 1 1 2 2 3 3
```

Use queue-scheduler cos-map command to configure 4 cos-map relationship of hardware priority queue and 8 priority of IEEE802.1p protocol

Use following command in global configuration mode.

```
queue-scheduler cos-map [ queue-number ] [ packed-priority ]
```

Use following command to display the priority cos-map.

```
show queue-scheduler cos-map
```

For example:

```
! Configure packed-priority 1 to mapped priority 6 of IEEE 802.1p
```

```
QTECH(config)#queue-scheduler cos-map 1 6
```

8.2.5 Flow mirror configuration

Flow mirror is copying the service flow which matches ACL rules to specified monitor interface to analyse and monitor packet.

Use following command to configure flow mirror.

Configure it in interface configuration mode.

Flow mirror configuration

```
mirrored-to { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [subitem subitem ] ] } [ interface interface-num ]
```

Cancel flow mirror configuration

```
no mirrored-to { [ ip-group { access-list-number | access-list-name } [subitem subitem ] ] [ link-group { access-list-number | access-list-name } [subitem subitem ] ] }
```

Details of this command refers to corresponded command.

8.2.6 Flow statistic configuration

Flow statistic configuration is used to statistic specified service flow packet.

Use following command to configure it.

Configure it in global configuration mode.

Flow statistic configuration

```
traffic-statistic { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] }
```

Clear statistic information

```
clear traffic-statistic { all | [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] }
```

Cancel flow statistic configuration

```
no traffic-statistic { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] }
```

If reconfiguring flow statistics, the corresponded information will be cleared.

Details of this command refers to corresponded command.

8.2.7 Traffic rewrite vlan configuration

Traffic rewrite vlan is rewrite vlan of the traffic to be transmitted.

Use following command to rewrite vlan.

Configure it in global configuration mode.

Traffic rewrite vlan configuration.

```
traffic-rewrite-vlan { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } vlan-id
```

Cancel traffic rewrite vlan configuration

```
no traffic-rewrite-vlan { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] }
```

Instruction:

Traffic rewrite vlan configuration is only effective to permit rule.

Details refer to corresponded commands.

8.2.8 Traffic-insert-vlan configuration

Traffic-insert-vlan is adding a tag head of configured vlan to the traffic to be transferred.

Use following command to configure it.

Configure it in global configuration mode.

Traffic insert vlan configuration

```
traffic-insert-vlan { user-group { access-list-number | access-list-name } [ subitem subitem ] | { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } } vlan-id
```

Cancel traffic insert vlan configuration.

```
no traffic-insert-vlan { user-group { access-list-number | access-list-name } [ subitem subitem ] | { [ ip-group { access-list-number | access-list-name } [ subitem subitem ] ] [ link-group { access-list-number | access-list-name } [ subitem subitem ] ] } }
```

Description:

This configuration is effective for the permit rule.

Details refer to corresponded commands.

8.3 Monitor and maintenance of QoS

Configure it in corresponded configuration mode. Show command can be used in any configured mode except user mode.

Display all QoS information:

show qos-info all

Display all QoS statistic information

show qos-info statistic

Display flow mirror configuration

show qos-info mirrored-to

Display queue scheduler and parameter

show queue-scheduler

Display the cos-map relationship of hardware priority queue and priority of IEEE802.1p protocol

show queue-scheduler cos-map

Display QOS configuration of all interface

show qos-interface [interface-num] all

Display parameter configuration of flow limit

show qos-interface [interface-num] rate-limit

Display line limit configuration

show qos-interface [interface-num] line-rate

Display QOS statistic information of all interface

show qos-interface statistic

Display priority configuration

show qos-info traffic-priority

Display redirection configuration

show qos-info traffic-redirect

Display flow statistic configuration

show qos-info traffic-statistic

Display configuration of copying to CPU.

show qos-info traffic-copy-to-cpu

Details of this command refers to corresponded command.

8.4 Port isolation

8.4.1 Brief introduction of port isolation

Forbid intercommunication of users in different interfaces by port isolation configuration.

There are two kinds of interfaces in port isolation function. One is uplink port, and the other is downlink port. Uplink port can transmit any packet, but downlink port can only transmit the packet whose destination is uplink port. Connect user's computer to downlink port, and advanced devices connect to uplink port to shield intercommunication between users and not influence user accessing exterior network through advanced switching devices.

8.4.2 Port isolation configuration

Use port-isolation command in global configuration mode to add a or a group of descendent isolation port. Use no port-isolation command to remove a or a group of descendent isolation port:

- Add port isolation downlink port
port-isolation { interface-list }
- Delete port isolation downlink port
no port-isolation { interface-list | all }

interface-list is the optioned interface list which means one or more Ethernet interfaces. When adding port isolation downlink ports, not all ports can be added to be port isolation downlink ports. Choose all only when delete port isolation downlink ports. Choose “all” to remove all downlink isolation ports. By default, all ports are port isolation uplink ports.

For example:

! Add Ethernet 0/1, Ethernet 0/3, Ethernet 0/4, Ethernet 0/5, Ethernet 0/8 to be downlink isolation port.

```
QTECH(config)#port-isolation ethernet 0/1 ethernet 0/3 to ethernet 0/5 ethernet 0/8
```

! Remove ethernet 0/3, Ethernet 0/4, Ethernet 0/5, ethernet 0/8 from downlink isolation port.

```
QTECH(config)#no port-isolation ethernet 0/3 to ethernet 0/5 ethernet 0/8
```

8.5 Strom control

8.5.1 Brief introduction of strom control

Restrict the speed rate of port receiving broadcast, known multicast/ unknown unicast packets by storm control configuration.

8.5.2 Strom control configuration

Use storm-control command in interface configuration mode to configure storm-control. Use show interface command to display storm-control information.

- Configure the speed rate of storm control
storm-control rate target-rate
- Enable storm control of some type
storm-control type { broadcast | multicast | dlf }
- Disable the speed rate of storm control and rstore to default 1/16
no storm-control ratio
- Disable storm control of some type
no storm-control type { broadcast | multicast | dlf }
- Enable storm control
storm-control { broadcast | multicast | dlf }
- no storm-control { broadcast | multicast | dlf }

For example:

! Configure global storm control ratio to be 1/16 of the port rate

```
QTECH(config)#storm-control ratio 1/16
```

! Restore to default storm control ratio

```
QTECH(config)#no storm-control ratio
```

! Enable IP multicast storm control

```
QTECH(config)#storm-control multicast
```

! Enable storm control of e0/1

```
QTECH(config-if-ethernet-0/1)# storm-control
```

! Disable storm control of e0/1

```
QTECH(config-if-ethernet-0/1)# no storm-control
```

Chapter 9 STP CONFIGURATION

9.1 Brief introduction of STP Configuration

STP (Spanning Tree Protocol) is a part of IEEE 802.1D network bridge. The realization of standard STP can eliminate network broadcast storm caused by network circle connection and the circle connection caused by misplaying and accident, and it also can provide the possibility of network backup connection.

STP protocol with IEEE 802.1D standard provides network dynamic redundancy transferring mechanism and prevents circle connection in bridge network. It determines which interface of the network bridge can transmit data packet. After executing STP matching, switch in the LAN will form a STP dynamic topology which prevents the loop existing between any two working station to prevent broadcast storm in LAN. At the same time, STP matching is responsible to detect the change of physical topology to establish new spanning tree after the changes of topology. For example: when there is a break in the switch or a channel, it can provide certain error tolerance to re-configure a new STP topology.

9.2 STP Configuration

9.2.1 STP Configuration list

The configuration can be effective only after STP enables. Configure related parameter of devices or Ethernet interface before enabling STP and these configurations will be saved after disabling STP. And the parameter will be effective after re-enabling STP. STP configuration list is as following:

- Enable/disable interface STP
- Configure STP mode
- Configure STP priority
- Configure Forward Delay
- Configure Hello Time
- Configure Max Age
- Configure path cost of specified interfaces
- Configure STP priority of specified port
- Configure interface to force to send rstp packet
- Configure link type of specified interface
- Configure the current port as an edge port
- Configure the speed limit of sending BPDU of specified interface
- STP monitor and maintenance

9.2.2 Enable/disable STP

Configure it in global configuration mode:

- Enable/disable STP of the devices
spanning-tree

- Disable STP of the devices
no spanning-tree

By default, switch STP disables.

For example:

! Enable STP

```
QTECH(config)#spanning-tree
```

9.2.3 Enable/disable interface STP

Disable STP of specified interface to make the interface not to attend STP calculating. Use following command in interface configuration mode:

- Enable STP on specified interface
spanning-tree
- Disable STP on specified interface
no spanning-tree

By default, interface STP enables.

For example:

! Disable STP on Ethernet 0/1

```
QTECH(config-if-ethernet-0/1)#no spanning-tree
```

9.2.4 Configure STP priority

Configure STP priority when STP enables, and the inferior priority of the switch can be the root bridge. Use following command in global configuration mode:

- Configure STP priority
spanning-tree priority bridge-priority
- Restore default STP priority
no spanning-tree priority

For example:

! Configure the priority of the switch in spanning tree to 30000

```
QTECH(config)#spanning-tree priority 30000
```

 **Caution:** If the priorities of all network bridge in switching network are the same, choose the one with the smallest MAC address to be the root. If STP enables, configuring network bridge may cause the re-accounting of the STP. By default, the network bridge priority is 32768 and ranges from 0 to 65535.

9.2.5 Configure switch Forward Delay

When this switch is the root bridge, port state transition period is the Forward Delay time, which is determined by the diameter of the switched network. The longer the diameter is, the longer the time is. Configure it in global configuration mode:

- Configure Forward Delay
spanning-tree forward-time seconds
- Restore default Forward Delay
no spanning-tree forward-time

For example:

! Configure forward delay to 20 seconds

```
QTECH(config)#spanning-tree forward-time 20
```

 **Caution:** If Forward Delay is configured too small, temporary redundancy will be caused; if Forward Delay is configured too large, network will not be restored linking for a long time. Forward Delay ranges from 4 to 30 seconds. The default forward delay time, 15 seconds is suggested to use. Forward Delay ≥ Hello Time + 2

9.2.6 Configure Hello Time

Suitable Hello Time can guarantee network bridge noticing link failure in time without occupying too much resources. Configure it in global configuration mode:

- Configure Hello Time
spanning-tree hello-time seconds
- Restore default Hello Time
no spanning-tree hello-time

For example:

! Configure Hello Time to 5 seconds

```
QTECH(config)#spanning-tree hello-time 5
```

 **Caution:** Too large Hello Time may cause link failure thought by network bridge for losing packets of the link to restart accounting STP; too smaller Hello Time may cause network bridge frequently to send configuration packet to strengthen the load of network and CPU. Hello Time ranges from 1 to 10 seconds. It is suggested to use the default time of 2 seconds. $\text{Hello Time} \leq \text{Forward Delay} - 2$

9.2.7 Configure Max Age

Max Age is used to judge whether the packet is outdated. User can configure it according to the real situation of the network in global configuration mode:

- Configure Max Age
spanning-tree max-age seconds
- Restore the default Max Age
no spanning-tree max-age

For example:

! Configure the Max Age to 10 seconds

```
QTECH(config)#spanning-tree max-age 10
```

 **Caution:** Max Age is used to configure the longest aging interval of STP. Lose packet when overtiming. The STP will be frequently accounts and take crowded network to be link fault, if the value is too small. If the value is too large, the link fault cannot be known timely. Max Age is determined by diameter of network, and the default time of 20 seconds is suggested. $2 * (\text{Hello Time} + 1) \leq \text{Max Age} \leq 2 * (\text{ForwardDelay} - 1)$

9.2.8 Configure path cost of specified interfaces

Configure interface STP path cost and choose the path with the smallest path cost to be the effective path. The path cost is related to the link speed rate. The larger the speed rate is, the less the cost is. STP can auto-detect the link speed rate of current interface and converse it to be the cost. Configure it in interface configuration mode:

- Configure path cost of specified interface
spanning-tree cost cost
- Restore the default path cost of specified interface
no spanning-tree cost

Configure path cost will cause the re-accounting of the STP. Interface path cost ranges from 1 to 65535. It is suggested to use the default cost to make STP calculate the path cost of the current interface. By default, the path cost is determined by the current speed.

In IEEE 802.1D, the default path cost is determined by the speed of the interface. The port with the speed 10M have the cost of 100, 100M, 19; 1000M, 4.

9.2.9 Configure STP priority of specified port

Specify specified port in STP by configuring port priority. Generally, the smaller the value is, the superior the priority is, and the port will be more possible to be included in STP. If the priorities are the same, the port number is considered. Configure it in interface configuration mode:

- Configure port priority
spanning-tree port-priority port-priority

- Restore the default port priority
no spanning-tree port-priority

The smaller the value is, the superior the priority is, and the port is easier to be the root interface. Change the port priority may cause the re-calculating of the STP. The port priority ranges from 0 to 255. the default port priority is 128.

For example:

```
! Configure the port priority of Ethernet 0/1 in STP to 120
QTECH(config-if-ethernet-0/1)#spanning-tree port-priority 120
```

9.2.10 Configure spanning-tree root-guard

Configure spanning-tree root-guard can avoid interface to be root which is used for preventing bone network topology destroying by outer BPDU packet. Configure it in interface configuration mode:

- configure spanning-tree root-guard
spanning-tree root-guard

- restore to default root-guard
no spanning-tree root-guard

Example:

```
! Enable mst root-guard of e0/1
QTECH(config-if-ethernet-0/1)#spanning-tree root-guard
```

9.2.11 Configure interface to force to send rstp packet

This configuration is used to check whether there is traditional network bridge running STP.

Configure it in interface configuration mode:

- Configure interface to force to send rstp packet
spanning-tree mcheck

For example:

```
! Configure Ethernet 0/1 to send RSTP packet
QTECH(config-if-ethernet-0/1)#spanning-tree mcheck
```

9.2.12 Configure link type of specified interface

In rstp, the requirement of interface quickly in transmission status is that the interface must be point to point link not media sharing link. It can specified interface link mode manually and can also judge it by network bridge.

Configure it in interface configuration mode:

- Configure interface to be point-to-point link

spanning-tree point-to-point forcetrue

- Configure interface not to be point-to-point link

spanning-tree point-to-point forcefalse

- Configure switch auto-detect whether the interface is point-to-point link

spanning-tree point-to-point auto

For example:

! Configure the link connected to Ethernet 0/1 as a point-to-point link

QTECH(config-if-ethernet-0/1)#spanning-tree point-to-point forcetrue

9.2.13 Configure the current port as an edge port

Edge port is the port connecting to the host which can be in transmission status in very short time after linkup, but once the port receiving STP packet, it will shift to be non-edge port.

Configure it in interface configuration mode:

- Configur the port to be edge port

spanning-tree portfast

- Configur the port to be non-edge port

no spanning-tree portfast

For example:

! Configure Ethernet 0/1 as a non-edge port.

QTECH(config-if-ethernet-0/1)#spanning-tree portfast

9.2.14 Configure the speed limit of sending BPDU of specified interface

Restrict STP occupying bandwidth by restricting the speed of sending BPDU packet. The speed is determined by the number of BPDU sent in each hello time.

Configure it in interface configuration mode:

- Configure the maximum number of configuration BPDUs sent by interface in each Hello time to be 2

spanning-tree transit-limit 2

For example:

! Configure the maximum number of configuration BPDUs that can be transmitted by the Ethernet 0/1 in each Hello time to 2

QTECH(config-if-ethernet-0/1)#spanning-tree transit-limit 2

9.2.15 STP monitor and maintenance

Display STP status

The displaying information is as following:

- STP status
- BridgeID
- Root BridgeID
- All kinds of configuration parameter of STP

Use following command in any configuration mode to display STP status globally or on a port:

show spanning-tree interface

For example:

! Display STP configuration

QTECH(config)#show spanning-tree interface ethernet 0/1

The bridge is executing the IEEE Rapid Spanning Tree protocol
The bridge has priority 32768, MAC address: 000a.5a00.0001
Configured Hello Time 2 second(s), Max Age 20 second(s),
Forward Delay 15 second(s)
Root Bridge has priority 32768, MAC address 000a.5a00.0001
Path cost to root bridge is 0
Stp top change 42 times
Port 1 (Ethernet0/1) of bridge is disabled
Spanning tree protocol is enabled
remote loop detect is enabled
The port is a Designated
Port Path cost 200000
Port priority 128
Designated bridge has priority 32768, MAC address 000a.5a00.0001
The Port is a non-edge port
Connected to a point-to-point LAN segment
Maximum transmission limit is 3 BPDUs per hello time
Times: Hello Time 2 second(s), Max Age 20 second(s)
Forward Delay 15 second(s), Packet Age 6
sent BPDU: 9
TCN: 0, RST: 9, Config BPDU: 0
received BPDU: 4040
TCN: 0, RST: 4040, Config BPDU: 0

9.2.16 Enable/disable STP remote-loop-detect

When multi-layer cascading, if switch in media layer shut down STP, the BPDU packet sent by upper switch will be cut by switch in media layer. When there is loop in the network below the media layer, upper switch cannot detect the loop. Remote loop detect is the complementary for this situation.

Enable STP remote-loop-detect

- In interface configuration mode
spanning-tree remote-loop-detect
- In global configuration mode
spanning-tree remote-loop-detect interface

Use no command to disable this function.

For example:

```
! Enable spanning-tree remote-loop-detect interface of Ethernet 0/1
QTECH(config)#spanning-tree remote-loop-detect interface ethernet 0/1
! Disable remote-loop-detect of Ethernet 0/1
QTECH(config-if-ethernet-0/1)#no spanning-tree remote-loop-detect
```

9.3 Brief Introduction of MSTP

Multiple spanning tree(IEEE802.1S, MSTP) is the upgrade for SST(Simple spanning tree, IEEE802.1D/802.1W). SST can realize link redundancy and loopback but cause the waste of effective bandwidth and overload of some link but backup of others because all vlans share a

tree. MSTP makes up these flaw and realize overload balance as SST by mapping different vlan to different STP example, that is, different STP example can generate different topology and different vlan data can choose different transmitting channel according to different STP example.

9.4 MSTP Configuration

9.4.1 MSTP configuration list

The parameter in MSTP configuration only can be effective after STP enables and the mode is MSTP. The parameter configuration is reserved after MSTP disables and enables next time. The MSTP configuration list is as following:

- Configure MSTP timer parameter
- Configure MSTP configuration mark
- Configure MSTP netbridge priority
- Configure MSTP interface edge interface status
- Configure MSTP interface link type
- Configure MSTP interface path cost
- Configure MSTP interface priority
- Display MSTP configuration information
- Enable/disable digest snooping
- Configure Ignore of VLAN

9.4.2 Configure MSTP timer parameter

MSTP timer parameter includes: forward delay, hello time, max age and max hops.

Configure it in global configuration mode:

- Configure forward delay
spanning-tree mst forward-time forward-time

- Configure hello time
spanning-tree mst hello-time hello-time

- Configure max age
spanning-tree mst max-age max-age

- Configure max hops
spanning-tree mst max-hops max-hops

Example:

! Configure max hop to be 10

```
QTECH(config)#spanning-tree mst max-hops 10
```

9.4.3 Configure MSTP configuration mark

MSTP configuring mark includes: MSTP name, MSTP revision level and the mapping relationship between MSTP and VLAN. MSTP possesses the same configuring mark and interconnected network can be treated as a virtual network logically.

Configure it in global configuration mode:

- Configure MSTP name
spanning-tree mst name name
- Configure MSTP revision level
spanning-tree mst revision revision-level

- Configure mapping relationship between MSTP and VLAN
spanning-tree mst instance instance-num vlan vlan-list

Example:

```
! Configure MSTP name to be QTECH
QTECH(config)#spanning-tree mst name QTECH
! Configure MSTP revision level to be 10
QTECH(config)#spanning-tree mst revision 10
! Configure VLAN2~7 mapping to STP instance 5
QTECH(config)#spanning-tree mst instance 5 vlan 2-7
```

9.4.4 Configure MSTP netbridge priority

In MSTP, netbridge priority is the parameter based on each STP instance. Netbridge priority and interface path cost determine the topology of each STP instance which construct the base of link load balance.

Configure it in global configuration mode:

- Configure netbridge priority in MSTP instance
spanning-tree mst instance instance-num priority priority

Example:

```
! Configure netbridge priority in MSTP instance 4 to be 4096
QTECH(config)#spanning-tree mst instance 4 priority 4096
```

9.4.5 Configure MSTP interface edge interface status

As SST, interface with edge interface attribution will turn to forwarding if it hasn't received STPpacket after 2 sending periods when link up.

Configure it in interface configuration mode:

- Configure port to be edge port

```
spanning-tree mst portfast
```

! Example:

```
Configure e0/2 to be edge port
QTECH(config-if-ethernet-0/0/2)#spanning-tree mst portfast
```

9.4.6 Configure MSTP interface link type

There are two types of link: one is sharing media (through hub), the other is point-to-point. Link type is used in suggest-agree mechanism of interface fast shifting. Only point-to-point allows fast shift. Link type can be manual configured or self-detected by STP protocol.

Configure it in interface configuration mode:

- Configure detection of link type

```
spanning-tree mst link-type point-to-point { forcetrue | forcefalse | auto }
```

! Example

```
Configure link type of e0/2 to be point-to-point
QTECH(config-if-ethernet-0/0/2)#spanning-tree mst link-type point-to-point for
cefalse
```

9.4.7 Configure MSTP interface path cost

Port path cost can be divided into internal cost and external cost. The former is the configuration parameter based on each MSTP instance to determine topology of different

instance in each MSTP region. The latter is parameter which has nothing to do with the instance to determine CST topology consisted by each region.

Configure it in interface configuration mode:

- Configure the path cost in some instance
spanning-tree mst instance instance-num cost cost
- Configure external path cost
spanning-tree mst external cost cost

Example:

```
! Configure the path cost in instance 2 to be 10
QTECH(config-if-ethernet-0/0/2)#spanning-tree mst instance 1 cost 10
! Configure external path cost of e0/2 to be 10
QTECH(config-if-ethernet-0/0/2)#spanning-tree mst external cost 10
```

9.4.8 Configure MSTP interface priority

In MSTP, interface priority is based on each STP instance.

Configure it in interface configuration mode:

- Configure interface priority in some instance
spanning-tree mst instance instance-num port-priority priority
- ```
! Configure priority of e0/2 in instance 1 to be 16
QTECH(config-if-ethernet-0/0/2)#spanning-tree mst instance 1 port-priority 16
```

### 9.4.9 Configure spanning-tree mst root-guard

Configure spanning-tree root-guard can avoid interface to be root which is used for preventing bone network topology destroying by outer BPDU packet. Configure it in interface configuration mode:

- configure spanning-tree mst root-guard  
spanning-tree mst root-guard
- restore to default root-guard  
no spanning-tree mst root-guard

Example:

```
! Enable mst root-guard of e0/1
QTECH(config-if-ethernet-0/1)#spanning-tree mst root-guard
```

### 9.4.10 Display MSTP configuration information

Basic information of MSTP includes: one is MSTP configuring mark(including MSTP name, MSTP revision level and the mapping relationship between MSTP and VLAN), the other is STP instance and interface configuration.

Configure it in any mode:

- Display MSTP configuring mark  
show spanning-tree mst config-id
- Display interface information of some instance  
show spanning-tree mst instance instance-num interface [ interface-list ]

! Example:

```
Display MSTP configuring mark
QTECH(config)#show spanning-tree mst config-id
Display interface 0/2 information of instance1
```

```
QTECH(config)#show spanning-tree mst instance 1 interface ethernet 0/0/2
```

### 9.4.11 Enable/disable digest snooping

When interface of switch connects to switch which has its own private STP, switch cannot connect to each other because of the private STP protocol. Digest snooping can avoid it. Enable digest snooping, switch will think the BPDU packet from other switch is from the same MST region and it will keep the configuring notes and add the notes to the BPDU packet to be sent. Switch realizes interconnection with others in MSTP.

Configure it in interface configuration mode:

- Enable interface digest-snooping  
spanning-tree mst config-digest-snooping
- Disable interface digest-snooping  
no spanning-tree mst config-digest-snooping

Example:

```
! Enable digest-snooping of interface 0/1
```

```
QTECH(config-if-ethernet-0/1)# spanning-tree mst config-digest-snooping
```

### 9.4.12 Configure Ignore of VLAN

In order to control MSTP, Ignore of VLAN can be enabled and the corresponded interface will not calculate.

Configure it in global configuration mode:

- Enable Ignore of VLAN  
spanning-tree mst ignored vlan vlan-list
- Disable Ignore of VLAN  
no spanning-tree mst ignored vlan vlan-list
- Display Ignore of VLAN  
show spanning-tree mst ignored-vlan

Example:

```
! Enable Ignore of VLAN 10 and 20-30
```

```
QTECH(config)# spanning-tree mst ignored vlan 10,20-30
```

# Chapter 10 802.1X CONFIGURATION COMMAND

## 10.1 Brief introduction of 802.1X configuration

IEEE 802.1X is the accessing management protocol standard based on interface accessing control passed in June, 2001. Traditional LAN does not provide accessing authentication. User can access the devices and resources in LAN when connecting to the LAN, which is a security hidden trouble. For application of motion office and CPN, device provider hopes to control and configure user's connecting. There is also the need for accounting.

IEEE 802.1X is a network accessing control technology based on interface which is the accessing devices authentication and control by physical accessing level of LAN devices. Physical accessing level here means the interface of LAN Switch devices. When authentication, switch is the in-between (agency) of client and authentication server. It obtains user's identity from client of accessing switch and verifies the information through authentication server. If the authentication passes, this user is allowed to access LAN resources or it will be refused.

System realizes IEEE 802.1X authentication. Use IEEE 802.1X authentication needs: RADIUS server which system can access to make the authentication informayion to send to; IEEE 802.1X authentication client software installed in accessing user's device (such as PC).

## 10.2 802.1X Configuration

Configure system or interface related parameter before enabling 802.1X authentication and these configurations will be saved after disabling 802.1X. And the parameter will be effective after re-enabling 802.1X.

802.1X configuration list is as following:

- Configure RADIUS project
- Configure domain
- Configure 802.1X

### 10.2.1 AAA configuration mode

Finish necessary configuration of domain and RDIUS project of 802.1X authentication.

Use aaa command in global configuration mode to enter AAA configuration mode.

For example:

! Enter AAA configuration mode

```
QTECH(config)#aaa
```

```
QTECH(config-aaa)#
```

### 10.2.2 RADIUS Server Configuration

RADIUS server saves valid user's identity. When authentication, system transfers user's identity to RADIUS server and transfer the validation to user.

User accessing to system can access LAN resources after authentication of RADIUS server.

The main configuration command of domain is as following:

- radius host
- primary-ip

- second-ip
- client-ip
- secret-key
- username-format
- realtime-account
- radius accounting
- server-disconnect drop radius 1x
- show radius host

The order of configuration can be as following:

(1) In AAA mode, use radius host command to enter RADIUS server configuration mode (if the RADIUS server does not exist, create it first), use no radius command to remove specified RADIUS server. The name of RADIUS server ranges from 1 to 32 characters with no difference in upper-case type and lower case letters and without space.

For example:

```
! Enter RADIUS server QTECH
QTECH(config-aaa)#radius host QTECH
QTECH(config-aaa-radius-QTECH)#
```

(2) In RADIUS server configuration mode, use primary-ip command to configure ip address and authentication of current primary authentication server (the default authentication port is 1812 and accounting port is 1813). Use no primary-ip command to remove ip address of primary server.

For example:

```
! Configure ip address of primary authentication server to be 192.168.0.100, and
authentication port to be 1812, accounting port to be 1813
QTECH(config-aaa-radius-QTECH)#primary-ip 192.168.0.100 1812 1813
```

(3) In RADIUS server configuration mode, use second-ip command to configure ip address and authentication and accounting port of second authentication server (the default authentication port is 1812 and the accounting port is 1813). Use no second-ip command to remove it.

For example:

```
! Configure the ip address of the second authentication server of the RADIUS server with the
name of QTECH to be 192.168.0.200, and authentication port to be 1812 and accounting port
to be 1813
QTECH(config-aaa-radius-QTECH)#second-ip 192.168.0.200 1812 1813
```

(4) Use client-ip command to configure client ip address for RADIUS server. Use no client-ip command to remove it. This ip address is used as the ip address of device to upload RADIUS server.

For example:

```
! Configure RADIUS client IP address to be 192.168.0.100
QTECH(config-aaa-radius-QTECH)#client-ip 192.168.0.100
! Remove RADIUS client IP address
QTECH(config-aaa-radius-QTECH)#no client-ip
```

(5) Use secret-key command to configure a shared key for the RADIUS server. Use no secret-key command to restore the default shared key Switch.

For example:

```
! Configure the shared key for the RADIUS server with the name of QTECH to be QTECH
QTECH(config-aaa-radius-QTECH)#secret-key QTECH
```

(6) Use `username-format` command to configure the format of the usernames to be sent to RADIUS servers. `With-domain` means user name with domain name. `Without-domain` means user name without domain name.

For example:

! Configure the username sent to the RADIUS server with the name of QTECH not to carry domain name.

```
QTECH(config-aaa-radius-QTECH)#username-format without-domain
```

(7) In RADIUS server configuration mode, use `realtime-account` command to enable realtime accounting. Use `no realtime-account` command to disable it. It is defaulted to enable and the interval of sending accounting packet is 12 minutes.

Example:

! Configure the interval of sending accounting packet to be 10 minutes

```
QTECH(config-aaa-radius-QTECH)#realtime-account interval 10
```

! Disable realtime accounting

```
QTECH(config-aaa-radius-QTECH)#no realtime-account
```

(8) Use `radius accounting` command to enable /disable accounting

For example:

! Disable accounting

```
QTECH(config-aaa)#no radius accounting
```

(9) Use `server-disconnect drop radius 1x` command to configure to cut online user or not

For example:

! Drop online user when server disconnects

```
QTECH(config-aaa)# server-disconnect drop radius 1x
```

(10) Use `show radius host` command to display RADIUS server information.

For example:

! Display RADIUS server information

```
QTECH(config-aaa-radius-QTECH)# show radius host QTECH
```

```

ServerName = QTECH
```

```
PrimServerIP = 0.0.0.0 PrimAuthPort = 1812 PrimAcctPort = 1813
```

```
SecServerIP = 0.0.0.0 SecAuthPort = 1812 SecAcctPort = 1813
```

```
SecretKey = QTECH UserNameFormat = with-domain

```

Total [1] item(s), printed [1] item(s).

### 10.2.3 Domain Configuration

Client need provide username and password when authentication. Username contains user's ISP information, domain and ISP corresponded. The main information of domain is the RADIUS server authentication and accounting the user should be.

The main configuration command of domain is as following:

- `domain`
- `radius host binding`
- `access-limit`
- `state`
- `default domain-name`
- `show domain`

The order of configuration can be as following:

(1) In AAA configuration mode, use domain command to enter AAA configuration mode. If it doesn't exist, create it. Use no domain command to remove the domain. The name of the domain ranges from 1 to 24 characters, no difference in upper-case type and lower case letters, and without space.

For example:

! Create domain with the name of qtech.ru

```
QTECH(config-aaa)#domain qtech.ru
```

```
QTECH(config-aaa-qtech.ru)#
```

(2) Use radius host command to choose a RADIUS server for current domain. Administrator specifies a existed RADIUS server to configure to be the RADIUS server of current domain.

For example:

! Configure current domain to use RADIUS configuration of "QTECH"

```
QTECH(config-aaa-qtech.ru)#radius host QTECH
```

(3) Use access-limit to enable command to configure the maximum number of access user that can be contained in current domain.

For example:

! Configure the maximum number of access user that can be contained in domain qtech.ru to 100

```
QTECH(config-aaa-qtech.ru)#access-limit enable 100
```

(4) Use state command to configure the state of the domain to be active or block.

For example:

! Activate qtech.ru

```
QTECH(config-aaa-qtech.ru)#state active
```

(5) Use default domain-name to enable command to configure a existed domain to be default domain. If the domain doesn't exist, the configuration fails. Use default domain-name disable command to disable the default domain.

When the default domain name is disabled, switch will not deal with the invalid packet, if the username goes without the domain name. After the default domain name is enabling, switch will add @ and default domain name to a username without a domain name to authenticate. To configure a default domain which must be existed, or the configuration fails.

For example:

! Configure default domain name to be qtech.ru and enable the default domain

```
QTECH(config-aaa)#default domain-name enable qtech.ru
```

(6) Use show domain command to display the configuration of the domain.

For example:

! Display the configuration of the domain

```
QTECH(config-aaa-qtech.ru)#show domain
```

```
There is no default domain
```

```

DomainName: qtech.ru
```

```
RADIUSServerName:
```

```
Access-limit: disabled
```

```
AccessedNum: 0
```

```
State: Block
```

```

Total [1] item(s), printed [1] item(s).
```

## 10.2.4 802.1X Configuration

Related command of 802.1X configuration is as following:

- dot1x method
- dot1x daemon
- dot1x eap-finish
- dot1x eap-transfer
- dot1x re-authenticate
- dot1x re-authentication
- dot1x timeout re-authperiod
- dot1x timeout re-authperiod interface
- dot1x port-control
- dot1x max-user
- dot1x user cut
- dot1x detect

(1) Use dot1x method command to enable 802.1x. Domain and RADIUS server configurations can be effective after this function enabling. Use no dot1x command to disable 802.1x. Use show dot1x command to display 802.1x authentication information.

After enabling 802.1X, user accessed to system can access VLAN resources after authentication. By default, 802.1X disables.

For example:

! Enable 802.1X based on port authentication

```
QTECH(config)#dot1x method portbased
```

! Display 802.1x authentication information

```
QTECH(config)#show dot1x
```

(2) When 802.1x enables, use this command to configure whether a port send 802.1x daemon and sending period.

By default, 802.1x daemon is not sent by default. When 802.1x enables, default interval to send daemon is 60seconds.

For example:

! Enable dot1x daemon on ethernet 0/5 with the period time of 20 seconds

```
QTECH(config-if-ethernet-0/5)#dot1x daemon time 20
```

(3) Use dot1x eap-finish and dot1x eap-transfer command to configure protocol type between system and RADIUS server:

After using dot1x eap-transfer command, 802.1 authentication packet encapsulated by EAP frame from user is sent to RADIUS server after transferring to data frame encapsulated by other high level protocol. After using dot1x eap-finish command, 802.1 authentication packet encapsulated by EAP frame from user is sent to RADIUS server without any changes.

For example:

! Configure authentication packet transitting to be eap-finish

```
QTECH(config)#dot1x eap-finish
```

(4) Use dot1x re-authenticate command to re-authenticate current interface. Use dot1x re-authentication command to enable 802.1x re-authentication. Use no dot1x re-authentication command to disable 802.1x re-authentication. Use dot1x timeout re-authperiod command to configure 802.1x re-authperiod. Use dot1x timeout re-authperiod interface command to configure 802.1x re-authperiod of a specified interface. Please refer to command line configuration to see the details.

(5) Use dot1x port-control command to configure port control mode.

After 802.1X authentication enables, all interfaces of the system default to be needing authentication, but interfaces of uplink and connecting to server need not authentication. Use dot1x port-control command to configure port control mode. Use no dot1x port-control command to restore the default port control. Use show dot1x interface command to display configuration of interface.

Configure it in interface configuration mode:

```
dot1x port-control { auto | forceauthorized | forceunauthorized }
```

For example:

! Ethernet 0/5 is RADIUS server port. Configure port-control mode of ethernet 0/5 to be forceauthorized in interface configuration mode

```
QTECH(config-if-ethernet-0/5)#dot1x port-control forceauthorized
```

! Display 802.1X configuration of ethernet 0/5

```
QTECH(config)#show dot1x interface ethernet 0/5
```

```
port ctrlmode Reauth ReauthPeriod(s) MaxHosts
e0/5 forceauthorized disabled 3600 160
```

Total [26] item(s), printed [1] item(s).

(6) Use dot1x max-user command to configure the maximum number of supplicant systems an ethernet port can accommodate. Use no dot1x max-user command to configure the maximum number to be 1.

Configure it by using following command:

```
dot1x max-user user-num
```

For example:

! Configure the max-user of ethernet 0/5 is 10 in interface configuration mode

```
QTECH(config-if-ethernet-0/5)#dot1x max-user 10
```

(7) Use dot1x user cut command to remove specified online user.

Remove specified online user by specified username and MAC address.

For example:

! Remove user with username of aaa@qtech.ru

```
QTECH(config)#dot1x user cut username aaa@qtech.ru
```

(8) Use dot1x detect command to configure dot1x detect

For example:

! Disable dot1x detect

```
QTECH(config)#no dot1x detect
```

# Chapter 11 SNTP CLIENT CONFIGURATION

## 11.1 Brief introduction of SNTP protocol

The working theory of SNTP is as following:

SNTPv4 can be worked in three modes: unicast, broadcast (multicast) and anycast.

In unicast mode, client actively sends requirement to server, and server sends response packet to client according to the local time structure after receiving requirement.

In broadcast and multicast modes, server sends broadcast and multicast packets to client timing, and client receives packet from server passively.

In anycast mode, client actively uses local broadcast or multicast address to send requirement, and all servers in the network will response to the client. Client will choose the server whose response packet is first received to be the server, and drops packets from others. After choosing the server, working mode is the same as that of the unicast.

In all modes, after receiving the response packet, client resolves this packet to obtain current standard time, and calculates network transmit delay and local time complementary, and then adjusts current time according them.

## 11.2 SNTP client configuration

SNTP client configuration command includes:

- Enable/disable SNTP client
- SNTP client working mode configuration
- SNTP client unicast server configuration
- SNTP client broadcast delay configuration
- SNTP client multicast TTL configuration
- SNTP client poll interval configuration
- SNTP client retransmit configuration
- SNTP client valid server configuration
- SNTP client MD5 authentication configuration

### 11.2.1 Enable/disable SNTP client

Use `sntp client` command in global configuration mode to enable SNTP client. Use `no sntp client` command to disable SNTP client. After SNTP enabling, switch can obtain standard time through internet by SNTP protocol to adjust local system time.

Enable SNTP client using following command:

- `sntp client`
- `no sntp client`

For example:

```
! Enable SNTP client
```

```
QTECH(config)#sntp client
```

### 11.2.2 SNTP client working mode configuration

SNTPv4 can work in three modes: unicast, broadcast (multicast), anycast. In unicast and anycast, client sends requirement and gets the response to adjust system time. In broadcast and multicast, client waits for the broadcast packet sent by server to adjust system time.

- sntp client mode { broadcast | unicast | anycast [ key number ] | multicast }
- no sntp client mode

For example:

! Configure SNTP client to operate in anycast

```
QTECH(config)#sntp client mode anycast
```

### 11.2.3 SNTP client unicast server configuration

In unicast mode, SNTP client must configure server address. The related command is as following:

- sntp server ip-address [ key number ]
- no sntp server

Only in unicast, configured server address can be effective.

For example:

! Configure unicast server ip-address to be 192.168.0.100

```
QTECH(config)#sntp server 192.168.0.100
```

### 11.2.4 SNTP client broadcast delay configuration

SNTP client broadcast delay configuration is as following:

- sntp client broadcastdelay milliseconds
- no sntp client broadcastdelay

Only in broadcast (multicast), configured transmit delay can be effective. After configuration, SNTP client can add transmit delay after obtaining time from server to adjust current system time.

For example:

! Configure broadcastdelay to be 1 second

```
QTECH(config)#sntp client broadcastdelay 1000
```

### 11.2.5 SNTP client multicast TTL configuration

Use following command to configure ttl-value of multicast packet:

- sntp client multicast ttl ttl-value
- no sntp client multicast ttl

This command should be effective by sending packet through multicast address in anycast operation mode. In order to restrict the range of sending multicast packet, TTL-value setting is suggested. The default ttl-value is 255.

For example:

! Configure TTL-value of sending multicast packet to be 5

```
QTECH(config)#sntp client multicast ttl 5
```

### 11.2.6 SNTP client poll interval configuration

Use following command to configure poll-interval of SNTP client in unicast or anycast.:

- sntp client poll-interval seconds
- no sntp client poll-interval

Only in unicast and anycast mode, configured poll interval can be effective. SNTP client sends requirement in a poll interval to the server to adjust current time.

For example:

! Configure poll-interval to be 100 seconds

```
QTECH(config)#sntp client poll-interval 100
```

## 11.2.7 SNTP client retransmit configuration

Uses following command to configure retransmit times inunicast and anycast operation mode.:

- sntp client retransmit times
- no sntp client retransmit
- sntp client retransmit-interval seconds
- no sntp client retransmit-interval

This command is effective in unicast and anycast operation mode. SNTP requirement packet is UDP packet, overtime retransmission system is adopted because the requirement packet cannot be guaranteed to send to the destination. Use above commands to configure retransmit times and the interval.

For example:

! Configure overtime retransmission to be twice and the interval to be 5

```
QTECH(config)#sntp client retransmit-interval 5
```

```
QTECH(config)#sntp client retransmit 2
```

## 11.2.8 SNTP client valid server configuration

In broadcast and multicast mode, SNTP client receives protocol packets from all servers without distinction. When there is malice attacking server (it will not provide correct time), local time cannot be the standard time. To solve this problem, a series of valid servers can be listed to filtrate source address of the packet.

Corresponded command is as following:

- sntp client valid-server
- no sntp client valid-server

For example:

! Configure servers in network interface 10.1.0.0/16 to be valid servers

```
QTECH(config)#sntp client valid-server 10.1.0.0 0.0.255.255
```

## 11.2.9 SNTP client MD5 authentication configuration

SNTP client can use valid server list to filtrate server, but when some malice attackers using valid server address to forge server packet and attack switch, switch can use MD5 authentication to filtrate packet, and authenticated packet can be accepted by client.

Configuration command is as following:

- sntp client authenticate
- no sntp client authenticate
- sntp client authentication-key number md5 value
- no sntp client authentication-key number
- sntp trusted-key number
- no sntp trusted-key number

For example:

! Configure SNTP client MD5 authentication-key, with the key ID being 12, and the key being abc and trusted-key being 12

```
QTECH(config)#sntp client authenticate
```

```
QTECH(config)#sntp client authentication-key 12 md5 abc
```

```
QTECH(config)#sntp trusted-key 12
```

# Chapter 12 SYSLOG CONFIGURATION

## 12.1 Brief introduction of Syslog

Syslog is system information center, which handles and outputs information uniformly.

Other modules send the information to be outputted to Syslog, and Syslog confirms the form of the outputting of the information according to user's configuration, and outputs the information to specified displaying devices according to the information switch and filtration rules of all outputting directions.

Because of Syslog, information producer - all modules of outputting information need not care where the information should be send at last, console, telnet terminal or logging host (Syslog server). They only need send information to Syslog. The information consumer - console, Telnet terminal, logging buffer, logging host and SNMP Agent can choose the information they need and drop what they needn't for suitable filtration rules.

Syslog information level reference:

| severe level     | Description                            | corresponded explanation                                                         |
|------------------|----------------------------------------|----------------------------------------------------------------------------------|
| 0: emergencies   | the most emergent error                | need reboot                                                                      |
| 1: alerts        | need correct immediately               | self-loop, hardware error                                                        |
| 2: critical      | key error                              | memory, resources distribution error                                             |
| 3: errors        | non-key errors need cautions           | general error; invalid parameter which is hard to restore                        |
| 4: warnings      | Warning for some error which may exist | alarm; losing packet which is not important; disconnect with the exterior server |
| 5: notifications | information needs cautions             | Trap backup outputting                                                           |
| 6: informational | general prompt information             | command line operation log; set operation for MIB node                           |
| 7: debugging     | debug information                      | debugging outputting; process, data of service protocol                          |

## 12.2 Syslog Configuration

Syslog configuration command includes:

- Enable/disable Syslog
- Syslog sequence number configuration
- Syslog time stamps configuration
- Syslog logging language configuration
- Syslog terminal outputting configuration
- Syslog logging buffered outputting configuration
- Syslog Flash storage outputting configuration
- Syslog logging host outputting configuration
- Syslog SNMP Agent outputting configuration

- Module debug configuration

### 12.2.1 Enable/disable Syslog

Use logging command in global configuration mode to enable Syslog. Use no logging command to disable Syslog and no information will be displayed.

Configuration command is as following:

- logging
- no logging

For example:

! Enable Syslog

QTECH(config)#logging

### 12.2.2 Syslog sequence number configuration

Use logging sequence-numbers command to configure global sequence number to be displayed in Syslog. Use no logging sequence-numbers command to configure global sequence number not to be displayed in Syslog.

- logging sequence-numbers
- no logging sequence-numbers

For example:

! Configure global sequence number to be displayed in Syslog outputting information.

QTECH(config)#logging sequence-numbers

### 12.2.3 Syslog time stamps configuration

Use following command to configure the type of timestamps in Syslog. There 3 types of timestamps: timestamps are not displayed, uptime is the timestamps, and datetime is the timestamps.

Configure command is as following:

- logging timestamps { notime | uptime | datetime }
- no logging timestamps

For example:

! Configure datetime to be the timestamps

QTECH(config)#logging timestamps datetime

### 12.2.4 Syslog terminal outputting configuration

Use following command in global configuration mode to enable monitor logging and configure filter regulation.

(1) Logging monitor configuration command is as following:

- logging monitor { all | monitor-no }
- no logging monitor { all | monitor-no }

monitor-no: 0 means console, and 1 to 2 means Telnet terminal.

For example:

! Enable monitor logging

QTECH(config)#logging monitor 0

(2) Terminal monitor configuration command is as following:

- terminal monitor
- no terminal monitor

This command has influence on current terminal and current log in.

For example:

! Enable current terminal information displaying

QTECH#terminal monitor

(3) Logging monitor configuration command is as following:

- logging monitor { all | monitor-no } { level | none | level-list { level [ to level ] } &<1-8> } [ module { xxx | ... } \* ]
- no logging monitor { all | monitor-no } filter

xxx: means the name of the module. ... means other modules are omitted

For example:

! Configure filter regulations of all terminals to allow all modules of levels 0 to 7 to output information

QTECH(config)#logging monitor 0 7

## 12.2.5 Syslog logging buffered outputting configuration

Use logging buffered command in global configuration mode to enable buffered logging and configure filter regulations. Use no logging buffered command to disable buffered logging and restore to default filter regulations.

(1) Logging buffered configuration command is as following:

- logging buffered
- no logging buffered

For example:

! Enable buffered logging

QTECH(config)# logging buffered

(2) Filtration rules configuration command is as following:

- logging buffered {level | none | level-list {level [ to level] } &<1-8> } [ module { xxx | ... } \* ]
- no logging buffered filter

xxx: means the name of the module. ... means other modules are omitted.

For example:

! Configure filter regulations of all terminals to allow all module of level 0 to 6 to output information

QTECH(config)#logging buffered 6

## 12.2.6 Syslog Flash storage outputting configuration

Use logging flash command in global configuration command to enable flash logging and configure filter regulations.

(1) Logging buffered configuration command is as following

- logging flash
- no logging flash

For example:

! Enable flash logging

QTECH(config)# logging flash

(2) Filtration rules configuration command is as following:

- logging flash { level | none | level-list { level [ to level ] } &<1-8> } [ module { xxx | ... } \* ]
- no logging flash filter

xxx: means the name of the module. ... means other modules are omitted.

For example:

! Configure filter regulations of all terminals to allow all modules to output information with the level of 0, 1, 2, 6

```
QTECH(config)#logging flash level-list 0 to 2 6
```

## 12.2.7 Syslog logging host outputting configuration

Use following command to configure host ip address, and enable host logging, and configure filter regulation of Syslog server.

(1) Server address configuration command is as following:

- logging ip-address
- no logging ip-address

At most 15 logging hosts are allowed to configure.

For exaple:

! Configure server address to be 1.1.1.1:

```
QTECH(config)#logging 1.1.1.1
```

(3) Logging buffered configuration command is as following:

- logging host { all | ip-address }
- no logging host { all | ip-address }

For example::

! Enable logging host 1.1.1.1

```
QTECH(config)#logging host 1.1.1.1
```

(3) Filtration rules configuration command is as following:

- logging host { all | ip-address } { level | none | level-list { level [ to level ] } &<1-8> } [ module { xxx | ... } \* ]
- no logging host { all | ip-address } filter

xxx: means the name of the module. ... means other modules are omitted.

For example:

! Configure filter regulations of logging host 1.1.1.1 to allow module vlan of level 7 to output information

```
QTECH(config)#logging host 1.1.1.1 none
```

```
QTECH(config)#logging host 1.1.1.1 level-list 7 module vlan
```

(4) Logging facility configuration command is as following:

- logging facility { xxx | ... }
- no logging facility

xxx:The name of logging facilities.... means other logging facilities are omitted.

For example:

! Configure logging facility to be localuse7

```
QTECH(config)#logging facility localuse7
```

(5) Fixed source address configuration command is as following:

- logging source ip-address
- no logging source

ip-address must be an interface address of a device.

For example:

! Configure logging host outputting to use fixed source address 1.1.1.2:

```
QTECH(config)#logging source 1.1.1.2
```

## 12.2.8 Syslog SNMP Agent outputting configuration

Use logging snmp-agent command to enable SNMP Agent logging and configure filter configuration. Use no logging snmp-agent command to disable SNMP Agent logging and restore to default filter configuration.

Configure Trap host ip address for Syslog information to send to SNMP Workstation by Trap packet. ( refer to SNMP configuration)

(1) Logging buffered configuration command is as following:

- logging snmp-agent
- no logging snmp-agent

For example:

! Enable SNMP Agent logging

```
QTECH(config)#logging snmp-agent
```

(2) Filtration rules configuration command is as following:

- logging snmp-agent { level | none | level-list { level [ to level ] } &<1-8> } [ module { xxx | ... } \* ]
- no logging snmp-agent filter

xxx: means the name of the module. ... means other modules are omitted.

For example:

! Configure SNMP Agent filtrate rules to be permitting information with the level 0 ~ 5

```
QTECH(config)#logging snmp-agent 5
```

## 12.2.9 Module debug configuration

Use debug command to enable debug of a module. Use no debug command to disable debug of a module:

- debug { all | { xxx | ... } \* }
- no debug { all | { xxx | ... } \* }

xxx: means the name of the module. ... means other modules are omitted.

For example:

! Enable debug of module vlan

```
QTECH(config)#debug vlan
```

# Chapter 13 SSH CONFIGURATION

## 13.1 Brief introduction of SSH

SSH is short for Secure Shell. Users can access to the device via standard SSH client, and sent up safe connection with device. The Data that transmitted via SSH connection are encrypt, which assure the transmitted sensitive data, management data and configuration data, such as password, between the users and devices will not be wiretapped or acquired illegally by the third party.

SSH can replace Telnet, providing users with means of safely management and device configuration.

## 13.2 SSH Configuration

The configuration task list of SSH is as follows:

- Enable/disable SSH function of the device
- SSH secret key configuration
- Others

### 13.2.1 Enable/disable SSH function of the device

Enable/disable SSH function of the device in global mode, users can not access to the devices via SSH client when SSH function is closed. To access to the device via SSH client, users need to configure correct secret key and upload the secret key in the device besides opening up the SSH function.

Configuration command is as following:

- ssh
- no ssh

Example:

! Enable SSH

QTECH(config)#ssh

### 13.2.2 SSH key configuration

Use SSH secret key in privileged mode. User cannot use SSH client to log in if there is no secret key or the key is incorrect or the key is not load. In order to log in by SSH client, configure correct key and load it with SSH enabling.

The configured secret key should be RSA. There are two kinds of keys: public and private. It can use the default key and also can download keyfile to device by tftp and ftp. Configured key can be used after loading. Configured key is stored in Flash storage which will be load when system booting. It also can load the key stored in Flash storage by command line when system booting.

If configured key is not RSA key or public and private key are not matched, user cannot log in by SSH.

Keyfile contains explanation and key explain line and the key. Explain line must contain ":" or space. Key contains the key coded by Base64, excluding "." and space. Private keyfile cannot contain public key. Private keyfile cannot use password to encrypt.

(1) Configure default key. The command is as following:

- Crypto key generate rsa

Example:

! Configure SSH key to be default key

QTECH#crypto key generate rsa

(2) Download or upload key by tftp or ftp. The command is as following:

- load keyfile { public | private } tftp server-ip filename
- load keyfile { public | private } ftp server-ip filename username passwd
- upload keyfile { public | private } tftp server-ip filename
- upload keyfile { public | private } ftp server-ip filename username passwd

Example:

! Download keyfile pub.txt from tftp server 1.1.1.1 to be SSH public key

QTECH#load keyfile public tftp 1.1.1.1 pub.txt

(3) Clear configured key. This command will clear all keyfiles stored in Flash storage. The configuration command is as following:

- crypto key zeroize rsa

Example:

! Clear configured SSH key

QTECH#crypto key zeroize rsa

(4) Load new key. After configuring new SSH key, it restored in Flash storage without loading. This command can read configured key from Flash storage and update the current key. When system booting, it will detect Flash storage, if SSH key is configured, it will load automatically. The configuration command is as following:

- crypto key refresh

Example:

! Load new SSH key:

QTECH#crypto key refresh

### 13.2.3 Others

(1) Use following command to display SSH configuration

- show ssh

This command is used to display SSH version number, enabling/disabling SSH and SSH keyfile. The SSH keyfile is “available” when the key is configured and loaded.

(2) Use following command to display configured keyfile

- show keyfile { public | private }

(3) Use following command to display logged in SSH client

- show users

This command is used to display all logged in Telnet and SSH client.

(4) Use following command to force logged in SSH client to stop

- stop username

This command can force logged in SSH client to stop. Username is the logged in user name.

(5) It allows at most 5 SSH clients to logged in. If Telnet client has logged in, the total number of SSH and Telnet clients is no more than 5. For example, if there are 2 Telnet clients in device, at most 3 SSH clients can log in.

# Chapter 14 SWITCH MANAGE AND MAINTENANCE

## 14.1 Configuration Files Management

### 14.1.1 Edit configuration files

Configuration files adopts text formatting which can be upload to PC feom devices by FTP and TFTP protocol. Use text edit tool (such as windows nootbook) to edit uploaded configuration files.

System is defaulted to execute configuration files in global configuration mode, so there are two initial commands: “enable”, and “configure terminal”. There is entering symbol after each command.

### 14.1.2 Modify and save current configuration

User can modify and save system current configuration by command line interface to make current configuration be initial configuration of system next booting. Copy running-config startup-config command is needed to save current configuration. When executing configuration files, if there is un-executed command, it will be displayed as “[Line:xxxx]invalid: commandString”. If there is command with executing failure, it will be displayed as “[Line:xxxx]failed: commandString”. If there is a command beyond 512 characters, it will be displayed as “[Line:xxxx]failed: too long command: commandString”, and only first 16 characters of this command will be displayed, and end up with ..., in which “xxxx” means the line number of the command, and commandString means command character string. Un-executive command includes command with grammar fault and un-matching pattern. Use following command in privileged mode.

```
QTECH#copy running-config startup-config
```

### 14.1.3 Erase configuration

Use clear startup-config command to clear saved configuration. After using this command to clear saved configuration and reboot switch. The switch will restore to original configuration. Use this command in privileged mode.

```
QTECH#clear startup-config
```

### 14.1.4 Execute saved configuration

User can restore saved configuration by commang line interface by using copy startup-config running-config command in privileged mode to execute saved configuration.

```
QTECH#copy startup-config running-config
```

### 14.1.5 Display saved configuration

User can display syatem saved configuration information in the form of text by command line interface. Use following command to display system saved configuration:

```
show startup-config [module-list]
```

module-list: Optional module. If the module name is unoptioned, all information of configuration files will be displayed. If choose one or same of the modules, the specified information will be displayed. This command can be used in any configuration mode.

For example:

! Display all saved configuration

```
QTECH#show running-config
```

! Display saved configuration of GARP and OAM module

```
QTECH#show running-config garp oam
```

### 14.1.6 Display current configuration

User can display system current configuration information in the form of text by command line interface. Use following command to display system current configuration:

```
show running-config [module-list]
```

module-list: Optional module. If the module name is unoptioned, all information of configuration files will be displayed. If choose one or same of the modules, the specified information will be displayed.

For example:

! Display all configurations

```
QTECH#show running-config
```

! Display configuration of GARP and OAM module

```
QTECH#show running-config garp oam
```

### 14.1.7 Configure file executing mode shift

User can change executing mode of configuration file by command line interface. System saved configuration files can be executed in stop and continue mode. When coming across errors, the executing will not stop; it will display errors and continue executing. It is defaulted to be non-stop mode. Use buildrun mode stop to configure executing mode to be stopped. Use buildrun mode continue command to configure buildrun mode to be continue. Use these commands in privileged mode.

For example:

! Configure buildrun mode to be stop.

```
QTECH#buildrun mode stop
```

! Configure buildrun mode to be continue

```
QTECH#buildrun mode continue
```

## 14.2 Online Loading Upgrade Program

System can upgrade application program and load configuration files on line by TFTP, FTP, Xmodem, and can upload configuration files, logging files, alarm information by TFTP and FTP.

### 14.2.1 Upload and download files by TFTP

Use following command to upload files by TFTP:

```
upload { alarm | configuration | logging } tftp tftpserver-ip filename
```

Use following command to download files by TFTP:

```
load { application | configuration | whole-bootrom } tftp tftpserver-ip filename
```

tftpserver-ip is the IP address of TFTP server. Filename is the file name to be loaded which cannot be system key words (such as con cannot be file name in windows operation system). Open TFTP server and set file upload path before use this command.

Suppose IP address of TFTP server is 192.168.0.100, file name is abc. Open TFTP server to configure upload and download path in privileged mode.

For example:

```
! Upload configuration to 192.168.0.100 by FTP and saved as abc
QTECH#upload configuration ftp 192.168.0.100 abc username password
Configuration information saved when uploading is successful.
! Download configuration program abc to 192.168.0.100 by TFTP
QTECH#load configuration ftp 192.168.0.100 abc
Reboot the switch after successful download and run new configuration program.
! Upload alarm to 192.168.0.100 by TFTP and saved as abc
QTECH#upload alarm tftp 192.168.0.100 abc
! Upload logging to 192.168.0.100 by TFTP and saved as abc
QTECH#upload logging tftp 192.168.0.100 abc
! Download application program app.arj to 192.168.0.100 by TFTP
QTECH#load application tftp 192.168.0.100 app.arj
Reboot the switch after successful download and run new application program.
! Download whole-bootrom abc to 192.168.0.100 by TFTP
QTECH#load whole-bootrom tftp 192.168.0.100 rom3x26.bin
```

## 14.2.2 Upload and download files by FTP

Use following command to upload files by FTP:

```
upload { alarm | configuration | logging } ftp ftpserver-ip filename username userpassword
```

Use following command to download files by FTP:

```
load { application | configuration | whole-bootrom} ftp ftpserver-ip filename username userpassword
```

ftpserver-ip is the IP address of FTP server. Filename is the file name to be loaded which cannot be system key words (such as con cannot be file name in windows operation system). Open FTP server and set username, password and file upload path before use this command. Suppose IP address of TFTP server is 192.168.0.100, file name is abc. Open TFTP server to configure username to be user, password to be 1234 and file download path in privileged mode.

For example:

```
! Upload configuration to 192.168.0.100 by FTP and saved as abc
QTECH#upload configuration ftp 192.168.0.100 abc user 1234
Configuration information saved when uploading is successful.
! Download configuration program abc to 192.168.0.100 by FTP
QTECH#load configuration ftp 192.168.0.100 abc user 1234
Reboot the switch after successful download and run new configuration program.
! Download application program abc to 192.168.0.100 by FTP
QTECH#load application ftp 192.168.0.100 abc user 1234
Reboot the switch after successful download and run new application program.
! Upload alarm to 192.168.0.100 by FTP and saved as abc
QTECH#upload alarm ftp 192.168.0.100 abc user 1234
! Upload logging to 192.168.0.100 by FTP and saved as abc
QTECH#upload logging ftp 192.168.0.100 abc user 1234
! Download whole-bootrom abc to 192.168.0.100 by FTP
QTECH#load whole-bootrom ftp 192.168.0.100 abc user 1234
```

### 14.2.3 Download files by Xmodem

Use load application xmodem command to load application program by Xmodem protocol.

load application xmodem

Input following command in privileged mode:

```
QTECH#load application xmodem
```

Choose “send” -> “send file” in super terminal, and input full path and filename of the file in filename dialog box, and choose Xmodem protocol in “protocol”, then click [send].

Reboot the switch after successful download and run new application program.

Use load configuration xmodem command to load configuration program by Xmodem protocol.

load configuration xmodem

Input following command in privileged mode:

```
QTECH#load configuration xmodem
```

Choose “send” -> “send file” in super terminal, and input full path and filename of the file in filename dialog box, and choose Xmodem protocol in “protocol”, then click [send].

Reboot the switch after successful download and run new application program.

Use load whole-bootrom xmodem command to load whole bootrom by xmodem protocol.

load whole-bootrom xmodem

Input following command in privileged mode:

```
QTECH#load whole-bootrom xmodem
```

Choose “send” -> “send file” in super terminal, and input full path and filename of the file in filename dialog box, and choose Xmodem protocol in “protocol”, then click [send].

Reboot the switch after successful download and run new BootRom program.

## 14.3 Facility management

### 14.3.1 MAC address table management

Brief introduction of MAC address table management

System maintains a MAC address table which is used to transfer packet. The item of this table contains MAC address, VLAN ID and interface number of packet entering. When a packet entering switch, switch will look up the MAC address table according to destination MAC and VLAN ID of the packet. If it is found out, send packet according to the specified interface in the item of MAC address table, or the packet will be broadcasted in this VLAN. In SVL learning mode, look up the table only according to MAC in packet and neglect VLAN ID.

System possesses MAC address learning. If the source MAC address of the received packet does not exist in MAC address table, system will add source MAC address, VLAN ID and port number of receiving this packet as a new item to MAC address table.

MAC address table can be manually configured. Administrator can configure MAC address table according to the real situation of the network. Added or modified item can be static, permanent, blackhole and dynamic.

System can provide MAC address aging. If a device does not receive any packet in a certain time, system will delete related MAC address table item. MAC address aging is effective on (dynamic) MAC address item which can be aging by learning or user configuration.

MAC address table management list

MAC address table management

- Configure system MAC address aging time
- Configure MAC address item

- Enable/disable MAC address learning
- Modify MAC address learning mode

Configure system MAC address aging time

- Configure system MAC address aging time

Use `mac-address-table age-time` command in global configuration mode to configure MAC address aging time. Use `no mac-address-table age-time` command to restore it to default time.

```
mac-address-table age-time { agetime | disable }
```

```
no mac-address-table age-time
```

Agetime means MAC address aging time which ranges from 1 to 1048575 seconds. Default MAC address aging time is 300 seconds. Disable means MAC address not aging. Use `no` command to restore the default MAC address aging time.

For example:

! Configure MAC address aging time to be 3600 seconds

```
QTECH(config)#mac-address-table age-time 3600
```

! Restore MAC address aging time to be 300 seconds

```
QTECH(config)#no mac-address-table age-time
```

- Display MAC address aging time

```
show mac-address-table age-time
```

Use `show mac-address-table age-time` command to display MAC address aging time.

```
show mac-address-table age-time
```

For example:

! Display MAC address aging time.

```
QTECH(config)#show mac-address-table aging-time
```

Configure MAC address item

- Add MAC address

MAC address table can be added manually besides dynamically learning.

```
mac-address-table { dynamic | permanent | static } mac interface interface-num vlan vlan-id
```

Parameter `mac`, `vlan-id` and `interface-num` corresponded to the three attributions of the new MAC address table item.

MAC address attribution can be configured to be dynamic, permanent and static. Dynamic MAC address can be aging; permanent MAC address will not be aging and this MAC address will exist after rebooting; static MAC address will not be aging, but it will be lost after rebooting.

For example:

! Add mac address 00:01:02:03:04:05 to be static address table.

```
QTECH(config)#mac-address-table static 00:01:02:03:04:05 interface ethernet 0/1 vlan 1
```

- Add blackhole MAC address

System can configure MAC address table item to be blackhole item. When the source address or destination address is blackhole MAC address, it will be dropped.

```
mac-address-table blackhole mac vlan vlan-id
```

For example:

! When tagged head of the packet is VLAN 1, forbid packet with its source address or destination address being 00:01:02:03:04:05 to go through system

```
QTECH(config)#mac-address-table blackhole 00:01:02:03:04:05 vlan 1
```

- Delete MAC address item

Use `no mac-address-table` command to remove mac address table.

```
no mac-address-table [blackhole | dynamic | permanent | static] mac vlan vlan-id
```

```
no mac-address-table [dynamic | permanent | static] mac interface interface-num vlan vlan-id
```

```
no mac-address-table [dynamic | permanent | static] interface interface-num
no mac-address-table [blackhole | dynamic | permanent | static] vlan vlan-id
no mac-address-table
```

Vlan means delete MAC address table item according to vlan-id; mac means deleting a specified MAC address table item; interface-num means delete MAC address table item according to interface number; command no mac-address-table means delete all MAC address.

For example:

! Delete all MAC address table item

```
QTECH(config)#no mac-address-table
```

- Display MAC address table

Use show mac-address command to display MAC address table.

```
show mac-address-table
```

```
show mac-address-table { interface-num [vlan vlan-id] | cpu }
```

```
show mac-address-table mac [vlan vlan-id]
```

```
show mac-address-table { blackhole | dynamic | permanent | static } [vlan vlan-id]
```

```
show mac-address-table { blackhole | dynamic | permanent | static } interface interface-num [vlan vlan-id]
```

```
show mac-address-table vlan vlan-id
```

The parameter meaning is the same as that of add/delete MAC address table item.

Enable/disable MAC address learning

This command is a batch command in global configuration mode to configure all interfaces to be the same; in interface configuration mode, it can configure interface MAC address learning. When MAC address learning is forbidden in an interface, packet with unknown destination address received from other interface will not be transmitted to this interface; and packet from this interface whose source address is not in this interface will not be transmitted. By default, all interface MAC address learning enable.

```
mac-address-table learning
```

```
no mac-address-table learning
```

For example:

! Enable MAC address learning on interface Ethernet 0/7.

```
QTECH(config-if-ethernet-0/7)#no mac-address-table learning
```

- Display MAC address learning

```
show mac-address learning [interface [interface-num]]
```

Use show mac-address-table learning command to display MAC address learning.

Modify MAC address learning mode

System supports SVL and IVL learning modes. The default one is SVL. User can configure MAC learning mode in global configuration mode. It will be effective after rebooting.

```
mac-address-table learning mode { svl | ivl }
```

```
show mac-address-table learning mode
```

For example:

! Modify MAC address to be IVL

```
QTECH(config)#mac-address-table learning mode ivl
```

! Display MAC address learning mode.

```
QTECH(config)#show mac-address-table learning mode
```

## 14.3.2 Reboot

Use reboot command in privileged mode to reboot switch:

```
QTECH#reboot
```

## 14.4 System Maintenance

### 14.4.1 Use show command to check system information

show command can be divided into following categories:

- Command of displaying system configuration
- Command of displaying system operation
- Command of displaying system statistics

Show command related to all protocols and interfaces refers to related chapters. Followings are system show commands.

Use following commands in any configuration mode:

- show version            Display system version
- show username        Display administrator can be logged in
- show users            Display administrators logged in
- show system          Display system information
- show memory          Display memory
- show clock            Display system clock
- show cpu              Display cpu information

For example:

! Display system version

```
QTECH# show version
```

```
software platform: Broadband NetWork Platform Software
```

```
software version: V100R001B01D001
```

```
copyright: Copyright (c) 2001-2005 By QTECH
```

```
compiled time: Mar 3 2006 19:30:00
```

```
processor: ARM7, 80MHz
```

```
SDRAM (bytes): 32M
```

```
flash memory (bytes): 4096k
```

```
product serial number: 123456789
```

```
hardware version: V1.0
```

```
bootrom version: V1.0
```

Version number and date are different with different version.

Basic Configuration and Management

### 14.4.2 Basic Configuration and Management

System basic configuration and management includes:

- Configure host name

Use hostname command in global configuration mode to configure system command line interface prompt. Use no hostname command to restore default host name.

Configure system command line interface prompt.

```
hostname hostname
```

hostname: character strings range from 1 to 32, these strings can be printable, excluding such wildcards as '/', ':', '\*', '?', '\\', '<', '>', '|', '"' etc.

Use no hostname command in global configuration mode to restore default host name to be QTECH.

For example:

```
! Configure hostname to be QSW-3200
```

```
QTECH(config)#hostname QSW-3200
```

```
QSW-3200(config)#
```

- Configure system clock

Use clock set command in privileged mode to configure system clock.

```
configure system clock
```

```
clock set HH:MM: SS YYYY/MM/DD
```

For example:

```
! Configure system clock to be 2001/01/01 0:0:0
```

```
QTECH#clock set 0:0:0 2001/01/01
```

### 14.4.3 Network connecting test command

Use ping command in privileged mode or user mode to check the network connection.

```
ping [-c count] [-s packetsize] [-t timeout] host
```

Parameter:

-c count: The number of packet sending.

-s packetsize: The length of packet sending, with the unit of second

-t timeout: the time of waiting for replying after packet is sent, with the unit of second

For example:

```
! Ping 192.168.0.100
```

```
QTECH#ping 192.168.0.100
```

```
PING 192.168.0.100: with 32 bytes of data:
```

```
reply from 192.168.0.100: bytes=32 time<10ms TTL=127
```

```
----192.168.0.100 PING Statistics----
```

```
5 packets transmitted, 5 packets received, 0% packet loss
```

```
round-trip (ms) min/avg/max = 0/0/0
```

### 14.4.4 Loopback test command

In global configuration mode, loopback command is used to test exterior of all interfaces; in interface configuration mode, loopback command is used to test whether the interface is normal, and it can be divided into interior and exterior. When exterior testing, exterior wire must be inserted (receiving and sending lines of RJ 45 connected directly). Use 4 diferent wires when the speed is less than 100M.

Using loopback command to do the loopback test, interface cannot transmit data packet correctly, and it will be automatically ended after a certain time. If shutdown command is executed, loopback test fails; when loopback test is executing, speed, duplex, mdi, vct and shutdown operations are forbindden. After exterior test, pull out the exterior wire to avoid abnormal communication.

Loopback on all interfaces:

```
loopback { internal | external }
```

Loopback on specified interface:

```
loopback { external | internal }
```

External means external loopback and internal means internal loopback

For example:

```
! Loopback on interface Ethernet 0/1
```

```
QTECH(config-if-ethernet-0/1)#loopback external
```

```
! Loopback on all interfaces
```

```
QTECH(config)#loopback internal
```

## 14.4.5 Administration IP address restriction

Managed ip address restriction can restrict host IP address or some network interface of switch by restricting web, telnet and snmp agent, but other IP address without configuration cannot manage switch. By default, three server possess an address interface of 0.0.0.0, so users of any IP address can manage switch. Different IP address and mask mean different information. The mask in reverse which is 0.0.0.0 means host address, or it means network interface. 255.255.255.255 means all hosts. When enabling a configuration, an item of 0.0.0.0 must be deleted. When receiving a packet, judge the IP address whether it is in the range of managed IP address. If it does not belong to it, drop the packet and shutdown telnet connection.

```
login-access-list { web | snmp | telnet } ip-address wildcard
```

Web means accessing IP address restriction of web server; snmp means accessing IP address restriction of snmp agent; telnet means accessing IP address restriction of telnet; ipaddress means IP address; wildcard means mask wildcard which is in the form of mask in reverse. 0 means mask this bit, and 1 means does not mask this bit. When mask in reserve is 0.0.0.0, it means host address, and 255.255.255.255 means all hosts. Use the no command to delete corresponding item.

For example:

```
! Configure ip address allowed by telnet management system to be 192.168.0.0/255.255.0.0
```

```
QTECH(config)#login-access-list telnet 192.168.0.0 0.0.255.255
```

```
QTECH(config)#no login-access-list telnet 0.0.0.0 255.255.255.255
```

Use show login-access-list command to display all ip address allowed by web, snmp, telnet management system.

```
show login-access-list
```

## 14.4.6 The number of Telnet user restriction

Configure the max number of Telnet users. This function can restrict the number of Telnet user (0-5) to enter privileged mode at the same time. The user logged in without entering privileged mode will not be restricted but restricts by the max number. Administrator and super user will not be restricted and can be logged in through series interface. Display the configuration by show users command.

Configure it in global configuration mode:

```
login-access-list telnet-limit limit-no
```

```
no login-access-list telnet-limit
```

Example:

```
! Configure only 2 Telnet users can enter privileged mode
```

```
QTECH(config)#login-access-list telnet-limit 2
```

## 14.4.7 Routing tracer command

Tracer is used for routing detecting and network examination. Configure it in privileged mode:  
tracer [ -u | -c ] [ -p udpport | -f first\_ttl | -h maximum\_hops | -w time\_out ] target\_name

Parameter:

-u means sending udp packet, -c means sending echo packet of icmp. It is defaulted to be -c;  
udpport: destination interface address for sending udp packet which is in the range of 1 to 65535 and defaulted to be 62929;

first\_ttl: initial ttl of sending packet which is in the range of 1 to 255 and defaulted to be 1;

maximum\_hops: the max ttl of sending packet which is in the range of 1 to 255 and defaulted to be 30;

time\_out: the overtime of waiting for the response which is in the range of 10 to 60 with the unit of second and default to be 10 seconds;

target\_name: destination host or router address

Example:

```
! Tracer 192.168.1.2
```

```
QTECH#tracer 192.168.1.2
```

```
Tracing route to 192.168.1.2 [192.168.1.2]
```

```
over a maximum of 30 hops:
```

```
 1 20 ms <10 ms <10 ms 192.168.0.1
 1 20 ms <10 ms 30 ms 192.168.1.2
```

```
tracer complete.
```

## 14.4.8 cpu-car command

cpu-car is used to configure cpu rate for receiving packet. no cpu-car is used to restore to default cpu rate for receiving packet. Configure it in global configuration mode:

```
cpu-car target-rate
```

```
no cpu-car
```

Parameter:

target-rate: cpu rate for receiving packet , which is in the range of 1 to 1000pps and the default rate is 50pps..

Example:

```
! Configure cpu rate for receiving packet to be 100pps
```

```
QTECH(config)#cpu-car 100
```

## 14.5 Monitor system by SNMP

### 14.5.1 Brief introduction of SNMP

SNMP (Simple Network Management Protocol) is an important network management protocol in TCP/IP network. It realizes network management by exchanging information packets. SNMP protocol provides possibility of concentrated management to large sized network. Its aim is guaranteeing packet transmission between any two points to be convenient for network administrator to search information, modify and search fault, finish fault diagnosing, capacity planning and creation reporting at any network node. It consists of NMS and Agent. NMS( Network Management Station ), is the working station of client program running, and Agent is server software running in network devices. NMS can send GetRequest, GetNextRequest and SetRequest packet to Agent. After receiving requirement packet of NMS, Agent will Read or

Write management variable according to packet type and create Response packet, and return it to NMS. On the other hand, the Trap packet of abnormality of cold boot or hot boot of devices will send to NMS.

System supports SNMP version of v1, v2c and v3. v1 provides simple authentication mechanism which does not support the communication between administrator to administrator and v1 Trap does not possess authentication mechanism. V2c strengthens management model (security), manages information structure, protocol operation, the communications between managers, and it can create and delete table, and strengthen communication capacity of managers, and reduce the storage operation of agency. V3 realizes user distinguishing mechanism and packet encryption mechanism, and greatly improves security of SNMP protocol.

## 14.5.2 Configuration

SNMP configuration command list:

SNMP configuration command list includes:

- Configure community
- Configure sysContact
- Configure Trap destination host adress
- Configure sysLocation
- Configure sysName
- Configure notify
- Configure engine id
- Configure view
- Configure group
- Configure user

Configure community

SNMP adopts community authentication. The SNMP packets which are not matching the authenticated community name will be dropped. SNMP community name is a character string. Different community can possess the accessing right of read-only or read-write. Community with the riht of read-only can only query system information, but the one with the right of read-write can configure system. System can configure at most 8 community names. It is defaulted to configure without community name. Configure it in global configuratiob mode.

- Configure community name and accessing right. This command can also used to modify community attribution with character string community-name being the same.

```
snmp-server community community-name { ro | rw } { deny | permit } [view view-name]
```

community-name is a printable character string of 1 to 20 characters; ro, rw means read only or can be read and write; permit, deny means community can or cannot be activated;

View-name is view configured for community, The default configuration view is iso.

- Delete community name and accessing right

```
no snmp-server community community-name
```

community-name is existed community name.

For example:

```
! Add community QTECH, and configure privilege to be rw, and permit
```

```
QTECH(config)#snmp-server community QTECH rw permit
```

```
! Remove community QTECH
```

```
QTECH(config)#no snmp-server community QTECH
```

- Display community name in any mode

```
show snmp community
```

For example:

! Display SNMP community information

```
QTECH(config)#show snmp community
```

Configure sysContact

sysContact is a managing variable in system group in MIB II, the content of which is the contact way of the administrator. Configure it in global configuration mode:

```
snmp-server contact syscontact
```

```
no snmp-server contact
```

syscontact: Contact way to administrator ranges from 1 to 255 printable characters. Use the no command to restore default way of contacting to administrator.

For example:

! Configure administrator contact way to be support@qtech.ru.

```
QTECH(config)#snmp-server contact support@qtech.ru
```



Caution: Use quotation mark to quote space in character string.

Use show snmp contact command in any configuration mode to display how to contact to administrator:

```
show snmp contact
```

For example:

! Display how to contact with administrator

```
QTECH(config)#show snmp contact
```

```
manager contact information : support@qtech.ru
```

Configure Trap destination host address

Use this configuration to configure or delete IP address of destination host. Configure it in global configuration mode.

- Configure notify destination host address

```
snmp-server host host-addr [version {1 | 2c | 3 [auth | noauth | priv]}] community-string [udp-port port] [notify-type [notifytype-list]]
```

- Delete notify destination host address

```
no snmp-server host ip-address community-string { 1 | 2c | 3 }
```

ip-address and snmp-server means IP address in SNMP server notify sending list. community-string means the security name IP corresponded in snmp-server notify table item. Security name is the community name for snmpv1 and snmp v2c, and username for snmpv3. 1, 2c, 3 mean SNMP versions. Port means the port number sent to. Notifytype-list means optional notify list. If it is unoptioned, default to choose all type. Only optionaed type will be sent to destination host.

For example:

! Configure SNMP server, the IP address is configured to be 192.168.0.100, and SNMP version to be 2c, and community name to be user

```
QTECH(config)#snmp-server host 192.168.0.100 version 2c user
```

! Delete the item with the notify destination host being 192.168.0.100 and community name being user

```
QTECH(config)#no snmp-server host 192.168.0.100 user
```

- Display snmp-server notify item in any configuration mode:

- show snmp host

! Display Trap information of snmp

```
QTECH(config)#show snmp host
```

Configure sysLocation

+7(495) 797-3311www.qtech.ru

Москва, Новозаводская ул., 18, стр. 1



most 32 engines can be configured. Use no snmp-server engineID command to restore default local engine-id or remove remote engine-id. Configure it in global configuration mode:

```
snmp-server engineID { local engineid-string | remote ip-address [udp-port port-number] engineid-string }
```

```
no snmp-server engineID { local | remote ip-address [udp-port port-number] }
```

Display current engine configuration in any configuration mode:

```
show snmp engineID [local | remote]
```

engineid-string is an engine id that can only be recognized in a network. This system only supports printable characters of engine id which excludes space.

Ip-address is remote engine ip address. Local ip address is not allowed to input.

Port-number is remote engine port number. Default port number is 162

For example:

! Configure local engine id to be 12345

```
QTECH(config)# snmp-server engineid local 12345
```

! Configure remote engine that can be recognized locally. Configure remote engine ip to be 1.1.1.1, and port number to be 888, and id to be 1234

```
QTECH(config)# snmp-server engineid remote 1.1.1.1 udp-port 888 1234
```

! Display local engine configuration

```
QTECH(config)# show snmp engineid local
```

Configure view

Use snmp-server view command to configure view and its subtree. Iso, internet and sysview are the default views. At most 64 views can be configured. View Internet must not delete and modify. Configure it in global configuration mode:

```
snmp-server view view-name oid-tree { included | excluded }
```

```
no snmp-server view view-name [oid-tree]
```

View-name means the name of the view to be added. It ranges from 1 to 32, excluding space.

Oid-tree means the subtree of the view which corresponds to such a mib node as "1.3.6.1";

The substring of OID must be the integer between 0 and 2147483647.

The sum of the number of characters in view name string and the number of oid nodes should not be more than 62.

When configuring view subtree to be exclude, the node in this subtree cannot be accessed which does not mean the node excluded this subtree can be accessed. When configuring notify destination host, if the security name is the community, sending notify is not effected on view; if the user with the security name being SNMPv3, sending notify is controlled by notify view of this user. What this notify view controlled is the accessing of the node that variable belongs to and it is not influence accessing attribution of trap OID that notify belonged to. If notify does not contain binded variable, sending notify is not effected on view.

For example:

! Add view "view1", and configure it to have a subtree "1.3.6.1"

```
QTECH(config)# snmp-server view view1 1.3.6.1 include
```

! Add a subtree "1.3.6.2" for existed view "view1"

```
QTECH(config)# snmp-server view view1 1.3.6.2 include
```

! Remove existed view "view1"

```
QTECH(config)# no snmp-server view view1
```

! Display configured view

```
QTECH(config)# show snmp view
```

Configure group

Use this configuration to configure a accessing conreol group. Folowing groups are default to exist: (1) security model is v3, the security level is differentiated group initial ; (2) security model is v3, the security level is differentiated encrypt group initial. At most 64 groups can be configured. Configure it in global configuration mode:

```
snmp-server group groupname { 1 | 2c | 3 [auth | noauth | priv] [context context-name]} [read readview]
```

```
[write writeview] [notify notifyview]
```

```
no snmp-server group groupname {1 | 2c | 3 [auth | noauth | priv] [context context-name]}
```

Display configured group in any configuration mode:

```
show snmp group
```

groupname means group name, which ranges from 1 to 32 characters, excluding space.

Readview is a view name, which means the right to read in the view. If the keyword is vacant, it is default not to include readable view.

Writeview is a view name, which means the right to read and write in the view. If the keyword is vacant, it is default not to include readable and writable view.

Notifyview is a view name, which means the right to send notification in the view. If the keyword is vacant, it is default not to include notify sending view.

Context-name is facility context. If the keyword is vacant, it is default to be local facility.

For example:

! Add group "group1" to local facility, using security model 1, and configure read, write, and notify view to be internet

```
QTECH(config)# snmp-server group group1 1 read internet write internet notify Internet
```

! Remove group "group1" from local facility

```
QTECH(config)# no snmp-server group group1 1
```

! Display current group configuration.

```
QTECH(config)# show snmp group
```

Configure user

Use this configuration to configure user for local engine and recognizable remote engine. Following users are default to exist: (1)initialmd5 (required md5 authentication) , (2) initialsha (required sha authentication) , (3) initialnone (non- authentication) . The above three users are reserved for system not for user. The engine the user belonged to must be recognizable. When deleting recognizable engine, contained users are all deleted. At most 64 users can be configured. Configure it in global configuration mode:

```
snmp-server user username groupname [remote host [udp-port port]] [auth { md5 | sha } { authpassword { encrypt-authpassword authpassword | authpassword } | authkey { encrypt-authkey authkey | authkey } }] [priv des { privpassword { encrypt-privpassword privpassword | privpassword } | privkey { encrypt-privkey privkey | privkey } }]
```

```
no snmp-server user username [remote host [udp-port port]]
```

Display configured user in any configuration mode:

```
show snmp user
```

Username is the username to be configured. It ranges from 1 to 32 characters, excluding space.

Groupname is the groupname that user going to be added. It ranges from 1 to 32 characters, excluding space.

Host is remote engine ip address. If it is vacant, it is default to be local engine.

Port is the port number of remote engine. If it is vacant, it is default to be 162.

Authpassword is authentication password. Unencrypted password ranges from 1 to 32 characters. To avoid disclosing, this password should be encrypted. To configured encrypted

password needs client-side which supports encryption to encrypt password, and use encrypted cryptograph to do the configuration. Cryptograph is different by different encryption. Input cryptograph in the form of hexadecimal system, such as “a20102b32123c45508f91232a4d47a5c”

Privpassword is encryption password. Unencrypted password ranges from 1 to 32 characters. To avoid disclosing, this password should be encrypted. To configured encrypted password needs client-side which supports encryption to encrypt password, and use encrypted cryptograph to do the configuration. Cryptograph is different by different encryption. Input cryptograph in the form of hexadecimal system, such as “a20102b32123c45508f91232a4d47a5c”

Authkey is authentication key. Unauthenticated key is in the range of 16 byte (using md5 key folding) or 20 byte (using SHA-1 key folding). Authenticated key is in the range of 16 byte (using md5 key folding) or 24 byte (using SHA-1 key folding).

Privkey is encrypted key. Unencrypted key ranges from 16 byte, and encrypted key ranges from 16 byte.

Keyword encrypt-authpassword, encrypt-authkey, encrypt-privpassword, encrypt-privkey are only used in command line created by compile to prevent leaking plain text password and key. When deconfiguring SNMP, user cannot use above keywords.

For example:

! Add user “user1” for local engine to group “grp1”, and configure this user not to use authentication and encryption.

```
QTECH(config)# snmp-server user user1 grp1
```

! Add user “user2” for local engine to group “grp2”, and configure this user to use md5 authentication and non-encryption with the auth-password to be 1234

```
QTECH(config)# snmp-server user user2 grp2 auth md5 auth-password 1234
```

! Add user “user3” for local engine to group “grp3”, and configure this user to use md5 authentication and des encryption with the auth-password to be 1234 and privpassword to be 4321

```
QTECH(config)# snmp-server user user3 grp3 auth md5 auth-password 1234 priv des priv-password 4321
```

## 14.6 System IP configuration

IP address means a unique address of 32 bits which is distributed to host in Internet. IP address consists of network number and host number. The structure of IP address can make us easy to address in Internet. The ways to obtain IP address are by DHCP (dynamic host configuration protocol), whose client can dynamically require to configuration information to DHCP server, including: distributed IP address, netmask, default gateway; BOOTP (Ip address configuration for statistic host) and manual operation by ipaddress command. Only one can be choosed to obtain IP address.

### 14.6.1 Configure and manage VLAN

Manage VLAN means only users in specified VLAN can communicate with switch. At most 26 managed vlan can be onfigured. By default, VLAN with its id being 1 is included.

```
ipaddress vlan vlan-id
```

```
no ipaddress vlan vlan-id
```

Use these commands to add or delete managed VLAN. vlan-id ranges from 1to 4094. It must be existed VLAN.

## 14.6.2 Configuration ip address by manual operation

Use `ipaddress` command in global configuration mode to configuration ip address, netmask, and gateway or default gateway by manual operation:

```
ipaddress ip-address mask [gateway]
```

`ip-address` means system ip address. `Mask` means netmask. `gateway`: If only IP address and netmask are configured, and gateway is not, the gateway will be default to be 0.

For example:

! Configure IP address to be 192.168.0.100, netmask to be 255.255.0.0.

```
QTECH(config)#ipaddress 192.168.0.100 255.255.0.0
```

Disable DHCP or BOOTP to configure IP address before manual operation of it will prompt error.

## 14.6.3 BOOTP

Use following command in global configuration mode to obtain IP address by DHCP:

- Use `bootp` command to enable bootp way to obtaining ip address.

```
bootp
```

- Use `no bootp` command to disable bootp.

```
no bootp
```

If DHCP is configured, disable DHCP before configure BOOTP

## 14.6.4 DHCP

Use following command in global configuration mode to obtain IP address by DHCP:

- Use `dhcp` command to configure to enable DHCP to obtain IP address.

```
dhcp
```

- Use `no dhcp` command to disable DHCP to obtain IP address.

```
no dhcp
```

## 14.6.5 Examples for IP address configuration

The original way is DHCP, change it into BOOTP way to obtain IP address, then, configure IP address to be 192.168.0.100, mask to be 255.255.0.0 and the gateway to be 192.168.0.254.

Configure it in global configuration mode:

- Enable DHCP to obtain IP address

```
QTECH(config)#dhcp
```

- Disable DHCP to obtain IP address

```
QTECH(config)#no dhcp
```

- Enable BOOTP to obtain IP address

```
QTECH(config)#bootp
```

- Disable BOOTP to obtain IP address

```
QTECH(config)#no bootp
```

- Manual configuration

```
QTECH(config)#ipaddress 192.168.0.100 255.255.0.0 192.168.0.254
```

## 14.6.6 Display ip address

Use `show ip` command in any configuration mode to display ip address and its obtaining mode, netmask, and gateway:

show ip

For example:

! Display ip address information

```
QTECH(config)#show ip
```

switch configuration

ip obtained: MANUAL

ip address: 192.168.0.100

netmask: 255.255.0.0

gateway: 192.168.0.254

MAC address: 00:40:47:00:00:00

## 14.7 Enable/disable dlf forward packet

Use dlf-forward command to enable dlf forward.

```
dlf-forward { multicast | unicast }
```

```
no dlf-forward { multicast | unicast }
```

Use dlf-forward command in global configuration mode or interface configuration mode to enable dlf forward. Use no dlf-forward command to disable dlf forward:

```
dlf-forward { multicast | unicast }
```

```
no dlf-forward { multicast | unicast }
```

For example:

! Disable dlf forward for unicast

```
QTECH(config)#no dlf-forward unicast
```

! Disable dlf forward for multicast

```
QTECH(config)#no dlf-forward multicast
```

## 14.8 CPU Alarm Configuration

### 14.8.1 Brief introduction of CPU alarm

Brief iSystem can monitor CPU usage. If CPU usage rate is beyond cpu busy threshold, cpu busy alarm is sent because the cpu is busy. In this status, if cpu is below cpu unbusy threshold, cpu unbusy alarm is sent. This function can report current CPU usage to user.

### 14.8.2 CPU alarm configuration list

CPU alarm configuration command includes:

- Enable/disable CPU alarm
- Configure CPU busy or unbusy threshold
- Display CPU alarm information

### 14.8.3 Enable/disable CPU alarm

Configure it in global configuration mode:

- Enable CPU alarm

```
alarm cpu
```

- Disable CPU alarm

```
no alarm cpu
```

by default, CPU alarm enables.

For example:

! Enable CPU alarm

QTECH(config)#alarm cpu

## 14.8.4 Configure CPU busy or unbusy threshold

Use alarm cpu threshold command in global configuration mode to configure CPU busy or unbusy threshold.:

- Configure CPU busy or unbusy threshold

alarm cpu threshold [ busy busy ] [ unbusy unbusy ]

busy > unbusy. Default CPU busy threshold is 90%, and CPU unbusy threshold is 60%.

For example:

! Configure CPU busy threshold to be 30%, and CPU unbusy threshold to be 10%

QTECH(config)#alarm cpu threshold busy 30 unbusy 10

## 14.8.5 Display CPU alarm information

- Use show alarm cpu command in any mode to display cpu alarm information:

show alarm cpu

For example:

! Display CPU alarm information

QTECH(config)#show alarm cpu

CPU status alarm: enable

CPU busy threshold(%): 90

CPU unbusy threshold(%): 60

CPU status: unb

## 14.9 Anti-DOS Attack

### 14.9.1 IP segment anti-attack

The IP segment packet number which can be received by system do not occupy resources of all receiving packets, which can normally handle other non-segment packets when receiving IP segment attack and the range of IP segment receiving number can be configured. 0 means system will not handle IP segment packet so that system can avoid the influence on segment attack.

- Configure it in global configuration mode

anti-dos ip fragment maxnum

- Display related information

show anti-dos

# Chapter 15 LLDP CONFIGURATION

## 15.1 Brief introduction of LLDP protocol

LLDP (Link Layer Discovery Protocol) is the new protocol defined by IEEE 802.1AB. It realizes proclaiming information about itself to other neighbor devices through network and receives the bulletin information from neighbor devices and stores it to standard MIB of LLDP. It is convenient for user to check the device model and linked interfaces of downlink neighbor devices and maintains central office and manage network. Network administrator can know the link of network layer 2 by accessing MIB.

## 15.2 LLDP configuration

### 15.2.1 LLDP configuration list

The configuration can be effective only after LLDP enables. Configure related parameter of devices or Ethernet interface before enabling LLDP and these configurations will be saved after disabling LLDP. And the parameter will be effective after re-enabling LLDP. LLDP configuration list is as following:

- Enable/disable global LLDP
- Configure LLDP hello-time
- Configure LLDP hold-time
- Interface LLDP packet receiving/sending mode configuration
- Display LLDP information

### 15.2.2 Enable/disable global LLDP

Use following command in global configuration mode:

- Enable global LLDP

lldp

- Disable global LLDP

no lldp

By default, global LLDP disables.

For example:

! Enable global LLDP

QTECH(config)#lldp

### 15.2.3 Configure LLDP hello-time

Use following command in global configuration mode:

- Configure LLDP hello-time

lldp hello-time <5-32768>

- Restore default LLDP hello-time

no lldp hello-time

The default LLDP hello-time is 30 seconds

For example:

! Configure LLDP hello-time to be 10

QTECH(config)#lldp hello-time 10

## 15.2.4 Configure LLDP hold-time

Use following command in global configuration mode:

- Configure LLDP hold-time  
lldp hold-time <2-10>
- Restore default LLDP hold-time  
no lldp hold-time

The default LLDP hold-time is 4

For example:

! Configure LLDP hold-time to be 2

```
QTECH(config)#lldp hold-time 2
```

## 15.2.5 Interface LLDP packet receiving/sending mode configuration

Use following command in interface configuration mode:

- Configure interface LLDP packet receiving/sending mode  
lldp { rx | tx | rxtx }

Parameter:

rx: only receive LLDP packet

tx: only send LLDP packet

rxtx: receiving/sending LLDP packet

- Disable interface LLDP packet receiving/sending  
no lldp

By default, interface LLDP packet receiving/sending mode is rxtx

For example:

! Configure e 0/1 only to send LLDP packet

```
QTECH(config-if-ethernet-0/1)#lldp tx
```

## 15.2.6 Display LLDP information

Display followings in any configuration mode:

- Enable/disable global LLDP
- Related parameter of global LLDP
- Interface packet receiving/sending mode
- Interface packet receiving/sending statistics
- Neighbour devices information found

```
show lldp interface [<interface-list>]
```

For example:

! Display LLDP information of interface Ethernet 0/0/1

```
QTECH(config)#show lldp interface ethernet 0/0/1
```

```
System LLDP: enable
```

```
LLDP hello-time: 30(s) LLDP hold-time: 4 LLDP TTL: 120(s)
```

```
Interface Ethernet 0/0/1
```

```
Port LLDP: rxtx Pkt Tx: 2019 Pkt Rx: 1943
```

Neighbor (1):

TTL: 119(s)

Chassis ID: 00:1f:ce:10:26:66

Port ID: port(7)

System Name: QTECH

System Description: QTECH

Port Description: e0/7

Port Duplex: auto

Port Speed: FULL-100

Port Link Aggregation: support ,in aggregation ,aggregated port ID is 7

# Chapter 16 ERRP COMMAND CONFIGURATION

## 16.1 Brief introduction of ERRP

ERRP (Ethernet Redundant Ring Protocol) is the private Ethernet ring protocol of QTECH which is used to protect real-time service (video/voice delay sensitive service). The basic working theory is many switches serial connect to be ring to provide link redundancy, and a master device detects/maintains the ring. The master device provides redundant port which can release redundant port when the ring break down to guarantee the service smooth. The calculation is less, so the convergency is faster than STP.

## 16.2 ERRP Configuration

### 16.2.1 ERRP Configuration list

Only when ERRP and ring enable, the configuration can be effective. the configuration will be reserved when ERRP and ring disable and it will be effective when ERRP and ring enable next time.

- ERRP configuration
- Configure ERRP timer
- Enter ERRP configuration mode
- Configure ERRP working mode
- Configure control-vlan in ERRP domain
- Create ERRP ring
- Enable/disable ERRP ring
- Show ERRP domain and ring
- ERRP Query Solicitation

### 16.2.2 ERRP configuration

Configure it in global configuration mode:

ERRP

no ERRP

It is defaulted to disable ERRP.

For example:

! Enable ERRP

QTECH(config)#ERRP

### 16.2.3 Configure ERRP timer

Configure it in global configuration mode:

- Configure packet overtime

ERRP fail-timer timer-value

Parameter:

timer-value: integrity in the range of 1-10

- Configure packet sending interval

ERRP hello-timer timer-value

Parameter:

timer-value: integrity in the range of 1-10

For example:

! Configure ERRP packet sending interval to be 1 second

```
QTECH(config)#ERRP hello-timer 1
```

## 16.2.4 Enter ERRP configuration mode

Configure it in global configuration mode:

ERRP domain domain-id

Parameter :

domain-id: ERRP domain id

For example:

! Configure ERRP domain 0

```
QTECH(config)#ERRP domain 0
```

## 16.2.5 Configure ERRP domain working mode

In order to work with other vendor, we add ERRP domain working mode. Configure it in ERRP domain configuration mode:

```
workmode { standard | huawei }
```

Parameter :

standard: protocol packet uses standard destination MAC and format in RFC3619. By default, it is standard mode.

huawei: protocol packet uses huawei private destination MAC and format. It can make switch work with Huawei's RRPP.

For example:

! Configure ERRP domain 0 working mode to be standard

```
QTECH(config-errp-domain-0)#workmode standard
```

## 16.2.6 Configure control-vlan of ERRP domain

Configure it in ERRP domain mode:

```
control-vlan vlan-id
```

```
no control-vlan
```

Parameter:

vlan-id: control vlan id of ERRP domain which is the integrity in the range of 1-4093.

Note:

Control VLAN is relative to data VLAN. Data VLAN is for transmitting data packet and control VLAN is only for transmitting ERRP protocol packet. Every ERRP domain owns two control VLANs, that are master control VLAN and sub-control VLAN. Protocol packet of master ring is transmitted in master control-VLAN and protocol packet of sub-ring is transmitted in sub-control VLAN. When configuring, specify master control. When configuring, specify master control VLAN, and sub-control VLAN is the one whose VLAN ID is 1 bigger than that of the master control VLAN.

Port only accessing to Ethernet ring (ERRP port) of each switch belong to control VLAN. ERRP port of master ring belong to both master control VLAN and sub-control VLAN. ERRP port of sub-ring belongs to sub-control VLAN only. There can be ERRP port and non- ERRP port in data VLAN. Master ring is taken as a logical node of sub-ring. The protocol packet of

sub-ring is transparent transmitted through master ring and handled as data packet in master ring. The protocol packet of master ring can only be transmitted in master ring.

Add all ERRP port to corresponded master and sub-control VLAN before or after handed down ERRP configuration and configure master and sub-control VLAN being tag vlan.

Example:

! Configure control VLAN of ERRP domain 0 being 25

```
QTECH(config-ERRP-0)#control-vlan 25
```

! Delete control VLAN of ERRP domain 0. if there is activated ring, the control VLAN will not allow to be deleted.

```
QTECH(config-ERRP-0)#no control-vlan
```

## 16.2.7 Create ERRP ring

Configure it in ERRP configuration mode:

- Create master role

```
ring ring-id role master primary-port pri-port secondary-port sec-port level level
```

- Create transit role

```
ring ring-id role transit primary-port pri-port secondary-port sec-port level level
```

- Create edge role

```
ring ring-id role edge common-port common-port edge-port edge-port
```

- Create Create assistant-edge role

```
ring ring-id role assistant-edge common-port common-port edge-port edge-port
```

Parameter:

ring-id: ring id which is in the range of 0-15

pri-port: port id such as ethernet 0/1

sec-port: port id such as ethernet 0/1

common-port: port id such as ethernet 0/1

sec-port: port id such as ethernet 0/1

level: ring level. 0 means primary ring and 1 means secondary.

For example:

! Configure primary ring 0 with role mode being master, primary port being 1 and secondary port being 2

```
QTECH(config-ERRP)#ring 0 role master primary-port ethernet 0/1 secondary-port ethernet 0/2 level 0
```

## 16.2.8 Enable/disable ERRP ring

Configure it in ERRP configuration mode:

```
ring ring-id { enable | disable }
```

Parameter:

ring-id: ring id

enable: activate a ring

diabile: inactivate a ring

For example:

! Enable ring 0

```
QTECH(config-ERRP)#ring 0 enable
```

## 16.2.9 Display ERRP domain and ring information

Display in any configuration:

```
show ERRP [domain domain-id [ring ring-id]]
```

Parameter:

domain-id: domain id

ring-id: ring id

Example:

! Display ring 1 of ERRP domain 0

```
QTECH(config)#show ERRP domain 0 ring 1
```

## 16.2.10 ERRP Query Solicitation

Use this command to cooperate IGMP SNOOPING. When ERRP ring topology changed, it will inform IGMP to resend IGMP query for updating IGMP SNOOPING multicast data. Main nod is defaulted to enable Query Solicitation but other nods are defaulted to disableQuery Solicitation.

Configure it in ERRP mode:

```
ring ring-id query-solicit
```

```
no ring ring-id query-solicit
```

Parameter:

ring-id: ring id

Example:

! Enable Query Solicitation of ERRP0 ring0

```
QTECH(config-errp-domain-0)#ring 0 query-solicit
```

# Chapter 17 PPPOE PLUS CONFIGURATION

## 17.1 Brief Introduction of PPPoE Plus

PPPoE+ is short for PPPoE Intermediate agent which is proposed early in DSL FORM to define according to user line mark propection of RFC 3046. The realization theory is similar to DHCP Option82 which makes some complement on PPPoE protocol packet. After accessing device get PPPoE protocol packet, insert user physical information for uplink direction and strip it for downlink direction before transmission.

## 17.2 PPPoE Plus Configuration

### 17.2.1 PPPoE Plus Configuration list

PPPoE Plus Configuration list is as following:

- Enable/disable global PPPoE Plus

### 17.2.2 Enable/disable PPPoE Plus

Configure it in global configuration mode:

- Enable global PPPoE Plus

```
pppoeplus
```

- Disable global PPPoE Plus

```
no pppoeplus
```

By default, PPPoE Plus is disabled.

Example:

```
! Enable global PPPoE Plus
```

```
QTECH(config)#pppoeplus
```

To display PPPoE Plus, configure it in any configuration mode:

- Display PPPoE Plus

```
show pppoeplus
```

### 17.2.3 Configure PPPoE Plus type

Configure it in global configuration mode:

- Configure PPPoE Plus type

```
pppoeplus type { standard | huawei }
```

The default type is standard and the adding tag form is TR-069 standard. The adding tag form will include hostname information when the type is huawei.

# Chapter 18 CFM CONFIGURATION

## 18.1 Brief introduction of CFM

CFM (Connectivity Fault Management) is a point-to-point OAM protocol defined by IEEE 802.1ag standard which is used to manage failure of operating network, including continuity detection, loopback, tracert, trap alarm and remote failure alarm.

## 18.2 CFM Configuration

### 18.2.1 CFM Configuration list

Configure domain before configuring other parameter when enabling CFM. CFM command list is as following:

- Create/delete MD
- Configure MD parameter
- Create/delete MA
- Configure MA parameter
- Create/delete MEP
- Create/delete RMEP
- Create/delete MIP
- loopback
- linktrace
- Show MD
- Show MA
- Show MP(MEP/MIP/RMEP)
- Show/clear CCM statistics
- Show/clear CCM database
- Show cfm error

### 18.2.2 Create/delete MD

There are at most 8 MD in a switch. Configure it in global configuration mode:

- Create cfm md and enter cfm md configuration mode

```
cfm md md-index
```

- Delete cfm md

```
no cfm md md-index
```

Parameter:

md-index: MD index in 4 byte integer without any symbols

Example:

! Create MD with index being 10

```
QTECH(config)#cfm md 10
```

### 18.2.3 Configure MD parameter

Use following commands in cfm md configuration mode:

- Configure cfm md dns name and level

```
cfm md format none level md-level
```

cfm md format { dns-name | mac-uint | string } name md-name level md-level

Parameter:

none: MD dns name is not specified

dns-name: dns name is a RFC1035 DNS name, Example: support@qtech.ru

mac-uint: dns name consists of MAC and 2 byte decimal integer without symbols, Example: 00:1f:ce:00:00:01-1

string: dns name is a string, Example: abcd

md-name: MD name content, which has to be the same as the name format

md-level: MD level ranges from 0~7

Example:

! Specify dns name of md 10 is abcd-3 with level 3

QTECH(config-cfm-md-10)#cfm md format string name abcd-3 level 3

## 18.2.4 Create/delete MA

In a MD, there can be multiple MA, and CFM will detect connection for each MA. There can be 48 MA in a MD and also in a switch. Configure it in cfm md configuration mode:

- Create cfm ma and enter cfm ma configuration mode

cfm ma ma-index

- Delete cfm ma

no cfm ma ma-index

Parameter:

ma-index: MA index in 4 byte integer without any symbols

Example:

! Configure ma index 10 in MD 10

QTECH(config-cfm-md-10)#cfm ma 10

## 18.2.5 Configure MA parameter

Use following commands in cfm ma configuration mode:

- Configure cfm ma format name and vlan

cfm ma format { primary-vid | string | uint16 | vpn-id } name ma-name primary-vlan vlan-id

Parameter:

primary-vid: format name is a VLAN ID, which can be specified as MA primary VLAN ranges from 1~4094

string: format name is a string, Example: abcd

uint16: format name is a 2 byte decimal integer without any symbol, Example: 65535

vpn-id: format name is a 3 byte OUI and 4 byte decimal integer without any symbol, Example: 000a5a-12

ma-name: MA name content, which has to be the same as name format

vlan-id: MA primary VLAN ranges from 1~4094

- Configure cfm ma ccm sending interval

cfm cc interval { 1 | 10 | 60 | 600 }

- Restore to default ccm sending interval 1s

no cfm cc interval

Example:

! Specify format name of ma 10 in md 10 is abcd with primary VLAN 3

QTECH(config-cfm-md-10-ma-10)#cfm ma format string name abcd primary-vlan 3

! Specify ccm sending interval of ma 10 in md 10 is 10s

QTECH(config-cfm-md-10-ma-10)#cfm cc interval 10

## 18.2.6 Create/delete MEP

There can be 255 MP(including MEP/MIP/RMEP) in each MA and each switch. Configure it in cfm ma configuration:

- Create mep, specify mep direction, primary vlan and port  
cfm mep mep-id direction { up | down } [ primary-vlan vlan-id ] interface ethernet port-id

Parameter:

mep-id: mep id, it cannot be duplicated in a MA, which ranges from 1~8191

up: mep direction up. This mep should connect to other MP with other port

down: mep direction down. This mep connects to other MP by this port

vlan-id: mep primary VLAN. If VLAN is not specified, it will use MA's primary VLAN, ranges from 1~4094

port-id: mep port

- Delete mep

no cfm mep mep-id

- Enable/disable mep status

cfm mep mep-id state { enable | disable }

- Enable/disable mep ccm

cfm mep mep-id cc { enable | disable }

- Configure mep priority for sending ccm/lrm, ranges from 0~7

cfm mep mep-id priority priority-id

- Restore priority of mep sending ccm/lrm to be 0

no cfm mep mep-id priority

Example:

! Create mep in md 10 ma 10 with id being 1, direction being down, port being 1

QTECH(config-cfm-md-10-ma-10)#cfm mep 1 direction down interface ethernet 0/1

## 18.2.7 Create/delete RMEP

Use following command in cfm ma configuration mode:

- Create rmeep and specify corresponded mep

cfm rmeep rmeep-id mep mep-id

Parameter:

rmeep-id: rmeep id, all other mep id except local mep in MA, which ranges from 1~8191

mep-id: mep id. Local mep id in MA, which ranges from 1~8191

- Delete rmeep

no cfm rmeep rmeep-id

Example:

! Create rmeep with id being 2 in md 10 ma 10 and corresponded to mep 1

QTECH(config-cfm-md-10-ma-10)#cfm rmeep 2 mep 1

## 18.2.8 Create/delete MIP

Use following command in cfm ma configuration mode:

- Create mip and specify the port

cfm mip mip-id interface ethernet port-id

Parameter:

mip-id: local mip id in MA, ranges from 1~8191

port-id: mip port

- Delete mip

no cfm mip mip-id

Example:

! Create mip in md 10 ma 10 with id being 1 and port being 1

QTECH(config-cfm-md-10-ma-10)#cfm mip 1 interface ethernet 0/1

## 18.2.9 Loopback

Use following command in cfm ma mode:

- cfm loopback

cfm loopback mep mep-id { dst-mac mac-address | dst-mep rmep-id } [ priority pri-id | count pkt-num | length data-len | data pkt-data ]

Parameter:

mep-id: mep for cfm loopback, ranges from 1~8191

mac-address: destination MAC. It is remote mep or mip MAC.

rmep-id: destination mep id, ranges from 1~8191, it is remote mep

pri-id: priority for sending loopback packets, ranges from 0~7. The default priority is 0.

pkt-num: number for sending loopback packets, ranges from 1~1024. The default number is 5

data-len: length of sending loopback packets, ranges from 1~1500 byte. The default length is 0

pkt-data: data content for sending loopback packets, ranges from 1~400 bytes. The default data is empty.

Example:

! Loopback mep1 to mep2 in md 10 ma 10

QTECH(config-cfm-md-10-ma-10)#cfm loopback mep 1 dst-mep 2

! Loopback mep1 to 00:1f:ce:00:04:1e in md 10 ma 10

QTECH(config-cfm-md-10-ma-10)#cfm loopback mep 1 dst-mac 00:1f:ce:00:04:1e

## 18.2.10 Linktrace

Please configure it in cfm ma configuration mode:

- cfm linktrace

cfm linktrace mep mep-id { dst-mac mac-address | dst-mep rmep-id } [ timeout pkt-time | ttl pkt-ttl | flag { use-mpdb | unuse-mpdb } ]

Parameter:

mep-id: mep id for tracing mep, ranges from 1~8191

mac-address: destination MAC. It is remote mep or mip MAC

rmep-id: destination mep id. It is remote mep, ranges from 1~8191

pkt-time: timeout for sending packets response, ranges from 3~60s. 5s is by default.

pkt-ttl: initial ttl of sending packets, ranges from 1~255. 64 is by default.

use-mpdb: CCM forwarding packet id. Searching MAC addr first, then searching CCM database

unuse-mpdb: packet forwarding id. Only searching MAC addr table

Example:

! Trace mep1 to mep2 in md 10 ma 10

QTECH(config-cfm-md-10-ma-10)#cfm linktrace mep 1 dst-mep 2

! Trace mep1 to 00:1f:ce:00:04:1e in md 10 ma 10

QTECH(config-cfm-md-10-ma-10)#cfm linktrace mep 1 dst-mac 00:1f:ce:00:04:1e

### 18.2.11 Show MD

In any configuration mode:

- Show MD

show cfm md [ md-index ]

Example:

! Show md all

QTECH(config)#show cfm md

### 18.2.12 Show MA

In any configuration mode:

- Show MA

show cfm ma

Example:

! show cfm ma all

QTECH(config)#show cfm ma

### 18.2.13 Show MP(MEP/MIP/RMEP)

In any configuration mode:

- Show local MP(mep/mip)

show cfm mp local

- Show remote MP(rmep)

show cfm mp remote

Example:

! Show local MP

QTECH(config)# show cfm mp local

! Show remote MP

QTECH(config)# show cfm mp remote

### 18.2.14 Show/clear CCM statistics

Show in any configuration mode and clear data in global configuration mode:

- Show CCM statistics

show cfm cc

- Clear CCM statistics

clear cfm cc

Example:

! Show CCM statistics

QTECH(config)#show cfm cc

! Clear CCM statistics

QTECH(config)#clear cfm cc

### **18.2.15 Show/clear CCM database**

Show in any configuration mode and clear data in global configuration mode:

- Show CCM database

show cfm cc database

- Clear CCM database

clear cfm cc database

Example:

! Show CCM database

QTECH(config)# show cfm cc database

### **18.2.16 Show cfm error**

In any configuration mode:

- Show cfm error

show cfm errors

Example:

! Show cfm error

QTECH(config)# show cfm errors

# Chapter 19 FLEX LINKS CONFIGURATION

## 19.1 Brief introduction of Flex links

Flex links is layer 2 links backup protocol which provides for STP option scheme. Choose Flex links to realize link backup when the STP is not wanted in customer network. If STP enables, flex links is disabled. Flex links consists of a pair of interfaces (can be ports or convergent interface) . One interface is transmitting data, the other is standby. The backup interface starts transmitting data when there is default in master link. The failure interface will be standby when it turns well and it will be transmitting data in 60 seconds when preempt mechanism is set. Flex links interface should disable STP and Flex links interface can configure bandwidth and delay being preempt mechanism and the superior one will be the master interface. There must be trap alarm when master or backup link default.

## 19.2 Flex links Configuration

### 19.2.1 Flex links Configuration list

- Enable or disable Flex links of interface(or convergent interface)
- Configure Flex links preemption mode
- Configure Flex links preemption mode delay
- Display Flex links information

### 19.2.2 Enable or disable Flex links of interface(or convergent interface)

Configure interface Flex links in interface configuration mode

```
switchport backup { interface interface-num | channel-group channel-group-number}
```

Configure channel-group Flex links in global configuration mode:

```
channel-group channel-group-number backup { interface interface-num | channel-group channel-group-number}
```

For example:

```
! Configure flex links backup interface of e0/0/1 to be e0/0/2
```

```
QTECH(config-if-ethernet-0/0/1)#switchport backup interface Ethernet 0/0/2
```

```
! Configure flex links backup interface of channel-group 1 to be e0/0/2
```

```
QTECH(config)#channel group 1 backup interface Ethernet 0/0/2
```

### 19.2.3 Configure Flex links preemption mode

Configure interface Flex links in interface configuration mode

```
switchport backup { interface interface-num | channel-group channel-group-number}
preemption mode {Forced|Bandwidth|Off}
```

Configure channel-group Flex links in global configuration mode:

```
channel-group channel-group-number backup { interface interface-num | channel-group channel-group-number}
preemption mode {Forced|Bandwidth|Off}
```

For example:

```
! Configure flex links preemption mode of e0/0/1 to be Forced
```

```
QTECH(config-if-ethernet-0/0/1)#switchport backup interface Ethernet 0/0/2 preemption mode
Forced
```

! Configure flex links preemption mode of channel-group 1 to be Forced

```
QTECH(config)#channel group 1 backup interface Ethernet 0/0/2 preemption mode Forced
```

## 19.2.4 Configure Flex links preemption mode delay

Configure interface Flex links in interface configuration mode

```
switchport backup { interface interface-num | channel-group channel-group-number}
preemption delay delay-time
```

Configure channel-group Flex links in global configuration mode:

```
channel-group channel-group-number backup { interface interface-num | channel-group
channel-group-number} preemption delay delay-time
```

For example:

! Configure flex links preemption delay of e0/0/1 to be 60 seconds

```
QTECH(config-if-ethernet-0/0/1)#switchport backup interface Ethernet 0/0/2 preemption delay
60
```

! Configure flex links preemption delay of channel-group 1 to be 60 seconds

```
QTECH(config)#channel group 1 backup interface Ethernet 0/0/2 preemption delay 60
```

## 19.2.5 Display Flex links information

In any configuration mode:

It will display as following:

Flex links master interface status

Flex links backup interface status

Flex links preemption mode

Flex links preemption delay

```
show interface switchport backup
```

For example:

! Display all Flex links information

```
QTECH(config)# show interface switchport backup
```

## 19.2.6 Configure MacMoveUpdate of Flex links

When active port down, the backup one will be active. Enable MacMoveUpdate to accelerate the recover. After enabling MacMoveUpdate, backup port will be active and it will send the mac address learnt from other ports. When receiving MacMoveUpdate packet, it will be transmitted and the local mac address will be updated after receiving it if MacMoveUpdate enables.

Enable MacMoveUpdate

Configure it in global mode:

```
mac-address-table move update transmit
```

Example:

```
QTECH(config)#mac-address-table move update transmit
```

Enable MacMoveUpdate

Configure it in global mode:

```
mac-address-table move update receive
```

Example:

```
QTECH(config)#mac-address-table move update receive
```

```
Show MacMoveUpdate
```

Configure it in global mode:

```
show mac-address-table move update
```

Example:

```
QTECH(config)# show mac-address-table move update
```

# Chapter 20 EFM CONFIGURATION

## 20.1 EFM Overview

EFM (ethernet of first mile) , defined by IEEE 802.3ah, is for management and maintenance on P2P Ethernet link between two devices. There are five main functions: EFM node discovery, remote failure indication, link monitoring, remote loopback and polling of MIB variables.

## 20.2 EFM Configuration

### 20.2.1 EFM configuration list

EFM configuration list:

- Enable/disable EFM
- Configure EFM working mode
- Configure EFM pdu-timeout
- Configure link timeout
- Configure response timeout
- Configure link monitoring
- Enable/disable remote failure indication
- Enable/disable link monitoring
- Enable/disable remote MIB variable obtaining
- Enable/disable remote loopback
- Enable/stop remote loopback
- Configure handling remote loopback querying packet
- Show EFM status
- Show EFM info
- Show EFM discovery
- Show/clear EFM statistics
- Show remote MIB

### 20.2.2 Enable/disable EFM

Configure it in interface configuration mode:

- Enable EFM

EFM

- Disable EFM

no EFM

By default, EFM is disabled.

For example:

```
! Enable EFM
```

```
QTECH(config-if-ethernet-0/1)#EFM
```

### 20.2.3 Configure EFM working mode

Configure it in interface configuration mode:

- Configure EFM working mode

EFM mode { passive | active }

Parameter:

passive: passive mode

active: active mode

By default, EFM working mode is active.

For example:

! Configure EFM working mode to be passive

```
QTECH(config-if-ethernet-0/1)#EFM mode passive
```

## 20.2.4 Configure EFM pdu-timeout

Configure pdu timeout to EFM pdu request packet. Discard the received EFMPDU response packets after timeout.:

- Configure EFM pdu-timeout

```
efm pdu-timeout time
```

Parameter:

time: EFM pdu timeout which is in the range of 1 to 60s. The default is 1s. It cannot be more than 1/3 of efm link-timeout.

- Restore to default efm pdu-timeout

```
no efm pdu-timeout
```

For example:

! Configure efm pdu-timeout to be 5s

```
QTECH(config-if-ethernet-0/1)#efm pdu-timeout 5
```

## 20.2.5 Configure link timeout

Configure EFM link timeout. When it is timeout, EFM link will be re-started. Configure it in interface mode:

- Configure link timeout

```
efm link-timeout time
```

Parameter:

time: EFM link timeout which is in the range of 1 to 60s. The default is 1s. It cannot be less than 3 times of EFM pdu timeout.

- Restore default EFM link timeout

```
no efm link-timeout
```

For example:

! Configure efm link-timeout to be 15s

```
QTECH(config-if-ethernet-0/1)#efm link-timeout 15
```

## 20.2.6 Configure response timeout

Configure response timeout to EFMPDU request packet. Discard the received EFMPDU response packets after timeout. Configure it in interface configuration mode:

- Configure response timeout to EFMPDU request packet.

```
EFM remote-response-timeout time
```

Parameter :

time: response timeout which is in the range of 1 to 10s. The default is 2s.

- Restore to default response timeout.

```
no EFM remote-response-timeout
```

For example:

! Configure response timeout to be 5s

```
QTECH(config-if-ethernet-0/1)#EFM remote-response-timeout 5
```

## 20.2.7 Configure link monitoring

Configure it in interface configuration mode:

- Configure window and threshold in errored-symbol-period

```
EFM link-monitor errored-symbol-period window high win-value1 low win-value2
```

```
EFM link-monitor errored-symbol-period threshold high th-value1 low th-value2
```

Parameter :

window: received symbol number (8 byte) , which is in the range of 1 ~ 0xffffffffffff. The default is 10000.win-value1 and win-value2 represent 4 high bytes and low bytes.

threshold: received error symbol number (8 bytes) , which is in the range of 1 ~ 0xffffffffffff. The default is 1, th-value1 and th-value2 represent 4 high bytes and low bytes.

- Configure window and threshold in errored-frame

```
EFM link-monitor errored-frame window win-value
```

```
EFM link-monitor errored-frame threshold th-value
```

Parameter:

win-value: received time, which is in the range of 10(100ms)~600(100ms). The default is 10(100ms)

th-value: received failure frame number, which is in the range of 1~0xffffffff. The default is 1

- Configure window and threshold in errored-frame-period

```
EFM link-monitor errored-frame-period window win-value
```

```
EFM link-monitor errored-frame-period threshold th-value
```

Parameter:

win-value: received frame number which is in the range of 1~0xffffffff. The default is 10000

th-value: received failure frame number, which is in the range of 1~0xffffffff. The default is 1

- Configure window and threshold in errored-frame-seconds

```
EFM link-monitor errored-frame-seconds window win-value
```

```
EFM link-monitor errored-frame-seconds threshold th-value
```

Parameter:

win-value: received time, which is in the range of 100(100ms)~9000(100ms). The default is 600(100ms)

th-value: received failure second, which is in the range of 1~900. The default is 1

- Restore to default link monitoring configuration

```
no EFM link-monitor { errored-symbol-period | errored-frame | errored-frame-period | errored-frame-seconds } window
```

```
no EFM link-monitor { errored-symbol-period | errored-frame | errored-frame-period | errored-frame-seconds } threshold
```

For example:

! Configure window in errored-symbol-period to be 50000

```
QTECH(config-if-ethernet-0/1)#EFM link-monitor errored-symbol-period window high 0 low 50000
```

## 20.2.8 Enable/disable remote failure indication

Enable/disable EFM remote failure indication. This function is used for detecting EFM urgent connecting. Configure it in interface configuration mode:

- Enable EFM failure indicator

EFM remote-failure { link-fault | dying-gasp | critical-event }

Parameter:

link-fault: detect local receiving failure

dying-gasp: detecting way undefined

critical-event: detecting way undefined

- Disable EFM remote failure indication

no EFM remote-failure { link-fault | dying-gasp | critical-event }

By default, this function is enabled.

Example:

! Disable link-fault

QTECH(config-if-ethernet-0/1)#no EFM remote-failure link-fault

## 20.2.9 Enable/disable link monitoring

Enable/disable EFM link monitoring. This function is for real-time link monitoring. Configure it in interface configuration mode:

- Enable link monitoring

EFM link-monitor { errored-symbol-period | errored-frame | errored-frame-period | errored-frame-seconds }

- Disable link monitoring

no EFM link-monitor { errored-symbol-period | errored-frame | errored-frame-period | errored-frame-seconds }

By default, link monitoring is enabled.

For example:

! Enable errored-frame

QTECH(config-if-ethernet-0/1)#EFM link-monitor errored-frame

## 20.2.10 Enable/disable remote MIB variable obtaining

Enable/disable EFM remote MIB variable obtaining. This function is for checking remote MIB variable. Configure it in interface configuration mode:

- Enable remote MIB variable obtaining

EFM variable-retrieval

- Disable remote MIB variable obtaining

no EFM variable-retrieval

For example:

! Disable remote MIB variable obtaining

QTECH(config-if-ethernet-0/1)#no EFM variable-retrieval

## 20.2.11 Enable/disable remote loopback

Enable/disable EFM remote loopback. This function is for detecting link status. Configure it in interface configuration mode:

- Enable remote loopback

EFM remote-loopback

- Disable remote loopback

no EFM remote-loopback

For example:

! Disable remote loopback

QTECH(config-if-ethernet-0/1)#no EFM remote-loopback

## 20.2.12 Enable/stop remote loopback

Enable/stop remote loopback. Configure it in interface configuration mode:

- Enable/stop remote loopback

EFM remote-loopback { start | stop }

Parameter:

start: enable remote loopback

stop: stop remote loopback

For example:

! Enable remote loopback

QTECH(config-if-ethernet-0/1)#EFM remote-loopback start

## 20.2.13 Configure handling remote loopback querying packet

Configure handling remote loopback querying EFMPDU. Configure it in interface configuration mode:

- Configure handling remote loopback querying packet

EFM remote-loopback { ignore | process }

Parameter:

ignore: ignore handling

process: process

For example:

! Process remote loopback query EFMPDU

QTECH(config-if-ethernet-0/1)#EFM remote-loopback process

## 20.2.14 Show EFM status

Use commands in any configuration mode:

Followings will be displayed:

EFM status

EFM working mode

Remote failure indicator status

Link monitoring status

Link monitoring parameter

show EFM status interface [ interface-name ]

Parameter:

interface-name: EFM port number

For example:

! Display all EFM status

QTECH(config)#show EFM status interface

## 20.2.15 Show EFM info

Use commands in any configuration mode:

Followings will be displayed:

Remote MAC address

Remote OUI

Local EFM working mode

Local EFM capacity

Local remote loopback status

show EFM summary

For example:

! Display EFM summary

QTECH(config)#show EFM summary

## 20.2.16 Show EFM discovery

Use commands in any configuration mode:

Followings will be displayed:

Local EFM working mode

Local EFM capacity

The mac EFMPDU length supported locally

Local port operation status

Local port loopback status

Local EFMPDU revision

Remote MAC address

Remote Vendor

Remote OUI

Remote EFMPDU revision

Remote EFM working mode

Remote EFM capacity

The mac EFMPDU length supported remotely

show EFM discovery interface [ interface-name ]

Parameter:

interface-name: EFM port number

For example:

! Display all EFM discovery interface

QTECH(config)#show EFM discovery interface

## 20.2.17 Show/clear EFM statistics

“show”command can be used in any mode but “clear”command can only be used in global configuration mode:

Followings will be displayed:

Receiving and sending numbers of local EFMPDU

Local and remote Remote failure numbers

Local and remote link monitoring numbers

- Display EFM statistics

show EFM statistics interface [ interface-name ]

- Clear EFM statistics

clear EFM statistics interface [ interface-name ]

For example:

! Display EFM statistics interface

QTECH(config)#show EFM statistics interface

## 20.2.18 Show remote MIB

Configure it in interface configuration mode:

- Show port MIB variable

show EFM port port-id-list remote-mib { phyadminstate | autonegadminstate }

- Show global MIB variable

show EFM remote-mib { fecability | fecmode }

Parameter:

phyadminstate: port status

autonegadminstate: auto-negotiation status

fecability: FEC capacity

fecmode: FEC mode

For example:

! show EFM status of port 1

QTECH(config-if-ethernet-0/1)#show EFM port 1 remote-mib phyadminstate