

# Content

## CHAPTER 1 COMMANDS FOR NETWORK PORT

### CONFIGURATION ..... 1-1

#### 1.1 COMMANDS FOR ETHERNET PORT CONFIGURATION ..... 1-1

- 1.1.1 bandwidth .....1-1
- 1.1.2 clear counters interface .....1-2
- 1.1.3 description .....1-2
- 1.1.4 flow control .....1-2
- 1.1.5 interface ethernet .....1-3
- 1.1.6 loopback.....1-3
- 1.1.7 media-type .....1-4
- 1.1.8 negotiation .....1-4
- 1.1.9 port-rate-statistics interval.....1-4
- 1.1.10 port-scan-mode .....1-4
- 1.1.11 port-status query interval .....1-5
- 1.1.12 rate-violation.....1-5
- 1.1.13 rate-violation control .....1-5
- 1.1.14 remote-statistics interval .....1-6
- 1.1.15 show interface .....1-6
- 1.1.16 shutdown .....1-9
- 1.1.17 speed-duplex .....1-10
- 1.1.18 storm-control.....1-11
- 1.1.19 storm-control .....1-11
- 1.1.20 storm-control bypass .....1-12
- 1.1.21 virtual-cable-test .....1-13
- 1.1.22 switchport discard packet.....1-13
- 1.1.23 switchport flood-control.....1-14
- 1.1.24 switchport flood-forwarding .....1-15

## CHAPTER 2 COMMANDS FOR PORT ISOLATION FUNCTION

### ..... 2-1

#### 2.1 ISOLATE-PORT GROUP .....2-1

Commands for Port Configuration	Content
2.2 ISOLATE-PORT GROUP SWITCHPORT INTERFACE .....	2-1
2.3 ISOLATE-PORT APPLY .....	2-2
2.4 SHOW ISOLATE-PORT GROUP .....	2-2
<b>CHAPTER 3 COMMANDS FOR PORT LOOPBACK DETECTION</b>	
<b>FUNCTION.....</b>	<b>3-1</b>
3.1 DEBUG LOOPBACK-DETECTION .....	3-1
3.2 LOOPBACK-DETECTION CONTROL .....	3-1
3.3 LOOPBACK-DETECTION CONTROL-RECOVERY TIMEOUT .....	3-2
3.4 LOOPBACK-DETECTION INTERVAL-TIME .....	3-2
3.5 LOOPBACK-DETECTION SPECIFIED-VLAN .....	3-3
3.6 SHOW LOOPBACK-DETECTION .....	3-3
<b>CHAPTER 4 COMMANDS FOR ULDP .....</b>	<b>4-1</b>
4.1 DEBUG ULDP .....	4-1
4.2 DEBUG ULDP ERROR .....	4-1
4.3 DEBUG ULDP EVENT .....	4-2
4.4 DEBUG ULDP FSM INTERFACE ETHERNET .....	4-2
4.5 DEBUG ULDP INTERFACE ETHERNET .....	4-2
4.6 DEBUG ULDP PACKET .....	4-3
4.7 ULDP AGGRESSIVE-MODE .....	4-3
4.8 ULDP ENABLE.....	4-3
4.9 ULDP DISABLE .....	4-4
4.10 ULDP HELLO-INTERVAL.....	4-4
4.11 ULDP MANUAL-SHUTDOWN .....	4-5
4.12 ULDP RECOVERY-TIME.....	4-5
4.13 ULDP RESET .....	4-5
4.14 SHOW ULDP .....	4-6
<b>CHAPTER 5 COMMANDS FOR LLDP FUNCTION.....</b>	<b>5-1</b>

Commands for Port Configuration	Content
5.1 CLEAR LLDP REMOTE-TABLE.....	5-1
5.2 DEBUG LLDP .....	5-1
5.3 DEBUG LLDP PACKETS .....	5-1
5.4 LLDP ENABLE .....	5-2
5.5 LLDP ENABLE (PORT) .....	5-2
5.6 LLDP MODE .....	5-3
5.7 LLDP MSGTxHOLD.....	5-3
5.8 LLDP NEIGHBORS MAX-NUM.....	5-3
5.9 LLDP NOTIFICATION INTERVAL .....	5-4
5.10 LLDP TOOMANYNEIGHBORS .....	5-4
5.11 LLDP TRANSMIT DELAY .....	5-5
5.12 LLDP TRANSMIT OPTIONAL TLV.....	5-5
5.13 LLDP TRAP .....	5-6
5.14 LLDP TX-INTERVAL .....	5-6
5.15 SHOW DEBUGGING LLDP.....	5-7
5.16 SHOW LLDP.....	5-7
5.17 SHOW LLDP INTERFACE ETHERNET .....	5-8
5.18 SHOW LLDP NEIGHBORS INTERFACE ETHERNET .....	5-8
5.19 SHOW LLDP TRAFFIC.....	5-9
<b>CHAPTER 6 COMMANDS FOR PORT CHANNEL .....</b>	<b>6-1</b>
6.1 DEBUG PORT-CHANNEL .....	6-1
6.2 INTERFACE PORT-CHANNEL .....	6-1
6.3 LACP PORT-PRIORITY .....	6-2
6.4 LACP SYSTEM-PRIORITY .....	6-2
6.5 LACP TIMEOUT.....	6-3
6.6 LOAD-BALANCE.....	6-3
6.7 PORT-GROUP .....	6-4
6.8 PORT-GROUP MODE .....	6-4

---

6.9 SHOW PORT-GROUP .....	6-5
<b>CHAPTER 7 COMMANDS FOR MTU .....</b>	<b>7-1</b>
7.1 MTU.....	7-1
<b>CHAPTER 8 COMMANDS FOR EFM OAM .....</b>	<b>8-1</b>
8.1 CLEAR ETHERNET-OAM .....	8-1
8.2 DEBUG ETHERNET-OAM ERROR .....	8-1
8.3 DEBUG ETHERNET-OAM FSM .....	8-1
8.4 DEBUG ETHERNET-OAM PACKET.....	8-2
8.5 DEBUG ETHERNET-OAM TIMER .....	8-2
8.6 ETHERNET-OAM .....	8-3
8.7 ETHERNET-OAM ERRORED-FRAME THRESHOLD HIGH .....	8-3
8.8 ETHERNET-OAM ERRORED-FRAME THRESHOLD LOW .....	8-3
8.9 ETHERNET-OAM ERRORED-FRAME WINDOW.....	8-4
8.10 ETHERNET-OAM ERRORED-FRAME-PERIOD THRESHOLD HIGH .....	8-4
8.11 ETHERNET-OAM ERRORED-FRAME-PERIOD THRESHOLD LOW .....	8-5
8.12 ETHERNET-OAM ERRORED-FRAME-PERIOD WINDOW .....	8-5
8.13 ETHERNET-OAM ERRORED-FRAME-SECONDS THRESHOLD HIGH .....	8-6
8.14 ETHERNET-OAM ERRORED-FRAME-SECONDS THRESHOLD LOW.....	8-7
8.15 ETHERNET-OAM ERRORED-FRAME-SECONDS WINDOW .....	8-7
8.16 ETHERNET-OAM ERRORED-SYMBOL-PERIOD THRESHOLD HIGH .....	8-8
8.17 ETHERNET-OAM ERRORED-SYMBOL-PERIOD THRESHOLD LOW .....	8-8
8.18 ETHERNET-OAM ERRORED-SYMBOL-PERIOD WINDOW .....	8-9
8.19 ETHERNET-OAM LINK-MONITOR .....	8-9
8.20 ETHERNET-OAM MODE.....	8-9
8.21 ETHERNET-OAM PERIOD .....	8-10
8.22 ETHERNET-OAM REMOTE-FAILURE.....	8-10
8.23 ETHERNET-OAM REMOTE-LOOPBACK.....	8-11
8.24 ETHERNET-OAM REMOTE-LOOPBACK SUPPORTED .....	8-11

Commands for Port Configuration	Content
8.25 ETHERNET-OAM TIMEOUT .....	8-12
8.26 SHOW ETHERNET-OAM .....	8-12
8.27 SHOW ETHERNET-OAM EVENTS .....	8-17
8.28 SHOW ETHERNET-OAM LINK-EVENTS CONFIGURATION .....	8-19
8.29 SHOW ETHERNET-OAM LOOPBACK STATUS.....	8-20
<b>CHAPTER 9 COMMANDS FOR PORT SECURITY .....</b>	<b>9-1</b>
9.1 CLEAR PORT-SECURITY .....	9-1
9.2 SHOW PORT-SECURITY .....	9-1
9.3 SWITCHPORT PORT-SECURITY.....	9-2
9.4 SWITCHPORT PORT-SECURITY AGING.....	9-2
9.5 SWITCHPORT PORT-SECURITY MAC-ADDRESS.....	9-2
9.6 SWITCHPORT PORT-SECURITY MAC-ADDRESS STICKY .....	9-3
9.7 SWITCHPORT PORT-SECURITY MAXIMUM .....	9-3
9.8 SWITCHPORT PORT-SECURITY VIOLATION.....	9-3
<b>CHAPTER 10 COMMANDS FOR DDM .....</b>	<b>10-1</b>
10.1 CLEAR TRANSCEIVER THRESHOLD-VIOLATION .....	10-1
10.2 DEBUG TRANSCEIVER .....	10-1
10.3 SHOW TRANSCEIVER.....	10-1
10.4 SHOW TRANSCEIVER THRESHOLD-VIOLATION .....	10-2
10.5 TRANSCEIVER-MONITORING .....	10-3
10.6 TRANSCEIVER-MONITORING INTERVAL .....	10-3
10.7 TRANSCEIVER THRESHOLD .....	10-3
<b>CHAPTER 11 COMMANDS FOR LLDP-MED .....</b>	<b>11-1</b>
11.1 CIVIC LOCATION .....	11-1
11.2 {DESCRIPTION-LANGUAGE   PROVINCE-STATE   CITY   COUNTY   STREET   LOCATIONNUM   LOCATION   FLOOR   ROOM   POSTAL   OTHERINFO} .....	11-1
11.3 ECS LOCATION.....	11-2

Commands for Port Configuration	Content
11.4 LLDP MED FAST COUNT .....	11-3
11.5 LLDP MED TRAP .....	11-3
11.6 LLDP TRANSMIT MED TLV ALL .....	11-3
11.7 LLDP TRANSMIT MED TLV CAPABILITY.....	11-4
11.8 LLDP TRANSMIT MED TLV EXTENDPOE.....	11-4
11.9 LLDP TRANSMIT MED TLV INVENTORY .....	11-5
11.10 LLDP TRANSMIT MED TLV NETWORKPOLICY .....	11-5
11.11 NETWORK POLICY .....	11-6
11.12 SHOW LLDP .....	11-7
11.13 SHOW LLDP [INTERFACE ETHERNET <IFNAME>] .....	11-8
11.14 SHOW LLDP NEIGHBORS .....	11-8
<b>CHAPTER 12 COMMANDS FOR BPDU-TUNNEL.....</b>	<b>12-1</b>
12.1 BPDU-TUNNEL-PROTOCOL .....	12-1
12.2 BPDU-TUNNEL-PROTOCOL GROUP-MAC .....	12-1
12.3 BPDU-TUNNEL-PROTOCOL PROTOCOL-MAC.....	12-2
12.4 BPDU-TUNNEL-PROTOCOL ETHERNETII .....	12-3
12.5 BPDU-TUNNEL-PROTOCOL SNAP .....	12-3
12.6 BPDU-TUNNEL-PROTOCOL LLC.....	12-4
<b>CHAPTER 13 COMMANDS FOR EEE ENERGY-SAVING .....</b>	<b>13-1</b>
13.1 EEE ENABLE.....	13-1
<b>CHAPTER 14 COMMANDS FOR LED SHUT-OFF .....</b>	<b>14-1</b>
14.1 LED SHUT-OFF .....	14-1

# Chapter 1 Commands for Network Port Configuration

## 1.1 Commands for Ethernet Port Configuration

### 1.1.1 bandwidth

**Command:** `bandwidth control <bandwidth> {transmit | receive | both}`  
`no bandwidth control`

**Function:** Enable the bandwidth limit function on the port; the no command disables this function.

**Parameter:** `<bandwidth>` is the bandwidth limit, which is shown in kbps ranging between 1-1000000K; both refers to the bandwidth limit when the port receives and sends data, receive refers to the bandwidth **limit** will only performed when the switch receives data from out side, while **transmit** refers to the function will be perform on sending only.

**Command Mode:** Port Mode.

**Default:** Bandwidth limit disabled by default.

**Usage Guide:** When the bandwidth limit is enabled with a size set, the max bandwidth of the port is determined by this size other than by 10/100/1000M. If **[both | receive | transmit]** keyword is not specified, the default is **both**.

Note: The bandwidth limit can not exceed the physic maximum speed on the port. For example, an 10/100M Ethernet port can not be set to a bandwidth limit at 101000K (or higher), but applicable on a 10/100/1000 port working at a speed of 100M. If the actual bandwidth is not a integral multiple of chip bandwidth granularity, it will be modified automatically. For example, a chip bandwidth granularity is 64K, but the input bandwidth is 50, the bandwidth will be modified as 64K.

Bandwidth control is similar to broadcast suppression. There is granularity limitation for the chip; the switch support 16Kbps granularities. If the `<Kbits>` that user input is not the integer times of 16, the system will adjust to the integer times of 16 automatically and print the true limit value to user.

**Example:** Set the bandwidth limit of 1/0/1-8 port is 40000K.

```
Switch(config)#interface ethernet 1/0/1-8
```

```
Switch(Config-If-Port-Range)#bandwidth control 40000 both
```

## 1.1.2 clear counters interface

**Command:** clear counters [interface {ethernet <interface-list> | vlan <vlan-id> | port-channel <port-channel-number> | <interface-name>}]

**Function:** Clears the statistics of the specified port.

**Parameters:** <interface-list> stands for the Ethernet port number; <vlan-id> stands for the VLAN interface number; <port-channel-number> for trunk interface number; <interface-name> for interface name, such as port-channel 1.

**Command mode:** Admin Mode.

**Default:** Port statistics are not cleared by default.

**Usage Guide:** If no port is specified, then statistics of all ports will be cleared.

**Example:** Clearing the statistics for Ethernet port1/0/1.

```
Switch#clear counters interface ethernet 1/0/1
```

## 1.1.3 description

**Command:** description <string>

no description

**Function:** Set name for specified port; the no command cancels this configuration.

**Parameter:** <string> is a character string, which should not exceeds 200 characters.

**Command Mode:** Port Mode.

**Default:** No port name by default.

**Usage Guide:** This command is for helping the user manage switches, such as the user assign names according to the port application, e.g. financial as the name of 1/0/1-2 ports which is used by financial department, engineering as the name of 1/0/9 ports which belongs to the engineering department, while the name of 1/0/12 ports is assigned with Server, which is because they connected to the server. In this way the port distribution state will be brought to the table.

**Example:** Specify the description of 1/0/1-2 port as financial.

```
Switch(config)#interface ethernet 1/0/1-2
```

```
Switch(Config-If-Port-Range)#description financial
```

## 1.1.4 flow control

**Command:** flow control

no flow control

**Function:** Enables the flow control function for the port: the “no flow control” command disables the flow control function for the port.



**Command mode:** Port Mode.

**Default:** Port flow control is disabled by default.

**Usage Guide:** After the flow control function is enabled, the port will notify the sending device to slow down the sending speed to prevent packet loss when traffic received exceeds the capacity of port cache. Ports support IEEE802.3X flow control; the ports work in half-duplex mode, supporting back-pressure flow control. If flow control results in serious HOL, the switch will automatically start HOL control (discarding some packets in the COS queue that may result in HOL) to prevent drastic degradation of network performance.

**Note:** Port flow control function is not recommended unless the users need a slow speed, low performance network with low packet loss. Flow control will not work between different cards in the switch. When enable the port flow control function, speed and duplex mode of both ends should be the same.

**Example:** Enabling the flow control function in ports 1/0/1-8.

```
Switch(config)#interface ethernet 1/0/1-8
Switch(Config-If-Port-Range)#flow control
```

## 1.1.5 interface ethernet

**Command:** `interface ethernet <interface-list>`

**Function:** Enters Ethernet Port Mode from Global Mode.

**Parameters:** `<interface-list>` stands for port number.

**Command mode:** Global Mode

**Usage Guide:** Run the `exit` command to exit the Ethernet Port Mode to Global Mode.

**Example:** Entering the Ethernet Port Mode for ports 1/0/1, 1/0/4-5, 1/0/8.

```
Switch(config)#interface ethernet 1/0/1;1/0/4-5;1/0/8
Switch(Config-If-Port-Range)#
```

## 1.1.6 loopback

**Command:** `loopback`

`no loopback`

**Function:** Enables the loopback test function in an Ethernet port; the `no` command disables the loopback test on an Ethernet port.

**Command mode:** Port Mode.

**Default:** Loopback test is disabled in Ethernet port by default.

**Usage Guide:** Loopback test can be used to verify the Ethernet ports are working normally. After loopback has been enabled, the port will assume a connection established to itself, and all traffic sent from the port will be received at the very same port.

**Example:** Enabling loopback test in Ethernet ports 1/0/1-8.

```
Switch(config)#interface ethernet 1/0/1-8  
Switch(Config-If-Port-Range)#loopback
```

## 1.1.7 media-type

This command is not supported by switch.

## 1.1.8 negotiation

**Command:** negotiation {on | off}

**Function:** Enables/Disables the auto-negotiation function of a 1000Base-FX port.

**Parameters:** on: enables the auto-negotiation; off: disable the auto-negotiation.

**Command mode:** Port configuration Mode.

**Default:** Auto-negotiation is enabled by default.

**Usage Guide:** This command applies to 1000Base-FX interface only. The **negotiation** command is not available for 1000Base-TX or 100Base-TX interface. To change the negotiation mode, speed and duplex mode of 1000Base-TX port, use **speed-duplex** command instead.

**Example:** Port 21 of Switch1 is connected to port 21 of Switch2, the following will disable the negotiation for both ports.

```
Switch1(config)#interface ethernet1/0/21  
Switch1(Config-If-Ethernet1/0/21)#negotiation off  
Switch2(config)#interface ethernet1/0/21  
Switch2(Config-If-Ethernet1/0/21)#negotiation off
```

## 1.1.9 port-rate-statistics interval

**Command:** port-rate-statistics interval <interval-value>

**Function:** Set the interval of port-rate-statistics, ranging from 5 to 600.

**Parameter:** interval-value: The interval of port-rate-statistics, unit is second, ranging from 5 to 600 with the configuration step of 5.

**Default:** Only port-rate-statistics of 5 seconds and 5 minutes are displayed.

**Command Mode:** Global Mode

**Usage Guide:** None.

**Example:** Count the interval of port-rate-statistics as 20 seconds.

```
Switch(config)#port-rate-statistics interval 20
```

## 1.1.10 port-scan-mode

This command is not supported by switch.

### 1.1.11 port-status query interval

This command is not supported by the switch.

### 1.1.12 rate-violation

**Command:** `rate-violation [broadcast | multicast | unicast | all] <200-2000000>`  
`no rate-violation`

**Function:** Set the max packet reception rate of a port. Any packet which violate the packet reception rate to process the control operation (currently shutdown and block operations are supported) of rate-violation. The no command will disable the rate-violation function of a port.

The rate-violation means the port received the packet rate (the number of the received packets per second), it can distinguish the packet type, such as broadcast packet, multicast packet, unicast packet.

**Parameters:** broadcast: broadcast packet

multicast: multicast packet

unicast: unicast packet

all: all packets

<200-2000000>: the number of packets allowed to pass per second.

**Command Mode:** Interface Mode

**Default:** There is no limit for the packet reception rate.

**Usage Guide:** This command is mainly used to detect the abnormal port flow. For example, when there are a large number of broadcast packets caused by a loopback, which affect the processing of other tasks, the port will be shut down or block to ensure the normal processing of the switch. This command needs to associate with rate-violation control command.

**Example:** Set the rate-violation of port 1/0/8-10 (GB ports) as 10000pps, it will be shutdown after rate-violation and the port recovery time as 1200 seconds, when the packet reception rate exceeds 10000, the port will but shut down, and then, after 1200 seconds, the port will be UP again.

```
Switch(config)#interface ethernet 1/0/8-10
```

```
Switch(Config-Port-Range)#rate-violation unicast 10000
```

```
Switch(Config-Port-Range)#rate-violation control shutdown recovery 1200
```

### 1.1.13 rate-violation control

**Command:** `rate-violation control [shutdown recovery <0-86400> | block]`

**no rate-violation control**

**Function:** Set the control operation after the rate-violation of a port, **shutdown** (it needs to configure the recovery time of a port after shutdown) and **block** operations are supported presently. The no operation will disable the rate-violation control operation of a port.

**Parameters:** **shutdown:** A port is shutdown after rate-violation.

**block:** A port is block after rate-violation, this parameter and MSTP, EAPS(MRPP), Loopback Detection, ULPP are mutually exclusive. If other modules set STP state, this function can not be set to block mode.

**<0-86400>:** The interval of recovery after shutdown, the unit is s.

**recovery:** After a period of time the port can recover Shutdown to UP again. **<0-86400>** is the timeout of recovery. For example, if the shutdown of a port happens after the packet reception rate exceeding the limit, the port will be UP again when the user-defined timeout expires. The default timeout is 300s, while 0 means the recovery will never happen.

**Command Mode:** Interface Mode

**Default:** There is no control operation for rate-violation.

**Usage Guide:** This command is mainly used to the control operation after rate-violation. **shutdown** or **block** operation can ensure the normal processing to other tasks of the switch. This command needs to associate with rate-violation [broadcast|multicast|unicast|all] <200-2000000> command.

**Example:** After set the rate-violation of the unicast packet of port 1/8-10 (GB ports) as 10000pps, the port will be block.

```
Switch(Config)#interface ethernet 1/0/8-10
Switch(Config-Port-Range)#rate-violation unicast 10000
Switch(Config-Port-Range)#rate-violation control block
```

## 1.1.14 remote-statistics interval

This command is not supported by the switch.

## 1.1.15 show interface

**Command:** `show interface [ethernet <interface-number> | port-channel <port-channel-number> | vlan <vlan-id> | <interface-name>] [detail]`

**show interface ethernet status**

**show interface ethernet counter {packet | rate}**

**Function:** Show information of layer 3 or layer 2 port on the switch

**Parameter:** `<vlan-id>` is the VLAN interface number, the value range from 1 to 4094. `<interface-number>` is the port number of the Ethernet, **status** show important information of all the layer 2 ports. **counter {packet | rate}** show package number or rate statistics of all layer 2 ports. `<port-channel-number>` is the number of the aggregation interface, `<interface-name>` is the name of the interface such as port-channel1. **[detail]** show the detail of the port.

**Command Mode:** Admin and Configuration Mode.

**Default:** Information not displayed by default

**Usage Guide:** While for vlan interfaces, the port MAC address, IP address and the statistic state of the data packet will be shown; As for Ethernet port, this command will show port speed rate, duplex mode, flow control switch state, broadcast storm suppression of the port and the statistic state of the data packets; for aggregated port, port speed rate, duplex mode, flow control switch state, broadcast storm suppression of the port and the statistic state of the data packets will be displayed. The information of all ports on the switch will be shown if no port is specified.

Using [detail] to show the detail information for ethernet port and port-channel port, the information is related with the type of switch, board card.

For ethernet port, using status to show important information of all the layer 2 ports by list format. each port is a row, the showing information include port number, Link, Protocol status, Speed, Duplex, Vlan, port type and port name; counter packets show package number statistics of all ethernet ports, include layer 2 unicast, broadcast, multicast, error of input and output redirection package number; counter rate show the rate statistics of all ethernet ports, input and output package number, byte number in 5 minutes and 5 seconds.

**Example:** Show the information of VLAN 1

```
Switch #show interface vlan 1
```

```
Vlan1 is up, line protocol is up, dev index is 11001
```

```
Device flag 0x1003(UP BROADCAST MULTICAST)
```

```
Time since last status change:0w-0d-4h-10m-59s (15059 seconds)
```

```
IPv4 address is:
```

```
192.168.1.1      255.255.255.0    (Primary)
```

```
VRF Bind: Not Bind
```

```
Hardware is EtherSVI, address is 00-03-0f-04-03-02
```

```
MTU is 1500 bytes , BW is 0 Kbit
```

```
Encapsulation ARPA, loopback not set
```

```
5 minute input rate 172207769 bits/sec, 174144 packets/sec
```

```
5 minute output rate 494 bits/sec, 1 packets/sec
```

```
The last 5 second input rate 172204454 bits/sec, 175342 packets/sec
```

The last 5 second output rate 397 bits/sec, 0 packets/sec

Input packets statistics:

Input queue 0/1200, 0 drops

2665793249 packets input, 4017750506 bytes, 2664563783 no buffer

29 input errors, 6 CRC, 0 oversize, 0 undersize

0 jabber, 23 fragments

Output packets statistics:

7759 packets output, 961906 bytes, 0 underruns

0 output errors, 0 collisions

Show the information of port 1/0/1:

Switch#show interface e1/0/1

Switch #show interface ethernet 1/0/1

Interface brief:

Ethernet1/0/1 is down, line protocol is down

Ethernet1/0/1 is layer 2 port, alias name is (null), index is 1

Hardware is Gigabit-TX, address is 00-03-0f-04-03-01

PVID is 1

MTU 1500 bytes, BW 10000 Kbit

Time since last status change:0w-0d-4h-30m-59s (16259 seconds)

Encapsulation ARPA, Loopback not set

Auto-duplex, Auto-speed

FlowControl is off, MDI type is auto

Statistics:

5 minute input rate 0 bits/sec, 0 packets/sec

5 minute output rate 0 bits/sec, 0 packets/sec

The last 5 second input rate 0 bits/sec, 0 packets/sec

The last 5 second output rate 0 bits/sec, 0 packets/sec

Input packets statistics:

0 input packets, 0 bytes, 0 no buffer

0 unicast packets, 0 multicast packets, 0 broadcast packets

0 input errors, 0 CRC, 0 frame alignment, 0 overrun, 0 ignored,

0 abort, 0 length error, 0 undersize 0 jabber, 0 fragments, 0 pause frame

Output packets statistics:

0 output packets, 0 bytes, 0 underruns

0 unicast packets, 0 multicast packets, 0 broadcast packets

0 output errors, 0 collisions, 0 late collisions, 0 pause frame

Show the important information of all layer 2 ports:

Switch #show interface ethernet status

Codes: A-Down - administratively down, a - auto, f - force, G - Gigabit

Interface	Link/Protocol	Speed	Duplex	Vlan	Type	Alias Name
1/0/1	DOWN/DOWN	auto	auto	1	G-TX	
1/0/2	DOWN/DOWN	auto	auto	1	G-TX	
1/0/3	UP/UP	a-100M	a-FULL	1	G-TX	
1/0/4	UP/UP	a-100M	a-FULL	1	G-TX	...

Show the package number statistics information of all layer 2 ports:

Switch #show interface ethernet counter packet

Interface	Unicast(pkts)	BroadCast(pkts)	MultiCast(pkts)	Err(pkts)
1/0/1	IN 0	0	0	0
	OUT 0	0	0	0
1/0/2	IN 0	0	0	0
	OUT 0	0	0	0
1/0/3	IN 0	0	1338508690	20
	OUT 0	0	7769	0
1/0/4	IN 0	0	1338506502	9
	OUT 0	0	23	0
...				

Show the rate statistics information of all layer 2 ports:

Switch #show interface ethernet counter rate

Interface	IN(pkts/s)	IN(bits/s)	OUT(pkts/s)	OUT(bits/s)
1/0/1	5m 0	0	0	0
	5s 0	0	0	0
1/0/2	5m 0	0	0	0
	5s 0	0	0	0
1/0/3	5m 86,780	86,108,687	0	494
	5s 87,671	86,089,926	0	397
1/0/4	5m 86,780	86,108,684	0	0
	5s 87,671	86,089,926	0	0
...				

## 1.1.16 shutdown

Command: shutdown

**no shutdown**

**Function:** Shuts down the specified Ethernet port; the no command opens the port.

**Command mode:** Port Mode.

**Default:** Ethernet port is open by default.

**Usage Guide:** When Ethernet port is shut down, no data frames are sent in the port, and the port status displayed when the user types the “**show interface**” command is “down”.

**Example:** Opening ports 1/0/1-8.

```
Switch(config)#interface ethernet1/0/1-8
```

```
Switch(Config-If-Port-Range)#no shutdown
```

**1.1.17 speed-duplex**

**Command:** **speed-duplex** {**auto** [**10** [**100** [**1000**]] [**auto** | **full** | **half** ]] | **force10-half** | **force10-full** | **force100-half** | **force100-full** | **force100-fx** [**module-type** {**auto-detected** | **no-phy-integrated** | **phy-integrated**}] | {{**force1g-half** | **force1g-full**} [**nonegotiate** [**master** | **slave**]]}}

**no speed-duplex**

**Function:** Sets the speed and duplex mode for 1000Base-TX, 100Base-TX or 100Base-FX ports; the no command restores the default speed and duplex mode setting, i.e., auto speed negotiation and duplex.

**Parameters:** **auto** is the auto speed and duplex negotiation, **10** is 10Mbps speed, **100** is 100Mbps speed, **1000** is 1000Mbps speed, **auto** is duplex negotiation, **full** is full-duplex, **half** is half-duplex; **force10-half** is the forced 10Mbps at half-duplex mode; **force10-full** is the forced 10Mbps at full-duplex mode; **force100-half** is the forced 100Mbps at half-duplex mode; **force100-full** is the forced 100Mbps at full-duplex mode; **force100-fx** is the forced 100Mbps at full-duplex mode; **module-type** is the type of 100Base-FX module; **auto-detected:** automatic detection; **no-phy-integrated:** there is no phy-integrated 100Base-FX module; **phy-integrated:** phy-integrated 100Base-FX module; **force1g-half** is the forced 1000Mbps speed at half-duplex mode; **force1g-full** is the forced 1000Mbps speed at full-duplex mode; **nonegotiate** disables auto-negotiation forcibly for 1000Mb port; **master** forces the 1000Mb port to be **master** mode; **slave** forces the 1000Mb port to be **slave** mode.

**Command mode:** Port Mode.

**Default:** Auto-negotiation for speed and duplex mode is set by default.

**Usage Guide:** This command is configured the port speed and duplex mode. When configuring port speed and duplex mode, the speed and duplex mode must be the same as the setting of the remote end, i.e., if the remote device is set to auto-negotiation, then auto-negotiation should be set at the local port. If the remote end is in forced mode, the same should be set in the local end.



1000Gb ports are by default **master** when configuring **nonegotiate** mode. If one end is set to **master** mode, the other end must be set to **slave** mode.

**force1g-half** is not supported yet.

**Example:** Port 1 of Switch1 is connected to port 1 of Switch2, the following will set both ports in forced 100Mbps at half-duplex mode.

```
Switch1(config)#interface ethernet1/0/1
```

```
Switch1(Config-If-Ethernet1/0/1)#speed-duplex force100-half
```

```
Switch2(config)#interface ethernet1/0/1
```

```
Switch2(Config-If-Ethernet1/0/1)#speed-duplex force100-half
```

## 1.1.18 storm-control

**Command:** **storm-control { kbps | pps }**

**no storm-control pps**

**Function:** Sets the traffic limit for broadcasts, multicasts and unknown destination unicasts on all ports in the switch, namely set the limit unit of limit broadcast, multicast or unknown destination unicast is kbps or pps; the no command is recover the default value (kbps) to be limit mode.

**Parameters:** **kbps** means the unit of limit is kbits/s; **pps** means the limit unit is packets/s.

**Command Mode:** **Global Mode.**

**Default:** The default is kbps.

**Usage Guide:** Configure the kbps or pps as the limit mode in global mode, then set broadcast, multicast or unknown unicast limit value in port mode.

**Example:** Setting ports 1-8 allow 1000kbit broadcast packets per second.

```
Switch(config)#storm-control pps
```

```
Switch(config-if-port-range)#storm-control broadcast 1000
```

## 1.1.19 storm-control

**Command:** **storm-control {unicast | broadcast | multicast} <value>**

**no storm-control {unicast | broadcast | multicast}**

**Function:** Sets the traffic limit for broadcasts, multicasts and unknown destination unicasts on all ports in the switch; the no command disables this traffic suppression function on all ports in the switch, i.e., enables broadcasts, multicasts and unknown destination unicasts to pass through the switch at line speed.

**Parameters:** use **unicast** to limit unicast traffic for unknown destination; **multicast** to limit multicast traffic; **broadcast** to limit broadcast traffic. **<value>** means the number of packets allowed to pass per second or the packets numbers, the Kbps ranging from 1 to

1000000, the pps ranging from 1 to 1488095.

**Command mode:** Port Mode.

**Default:** No limit is set by default. So, broadcasts, multicasts and unknown destination unicasts are allowed to pass at line speed.

**Usage Guide:** All ports in the switch belong to a same broadcast domain if no VLAN has been set. The switch will send the above mentioned three traffics to all ports in the broadcast domain, which may result in broadcast storm and so may greatly degrade the switch performance. Enabling Broadcast Storm Control can better protect the switch from broadcast storm. If the allowed traffic is set to 1000kbps, this means allow 1000 kbit per second and suppress the rest. The switch supports two kind of speed limit, it includes kbps which is limit by bandwidth and pps which is limit by the numbers of packets. It only can select one from the two ways and cannot set the two way in the same time (by global mode).

Broadcast suppression is similar to bandwidth control. There is granularity limitation for the chip; the switch support 16Kbps granularities. If the <Kbits> that user input is not the integer times of 16, the system will adjust to the integer times of 16 automatically and print the true limit value to user.

**Example:** Setting ports 1-8 allow 1000kbit broadcast packets per second.

```
Switch(config-if-port-range)#storm-control broadcast 1000
```

## 1.1.20 storm-control bypass

**Command:** `storm-control bypass {arp | bpdu | igmp | rma | rek } <enable | disable >`

**Function:** Set the switch broadcast to limit protocol filtering function.

**Parameters:** **arp** means the protocol packets of arp-request, **multicastbpdu** means bpdu protocol packets, **igmp** means igmp protocol packets, **rma** means multicast address is the saved multicast packets, **oadcastrek** means the special private packets that realk used. **<enable>** enable some protocol to limit filter function. **<enable>** enable some protocol to broadcast limit filter function.

**Command Mode:** Global Mode.

**Default:** Disable.

**Usage Guide:** Configure broadcast limit filter function of some protocol in global mode, then configure broadcast limit in port mode. At this moment, the protocol packets flow from the port cannot be limited.

**Example:** Configure arp protocol filter function to make the arp-request data packets thatfrom 1 port in cannot be limited.

```
Switch (config)#storm-control bypass arp enable
```

```
Switch(config-if-ethernet1/0/1)#storm-control broadcast 1000
```

### 1.1.21 virtual-cable-test

**Command:** virtual-cable-test interface (ethernet *IFNAME*)

**Function:** Test the link of the twisted pair cable connected to the Ethernet port. The response may include: well, short, open, fail. If the test information is not well, the location of the error will be displayed (how many meters it is away from the port).

**Parameter:** <*interface-list*>: Port ID

**Command Mode:** Admin Mode.

**Default Settings:** No link test.

**Usage Guide:** The RJ-45 port connected with the twisted pair under test should be in accordance with the wiring sequence rules of IEEE802.3, or the wire pairs in the test result may not be the actual ones. On a 100M port, only two pairs are used: (1, 2) and (3, 6), whose results are the only effective ones. If a 1000M port is connected to a 100M port, the results of (4, 5) and (7, 8) will be of no meaning. The result may have deviations according to the type of the twisted pair, the temperature, working voltage and other conditions. When the temperature is 20 degree Celsius, and the voltage is stable without interference, and the length of the twisted pair is not longer than 100 meters, a deviation of +/-2 meters is allowed. When the port is at Link UP status, a deviation of +/-10 meters is allowed. Notice: the test procedure will block all data flow on the line for 5-10 seconds, and then restore the original status.

568A wiring sequence: (1 green white, 2 green), (3 orange white, 6 orange), (4 blue, 5 blue white), (7 brown white, 8 brown).

568B wiring sequence: (1 orange white, 2 orange), (3 green white, 6 green), (4 blue, 5 blue white), (7 brown white, 8 brown).

**Example:** Test the link status of the twisted pair connected to the 1000M port 1/0/1.

```
Switch#virtual-cable-test interface ethernet 1/0/1
```

```
Interface Ethernet1/0/1:
```

```
-----
```

Cable pairs	Cable status	Error length (meters)
-----	-----	-----
(1, 2)	open	5
(3, 6)	open	5
(4, 5)	open	5
(7, 8)	short	5

### 1.1.22 switchport discard packet

**Command:** `switchport discard packet { all | untag }`

`no switchport discard packet { all | untag }`

**Function:** Configure the port not to receive any packet or untag; the **no** command cancel the restriction of discard, it means the port is allowed to receive any packet or untag.

**Parameters:** **all** means it does not receive any packet including untag, tag and the deal packet. **untag** means it does not receive untag.

**Command Mode:** Port Mode

**Default:** The default does not have the restriction.

**Usage Guide:** This command is not suggested to be configured only if there is the special requirement.

**Example:** Configure the port of 1/0/8 not to receive all packets.

```
Switch(config)#interface ethernet 1/0/8
```

```
Switch(config-if-ethernet1/0/8)#switchport discard packet all
```

### 1.1.23 switchport flood-control

**Command:** `switchport flood-control { bcast|mcast|ucast }`

`no switchport flood-control { bcast|mcast|ucast }`

**Function:** Configure that switch does not transmit broadcast, unknown multicast or unknown unicast packets any more to the specified port; no command restores the default configuration.

**Parameter:** **bcast:** prevents that broadcast packets cannot be transmitted to the specified port; **mcast:** prevents that unknown multicast packets cannot be transmitted to the specified port; **ucast:** prevents that unknown unicast packets cannot be transmitted to the specified port.

**Command Mode:** Port configuration mode.

**Default:** Switch transmits broadcast, unknown multicast and unknown unicast packets to other port in broadcast domain.

**Usage Guide:** This command takes effect for 100M and 1000M ports; it is also takes effect for Access, Trunk and Hybrid ports. When this command is valid, the port will allow unicast or multicast flow to pass after port learned the corresponding unicast mac or multicast mac.

This command only control that broadcast, multicast and unknown unicast packets sent by other ports cannot be transmitted to the specified port, but it cannot control these packets from the specified port. For example, set **switchport flood-control bcast** command in port 1/0/1, broadcast packets cannot be transmitted from other ports to port 1/0/1, but port 1/0/1 can receive and transmit broadcast packets.

**Example:** Configure flood-control of bcast and mcast for port 1/0/1 or port 1/0/8-10 respectively.

```
Switch(config)#interface ethernet 1/0/1
Switch(config-if-ethernet1/0/1)#switchport flood-control bcast
```

```
Switch(config)#interface ethernet 1/0/8-10
Switch(config-if-port-range)#switchport flood-control mcast
```

## 1.1.24 switchport flood-forwarding

**Command:** `switchport flood-forwarding mcast`

**no switchport flood-forwarding mcast**

**Function:** Configure that switch transmit unknown multicast or unknown unicast packets to the specified port; no command restores the default configuration.

**Parameters:** `mcast`: prevents that unknown multicast packets can be transmitted to the specified port.

**Command Mode:** Port Mode.

**Default:** Switch transmits unknown multicast packets to other port in broadcast domain.

**Usage Guide:** This command takes effect for 100M and 1000M ports; it is also takes effect for Access, Trunk and Hybrid ports. The command is usually combined with `ip imgp snooping`, `ip imgp snooping` does not supports unknown multicast and broadcast, it can transfer unknown multicast flow after configure `switchport flood-forwarding mcast`.

**Example:** Set switch 1/0/1 port broadcast flood-forwarding.

```
switch#
switch#confi
switch(config)#interface ethernet 1/0/1
switch(config-if-ethernet1/0/1)# switchport flood-forwarding mcast
switch(config-if-ethernet1/0/1)#exit
switch(config)#
```

# Chapter 2 Commands for Port Isolation Function

## 2.1 isolate-port group

**Command:** isolate-port group <WORD>  
no isolate-port group <WORD>

**Function:** Set a port isolation group, which is the scope of isolating ports; the no operation of this command will delete a port isolation group and remove all ports out of it.

**Parameters:** <WORD> is the name identification of the group, no longer than 32 characters.

**Command Mode:** Global Mode.

**Default:** None.

**Usage Guide:** Users can create different port isolation groups based on their requirements. For example, if a user wants to isolate all downlink ports in a vlan of a switch, he can implement that by creating a port isolation group and adding all downlink ports of the vlan into it. No more than 16 port isolation groups can a switch have. When the users need to change or redo the configuration of the port isolation group, he can delete the existing group with the no operation of this command.

**Example:** Create a port isolation group and name it as "test".

```
Switch>enable
```

```
Switch#config
```

```
Switch(config)#isolate-port group test
```

## 2.2 isolate-port group switchport interface

**Command:** isolate-port group <WORD> switchport interface [ethernet] <IFNAME>  
no isolate-port group <WORD> switchport interface [ethernet]  
<IFNAME>

**Function:** Global Mode: Add one port or a group of ports into a port isolation group to isolate, which will become isolated from the other ports in the group. The no operation of this command will remove one port or a group of ports out of a port isolation group, which will be able to communicate with ports in that group normally. If the ports removed from the group still belong to another port isolation group, they will remain isolated from the ports in that group. If an Ethernet port is a member of a convergence group, it should not be added

into a port isolation group, and vice versa, a member of a port isolation group should not be added into an aggregation group. But one port can be a member of one or more port isolation groups.

**Vlan mode:** Add one port or a group of ports into a port isolation group to isolate, which will become isolated from the other ports in a vlan. The no operation of this command will remove one port or a group of ports out of a port isolation group, which will be able to communicate with ports in that group normally.

**Parameters:** **<WORD>** is the name identification of the group, no longer than 32 characters. If there is no such group with the specified name, create one; **ethernet** means that the ports to be isolated is Ethernet ones, followed by a list of Ethernet ports, supporting symbols like ";" and "-". For example: "ethernet 1/0/1;3;4-7;8"; **<IFNAME>** is the name of the interface, such as e1/0/1. If users use interface name, the parameter of ethernet will not be required.

**Command Mode:** Global Mode or Vlan Configuration Mode.

**Default:** None.

**Usage Guide:** Users can add Ethernet ports into a port isolation group according to their requirements, the isolation group can isolate it from each other (Global mode) in all vlan, it also can isolate it from each other (vlan mode) in some vlan or remove them from a port isolation group according to their requirements. When an Ethernet port is a member of more than one port isolate group, it will be isolated from every port of all groups it belongs to.

**Example:** Add Ethernet ports 1/0/1-2 and 1/0/5 into a port isolation group named as "test", add Ethernet ports 1/0/3-4 into a port isolation group named as "1" in vlan10.

```
Switch(config)#isolate-port group test switchport interface ethernet 1/0/1-2; 1/0/5
```

```
Switch(config-vlan10)#isolate-port group 1 switchport interface ethernet 1/0/3-4
```

## 2.3 isolate-port apply

This command is not supported by the switch.

## 2.4 show isolate-port group

**Command:** show isolate-port group [**<WORD>**]

**Function:** Display the configuration of port isolation, including all configured port isolation groups and Ethernet ports in each group.

**Parameters:** **<WORD>** the name identification of the group, no longer than 32 characters; no parameter means to display the configuration of all port isolation groups.

**Command Mode:** Admin Mode and Global Mode.

**Default:** Display the configuration of all port isolation groups.

**Usage Guide:** Users can view the configuration of port isolation with this command.

**Example:** Display the port isolation configuration of the port isolation group named as "test".

```
Switch(config)#show isolate-port group test
```

```
Isolate-port group test
```

```
    The isolate-port Ethernet1/0/5
```

```
    The isolate-port Ethernet1/0/2
```



# Chapter 3 Commands for Port Loopback Detection Function

## 3.1 debug loopback-detection

**Command:** debug loopback-detection

**Function:** After enabling the loopback detection debug on a port, BEBUG information will be generated when sending, receiving messages and changing states.

**Parameters:** None.

**Command Mode:** Admin Mode.

**Default:** Disabled by default.

**Usage Guide:** Display the message sending, receiving and state changes with this command.

**Example:**

```
Switch#debug loopback-detection
```

```
%Jan 01 03:29:18 2006 Send loopback detection probe packet:dev Ethernet1/0/10, vlan id 1
```

```
%Jan 01 03:29:18 2006 Send loopback detection probe packet:dev Ethernet1/0/10, vlan id 2
```

## 3.2 loopback-detection control

**Command:** loopback-detection control {shutdown |block }  
no loopback-detection control

**Function:** Enable the function of loopback detection control on a port, the no operation of this command will disable the function.

**Parameters:** **shutdown** set the control method as shutdown, which means to close down the port if a port loopback is found.

**block** set the control method as block, which means to block a port by allowing bpdv and loopback detection messages only if a port loopback is found.

**Default:** Disable the function of loopback diction control.

**Command Mode:** Port Mode.

**Usage Guide:** If there is any loopback, the port will not recovery the state of be controlled after enabling control operation on the port. If the overtime is configured, the ports will

recovery normal state when the overtime is time-out. If the control method is block, the corresponding relationship between instance and vlan id should be set manually by users, it should be noticed when be used.

**Example:** Enable the function of loopback detection control under port1/2 mode.

```
Switch(config)#interface ethernet 1/0/2
```

```
Switch(Config-If-Ethernet1/0/2)#loopback-detection control shutdown
```

```
Switch(Config-If-Ethernet1/0/2)#no loopback-detection control
```

### 3.3 loopback-detection control-recovery timeout

**Command:** `loopback-detection control-recovery timeout <0-3600>`

**Function:** This command is used to recovery to uncontrolled state after a special time when a loopback being detected by the port entry be controlled state.

**Parameters:** <0-3600> second is recovery time for be controlled state, 0 is not recovery state.

**Default:** The recovery is not automatic by default.

**Command Mode:** Global Configuration Mode.

**Usage Guide:** When a port detects a loopback and works in control mode, the ports always work in control mode and not recover. The port will not sent packet to detection in shutdown mode, however, the port will sent loopback-detection packet to detection whether have loopback in block or learning mode. If the recovery time is configured, the ports will recovery normal state when the overtime is time-out. The recovery time is a useful time for shutdown control mode, because the port can keep on detection loopback in the other modes, so suggest not to use this command.

**Examples:** Enable automatic recovery of the loopback-detection control mode after 30s.

```
Switch(config)#loopback-detection control-recovery timeout 30
```

### 3.4 loopback-detection interval-time

**Command:** `loopback-detection interval-time <loopback> <no-loopback>  
no loopback-detection interval-time`

**Function:** Set the loopback detection interval. The no operate closes the loopback detection interval function.

**Parameters:** <loopback > the detection interval if any loopback is found, ranging from 5 to 300, in seconds.

<no-loopback > the detection interval if no loopback is found, ranging from 1 to 30, in seconds.

**Default:** The default value is 5s with loopbacks existing and 3s otherwise.

**Command Mode:** Global Mode.

**Usage Guide:** When there is no loopback detection, the detection interval can be relatively shorter, for too short a time would be a disaster for the whole network if there is any loopback. So, a relatively longer interval is recommended when loopbacks exist.

**Example:** Set the loopback detection interval as 35, 15.

```
Switch(config)#loopback-detection interval-time 35 15
```

## 3.5 loopback-detection specified-vlan

**Command:** `loopback-detection specified-vlan <vlan-list>`

`no loopback-detection specified-vlan [<vlan-list>]`

**Function:** Enable the function of loopback detection on the port and specify the VLAN to be checked; the no operation of this command will disable the function of detecting loopbacks through this port or the specified VLAN.

**Parameters:** `<vlan-list>` the list of VLANs allowed passing through the port. Given the situation of a trunk port, the specified VLANs can be checked. So this command is used to set the vlan list to be checked.

**Default:** Disable the function of detecting the loopbacks through the port.

**Command Mode:** Port Mode.

**Usage Guide:** If a port can be a TRUNK port of multiple Vlan, the detection of loopbacks can be implemented on the basis of port+Vlan, which means the objects of the detection can be the specified Vlan on a port. If the port is an ACCESS port, only one Vlan on the port is allowed to be checked despite the fact that multiple Vlan can be configured. This function is not supported under Port-channel.

**Example:** Enable the function of loopback detection under port 1/2 mode.

```
Switch(config)#interface ethernet 1/0/2
```

```
Switch(Config-If-Ethernet1/0/2)#switchport mode trunk
```

```
Switch(Config-If-Ethernet1/0/2)#switchport trunk allowed vlan all
```

```
Switch(Config-If-Ethernet1/0/2)#loopback-detection specified-vlan 1;3;5-20
```

```
Switch(Config-If-Ethernet1/0/2)#no loopback-detection specified-vlan 1;3;5-20
```

## 3.6 show loopback-detection

**Command:** `show loopback-detection [interface <interface-list>]`

**Function:** Display the state of loopback detection on all ports if no parameter is provided, or the state and result of the specified ports according to the parameters.

**Parameters:** *<interface-list>* the list of ports to be displayed, for example: ethernet 1/0/1.

**Command Mode:** Admin and Configuration Mode.

**Usage Guide:** Display the state and result of loopback detection on ports with this command.

**Example:** Display the state of loopback detection on port 4.

```
Switch(config)#show loopback-detection interface Ethernet 1/0/4
```

loopback detection config and state information in the switch!

PortName	Loopback Detection	Control Mode	Is Controlled
Ethernet1/4	Enable	Shutdown	No

# Chapter 4 Commands for ULDP

## 4.1 debug uldp

**Command:** `debug uldp (hello | probe | echo | unidir | all) [receive | send] interface [ethernet] IFNAME`

**no debug uldp (hello | probe | echo | unidir | all) [receive | send] interface [ethernet] IFNAME**

**Function:** Enable the debugging for receiving and sending the specified packets or all ULDP packets on port. After enable the debugging, show the information of the received and sent packets in terminal. The no command disables the debugging.

**Parameters:** hello: packet's type is hello, it's announcement packet, including common announcement packet, RSY and Flush packet

probe: packet's type is probe, it's detection packet

echo: packet's type is echo, it means response of detection packet

unidir: packet's type is unidir, it's announcement packet that discover the single link

all: All ULDP packets

**Command mode:** Admin mode

**Default:** Disable.

**Usage Guide:** With this command, user can check probe packets received by port 1/0/2.

Switch#debug uldp probe receive interface ethernet 1/0/2

## 4.2 debug uldp error

**Command:** `debug uldp error`

**no debug uldp error**

**Function:** Enable the error message debug function, the no form command disable the function.

**Parameter:** None.

**Command Mode:** Admin Mode.

**Default:** Disabled.

**Usage Guide:** Use this command to display the error message.

**Example:** Display the error message.

Switch#debug uldp error

### 4.3 debug uldp event

**Command:** debug uldp event

**no debug uldp event**

**Function:** Enable the message debug function to display the event; the no form command disables this function.

**Parameter:** None.

**Command Mode:** Admin Mode.

**Default:** Disabled.

**Usage Guide:** Use this command to display all kinds of event information.

**Example:** Display event information.

```
Switch#debug uldp event
```

### 4.4 debug uldp fsm interface ethernet

**Command:** debug uldp fsm interface ethernet <IFname>

**no debug uldp fsm interface ethernet <IFname>**

**Function:** To enable debugging information for ULDP for the specified interface. The no form of this command will disable the debugging information.

**Parameters:** <IFname> is the interface name.

**Command Mode:** Admin Configuration Mode.

**Default:** Disabled by default.

**Usage Guide:** This command can be used to display the information about state transitions of the specified interfaces.

**Example:** Print the information about state transitions of interface ethernet 1/0/1.

```
Switch#debug uldp fsm interface ethernet 1/0/1
```

### 4.5 debug uldp interface ethernet

**Command:** debug uldp {hello|probe|echo|unidir|all} [receive|send] interface ethernet <IFname>

**no debug uldp {hello|probe|echo|unidir|all} [receive|send] interface ethernet <IFname>**

**Function:** Enable the debug function of display the packet details. After that, display some kinds of the packet details of terminal interface.

**Parameter:** <IFname>: Name of the interface.

**Command Mode:** Admin Mode.

**Default:** Disabled.

**Usage Guide:** Use this command to display the Hello packet details receiving on the interface Ethernet 1/0/1.

```
Switch#debug uldp hello receive interface Ethernet 1/0/1
```

## 4.6 debug uldp packet

**Command:** `debug uldp packet [receive|send]`

`no debug uldp packet [receive|send]`

**Function:** Enable receives and sends packet debug function, after that. Display the type and interface of the packet which receiving and sending on the client. The no form command disables this function.

**Parameter:** None.

**Command Mode:** Admin Mode.

**Default:** Disabled.

**Usage Guide:** Use this command to display the packet that receiving on each interface.

```
Switch#debug uldp packet receive
```

## 4.7 uldp aggressive-mode

**Command:** `uldp aggressive-mode`

`no uldp aggressive-mode`

**Function:** To configure ULDP to work in aggressive mode. The no form of this command will restore the normal mode.

**Parameters:** None.

**Command Mode:** Global Configuration Mode and Port Configuration Mode.

**Default:** Normal mode.

**Usage Guide:** The ULDP working mode can be configured only if it is enabled globally. When ULDP aggressive mode is enabled globally, all the existing fiber ports will work in aggressive mode. For the copper ports and fiber ports which are available after the configuration is available, aggressive mode should be enabled in port configuration mode.

**Example:** To enable ULDP aggressive mode globally.

```
Switch(config)#uldp aggressive-mode
```

## 4.8 uldp enable

**Command:** `uldp enable`

**Function:** ULDP will be enabled after issuing this command. In global configuration mode, this command will enable ULDP for the global. In port configuration mode, this command will enable ULDP for the port.

**Parameters:** None.

**Command Mode:** Global Configuration Mode and Port Configuration Mode.

**Default:** By default ULDP is not configured.

**Usage Guide:** ULDP can be configured for the ports only if ULDP is enabled globally. If ULDP is enabled globally, it will be effect for all the existing fiber ports. For copper ports and fiber ports which are available after ULDP is enabled, this command should be issued in the port configuration mode to make ULDP be effect.

**Example:** Enable ULDP in global configuration mode.

```
Switch(config)#uldp enable
```

## 4.9 uldap disable

**Command:** uldap disable

**Function:** To disable ULDP configuration through this command.

**Parameters:** None.

**Command Mode:** Global Configuration Mode and Port Configuration Mode.

**Default:** By default ULDP is not configured.

**Usage Guide:** When ULDP is disabled globally, then ULDP in all the ports will be disabled.

**Example:** To disable the ULDP configuration in global configuration mode.

```
Switch(config)#uldp disable
```

## 4.10 uldap hello-interval

**Command:** uldap hello-interval *<integer>*

**no uldap hello-interval**

**Function:** To configure the interval for ULDP to send hello messages. The no form of this command will restore the default interval for the hello messages.

**Parameters:** *<integer>*: The interval for the Hello messages, with its value limited between 5 and 100 seconds, 10 seconds by default.

**Command Mode:** Global Configuration Mode.

**Default:** 10 seconds by default.

**Usage Guide:** Interval for hello messages can be configured only if ULDP is enabled globally, its value limited between 5 and 100 seconds.



**Example:** To configure the interval of Hello messages to be 12 seconds.

```
Switch(config)#uldp hello-interval 12
```

## 4.11 uldp manual-shutdown

**Command:** `uldp manual-shutdown`

**no uldp manual-shutdown**

**Function:** To configure ULDP to work in manual shutdown mode. The no command will restore the automatic mode.

**Parameters:** None.

**Command Mode:** Global Configuration Mode.

**Default:** Auto mode.

**Usage Guide:** This command can be issued only if ULDP has been enabled globally.

**Example:** To enable manual shutdown globally.

```
Switch(config)#uldp manual-shutdown
```

## 4.12 uldp recovery-time

**Command:** `uldp recovery-time<integer>`

**no uldp recovery-time**

**Function:** To configure the interval for ULDP recovery timer. The no form of this command will restore the default configuration.

**Parameters:** *<integer>*: the time out value for the ULDP recovery timer. Its value is limited between 30 and 86400 seconds.

**Command Mode:** Global Configuration Mode.

**Default:** 0 is set by default which means the recovery is disabled.

**Usage Guide:** If an interface is shutdown by ULDP, and the recovery timer times out, the interface will be reset automatically. If the recovery timer is set to 0, the interface will not be reset.

**Example:** To set the recovery timer to be 600 seconds.

```
Switch(config)#uldp recovery-time 600
```

## 4.13 uldp reset

**Command:** `uldp reset`

**Function:** To reset the port when ULDP is shutdown.

**Parameters:** None.

**Command Mode:** Globally Configuration Mode and Port Configuration Mode.

**Default:** None.

**Usage Guide:** This command can only be effect only if the specified interface is disabled by ULDP.

**Example:** To reset all the port which are disabled by ULDP.

```
Switch(config)#uldp reset
```

## 4.14 show uldp

**Command:** `show uldp [interface ethernet<interface-name>]`

**Function:** To show the global ULDP configuration and status information of interface. If <interface-name> is specified, ULDP configuration and status about the specified interface as well as its neighbors' will be displayed.

**Parameters:** <interface-name> is the interface name.

**Command Mode:** Admin and Configuration Mode.

**Default:** None.

**Usage Guide:** If no parameters are appended, the global ULDP information will be displayed. If the interface name is specified, information about the interface and its neighbors will be displayed along with the global information.

**Example:** To display the global ULDP information.

```
Switch(config)#show uldp
```

# Chapter 5 Commands for LLDP Function

## 5.1 clear lldp remote-table

**Command:** clear lldp remote-table

**Function:** Clear the Remote-table on the port.

**Parameters:** None.

**Default:** Do not clear the entries.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** Clear the Remote table entries on this port.

**Example:** Clear the Remote table entries on this port.

```
Switch(Config-If-Ethernet 1/0/1)# clear lldp remote-table
```

## 5.2 debug lldp

**Command:** debug lldp

no debug lldp

**Function:** Enable the debug information of LLDP function, the no operation of this command will disable the debug information of LLDP function.

**Parameters:** None.

**Default:** Disable the debug information of LLDP function.

**Command Mode:** Admin Mode.

**Usage Guide:** When the debug switch is enabled, users can check the receiving and sending of packets and other information.

**Example:** Enable the debug switch of LLDP function on the switch.

```
Switch#debug lldp
```

## 5.3 debug lldp packets

**Command:** debug lldp packets interface ethernet <IFNAME>

no debug lldp packets interface ethernet <IFNAME>

**Function:** Display the message-receiving and message-sending information of LLDP on the port; the no operation of this command will disable the debug information switch.

**Parameters:** None.

**Default:** Disable the debug information on the port.

**Command Mode:** Admin Mode.

**Usage Guide:** When the debug switch is enabled, users can check the receiving and sending of packets and other information on the port.

**Example:** Enable the debug switch of LLDP function on the switch.

```
Switch#debug lldp packets interface ethernet 1/0/1
```

```
%Jan 01 00:02:40 2006 LLDP-PDU-TX   PORT= ethernet 1/0/1
```

## 5.4 lldp enable

**Command:** lldp enable

lldp disable

**Function:** Globally enable LLDP function; **disable** command globally disables LLDP function.

**Parameters:** None.

**Default:** Disable LLDP function.

**Command Mode:** Global Mode.

**Usage Guide:** If LLDP function is globally enabled, it will be enabled on every port.

**Example:** Enable LLDP function on the switch.

```
Switch(config)#lldp enable
```

## 5.5 lldp enable (Port)

**Command:** lldp enable

lldp disable

**Function:** Enable the LLDP function module of ports in port configuration mode; **disable** command will disable the LLDP function module of port.

**Parameters:** None.

**Default:** the LLDP function module of ports is enabled by default in port configuration mode.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** When LLDP is globally enabled, it will be enabled on every port, the switch on a port is used to disable this function when it is unnecessary on the port.

**Example:** Disable LLDP function of port on the port ethernet 1/0/5 of the switch.

```
Switch(config)#in ethernet 1/0/5
```

```
Switch(Config-If-Ethernet1/0/5)#lldp disable
```

## 5.6 Ildp mode

**Command:** `lldp mode <send / receive / both / disable>`

**Function:** Configure the operating state of LLDP function of the port.

**Parameters:** send: Configure the LLDP function as only being able to send messages.

receive: Configure the LLDP function as only being able to receive messages.

both: Configure the LLDP function as being able to both send and receive messages.

disable: Configure the LLDP function as not being able to send or receive messages.

**Default:** The operating state of the port is “both”.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** Choose the operating state of the Ildp Agent on the port.

**Example:** Configure the state of port ethernet 1/0/5 of the switch as “receive”.

```
Switch(config)#in ethernet 1/0/5
```

```
Switch(Config-If-Ethernet1/0/5)#lldp mode receive
```

## 5.7 Ildp msgTxHold

**Command:** `lldp msgTxHold <value>`

`no lldp msgTxHold`

**Function:** Set the multiplier value of the aging time carried by update messages sent by the all ports with LLDP function enabled, the value ranges from 2 to 10.

**Parameters:** `<value>` is the aging time multiplier, ranging from 2 to 10.

**Default:** the value of the multiplier is 4 by default.

**Command Mode:** Global Mode.

**Usage Guide:** After configuring the multiplier, the aging time is defined as the product of the multiplier and the interval of sending messages, and its maximum value is 65535 seconds.

**Example:** Set the value of the aging time multiplier as 6.

```
Switch(config)#lldp msgTxHold 6
```

## 5.8 Ildp neighbors max-num

**Command:** `lldp neighbors max-num <value>`

`no lldp neighbors max-num`

**Function:** Set the maximum number of entries can be stored in Remote MIB.

**Parameters:** *<value>* is the configured number of entries, ranging from 5 to 500.

**Default:** The maximum number of entries can be stored in Remote MIB is 100.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** The maximum number of entries can be stored in Remote MIB.

**Example:** Set the Remote as 200 on port ethernet 1/0/5 of the switch.

```
Switch(config)#in ethernet 1/0/5
```

```
Switch(Config-If-Ethernet1/0/5)#lldp neighbors max-num 200
```

## 5.9 lldp notification interval

**Command:** `lldp notification interval <seconds>`

`no lldp notification interval`

**Function:** When the time interval ends, the system is set to check whether the Remote Table has been changed. If it has, the system will send Trap to the SNMP management end.

**Parameters:** *<seconds>* is the time interval, ranging from 5 to 3600 seconds.

**Default:** The time interval is 5 seconds.

**Command Mode:** Global Mode.

**Usage Guide:** After configuring the notification time interval, a “trap” message will be sent at the end of this time interval whenever the Remote Table changes.

**Example:** Set the time interval of sending Trap messages as 20 seconds.

```
Switch(config)#lldp notification interval 20
```

## 5.10 lldp tooManyNeighbors

**Command:** `lldp tooManyNeighbors {discard | delete}`

**Function:** Set which operation will be done when the Remote Table is full.

**Parameters:** discard: discard the current message.

delete: Delete the message with the least TTL in the Remoter Table.

**Default:** Discard.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** When the Remote MIB is full, Discard means to discard the received message; Delete means to the message with the least TTL in the Remoter Table.

**Example:** Set port ethernet 1/0/5 of the switch as delete.

```
Switch(config)#in ethernet 1/0/5
```

```
Switch(Config-If-Ethernet1/0/5)#lldp tooManyNeighbors delete
```

## 5.11 Ildp transmit delay

**Command:** `lldp transmit delay <seconds>`

`no lldp transmit delay`

**Function:** Since local information might change frequently because of the variability of the network environment, there could be many update messages sent in a short time. So a delay is required to guarantee an accurate statistics of local information.

When transmit delay is the default value and tx-interval is configured via some commands, transmit delay will become one fourth of the latter, instead of the default 2.

**Parameters:** `<seconds>` is the time interval, ranging from 1 to 8192 seconds.

**Default:** The interval is 2 seconds by default.

**Command Mode:** Global Mode.

**Usage Guide:** When the messages are being sent continuously, a sending delay is set to prevent the Remote information from being updated repeatedly due to sending messages simultaneously.

**Example:** Set the delay of sending messages as 3 seconds.

```
Switch(config)#lldp transmit delay 3
```

## 5.12 Ildp transmit optional tlv

**Command:** `lldp transmit optional tlv [portDesc] [sysName] [sysDesc] [sysCap]`

`no lldp transmit optional tlv`

**Function:** Configure the type of optional TLV of the port.

**Parameters:** `portDesc`: the description of the port; `sysName`: the system name;

`sysDesc`: The description of the system; `sysCap`: the capability of the system.

**Default:** The messages carry no optional TLV by default.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** When configuring the optional TLV, each TLV can only appear once in a message, `portDesc` optional TLV represents the name of local port; `sysName` optional TLV represents the name of local system; `sysDesc` optional TLV represents the description of local system; `sysCap` optional TLV represents the capability of local system.

**Example:** Configure that port ethernet 1/0/5 of the switch carries portDesc and sysCap TLV.

```
Switch(config)#in ethernet 1/0/5
```

```
Switch(Config-If-Ethernet1/0/5)# lldp transmit optional tlv portDesc sysCap
```

## 5.13 Ildp trap

**Command:** `lldp trap <enable / disable>`

**Function:** **enable:** configure to enable the Trap function on the specified port; **disable:** configure to disable the Trap function on the specified port.

**Parameters:** None.

**Default:** The Trap function is disabled on the specified port by default.

**Command Mode:** Port Configuration Mode.

**Usage Guide:** The function of sending Trap messages is enabled on the port.

**Example:** Enable the Trap function on port ethernet 1/0/5 of the switch.

```
Switch(config)#in ethernet1/0/5
```

```
Switch(Config-If-Ethernet1/0/5)#lldp trap enable
```

## 5.14 Ildp tx-interval

**Command:** `lldp tx-interval <integer>`

`no lldp tx-interval`

**Function:** Set the interval of sending update messages on all the ports with LLDP function enabled, the value of which ranges from 5 to 32768 seconds and is 30 seconds by default.

**Parameters:** *<integer>* is the interval of sending updating messages, ranging from 5 to 32768 seconds.

**Default:** 30 seconds.

**Command Settings:** Global Mode.

**Usage Guide:** After configuring the interval of sending messages, LLDP messages can only be received after a period as long as configured. The interval should be less than or equal with half of aging time, for a too long interval will cause the state of being aged and reconstruction happen too often; while a too short interval will increase the flow of the network and decrease the bandwidth of the port. The value of the aging time of messages is the product of the multiplier and the interval of sending messages. The maximum aging time is 65535 seconds.

When tx-interval is the default value and transmit delay is configured via some commands, tx-interval will become four times of the latter, instead of the default 40.

**Example:** Set the interval of sending messages as 40 seconds.

```
Switch(config)#lldp tx-interval 40
```



## 5.15 show debugging lldp

**Command:** show debugging lldp

**Function:** Display all ports with lldp debug enabled.

**Parameters:** None.

**Default:** None.

**Command Mode:** Admin and Configuration Mode.

**Usage Guide:** With show debugging lldp, all ports with lldp debug enabled will be displayed.

**Example:** Display all ports with lldp debug enabled.

```
Switch(config)#show debugging lldp
====BEGINNING OF LLDP DEBUG SETTINGS====
debug lldp
debug lldp packets interface Ethernet1/0/1
debug lldp packets interface Ethernet1/0/2
debug lldp packets interface Ethernet1/0/3
debug lldp packets interface Ethernet1/0/4
debug lldp packets interface Ethernet1/0/5
=====END OF DEBUG SETTINGS=====
```

## 5.16 show lldp

**Command:** show lldp

**Function:** Display the configuration information of global LLDP, such as the list of all the ports with LLDP enabled, the interval of sending update messages, the configuration of aging time, the interval needed by the sending module to wait for re-initialization, the interval of sending TRAP, the limitation of the number of the entries in the Remote Table.

**Parameters:** None.

**Default:** Do not display the configuration information of global LLDP.

**Command Mode:** Admin Mode, Global Mode.

**Usage Guide:** Users can check all the configuration information of global LLDP by using "show lldp".

**Example:** Check the configuration information of global LLDP after it is enabled on the switch.

```
Switch(config)#show lldp
-----LLDP GLOBAL INFORMATIONS-----
LLDP has been enabled globally.
```

```
LLDP enabled port : Ethernet1/0/3 Ethernet1/0/4
LLDP interval :30
LLDP txTTL :120
LLDP NotificationInterval :5
LLDP txDelay :2
LLDP-MED FastStart Repeat Count :4
-----END-----
```

## 5.17 show lldp interface ethernet

**Command:** show lldp interface ethernet <IFNAME>

**Function:** Display the configuration information of LLDP on the port, such as: the working state of LLDP Agent.

**Parameters:** <IFNAME>: Interface name.

**Default:** Do not display the configuration information of LLDP on the port.

**Command Mode:** Admin Mode, Global Mode.

**Usage Guide:** Users can check the configuration information of LLDP on the port by using “show lldp interface ethernet XXX”.

**Example:** Check the configuration information of LLDP on the port after LLDP is enabled on the switch.

```
Switch(config)#show lldp interface ethernet 1/0/1
Port name : ethernet 1/0/1
LLDP Agent Adminstatus: Both
LLDP Operation TLV: portDecs sysName sysDesc sysCap
LLDP Trap Status: disable
LLDP maxRemote: 100
LLDP Overflow handle: discard
LLDP interface remote status : Full
```

## 5.18 show lldp neighbors interface ethernet

**Command:** show lldp neighbors interface ethernet < IFNAME >

**Function:** Display the LLDP neighbor information of the port.

**Parameters:** None.

**Default:** Do not display the LLDP neighbor information of the port.

**Command Mode:** Admin Mode, Global Mode.

**Usage Guide:** Users can check the LLDP neighbor information of the port by using “show

lldp neighbors interface ethernet XXX”.

**Example:** Check the LLDP neighbor information of the port after LLDP is enabled on the port.

Switch(config)#show lldp neighbors interface ethernet 1/0/1

## 5.19 show lldp traffic

**Command:** show lldp traffic

**Function:** Display the statistics of LLDP data packets.

**Parameters:** None.

**Default:** Do not display the statistics of LLDP data packets.

**Command Mode:** Admin Mode, Global Mode.

**Usage Guide:** Users can check the statistics of LLDP data packets by using “show lldp traffic”.

**Example:** Check the statistics of LLDP data packets after LLDP is enabled on the switch.

Switch(config)#show lldp traffic

PortName	Ageouts	FramesDiscarded	FramesInErrors	FramesIn	FramesOut	TLVsDiscarded	TLVsUnrecognized
Ethernet1/0/1	0	0	0	0	7	0	0

# Chapter 6 Commands for Port Channel

## 6.1 debug port-channel

**Command:** `debug port-channel <port-group-number> {all | event | fsm | packet | timer}`

`no debug port-channel [<port-group-number>]`

**Function:** Open the debug switch of port-channel.

**Parameters:** `<port-group-number>` is the group number of port channel, ranging from 1~128

**all:** all debug information

**event:** debug event information

**fsm:** debug the state machine

**packet:** debug LACP packet information

**timer:** debug the timer information

**Command mode:** Admin mode.

**Default:** Disable the debugging of port-channel.

**Usage Guide:** Open the debug switch to check the debug information of port-channel.

**Notice:** it can create 16 port group at most.

**Example:**

(1)debug the state machine for port-group 1.

```
Switch#debug port-channel 1 fsm
```

(2) debug LACP packet information for port-group 2.

```
Switch#debug port-channel 2 packet
```

(3) debug all for port-group 1.

```
Switch#debug port-channel 1 all
```

## 6.2 interface port-channel

**Command:** `interface port-channel <port-channel-number>`

**Function:** Enters the port channel configuration mode

**Command mode:** Global Mode

**Usage Guide:** On entering aggregated port mode, configuration to GVRP or spanning tree modules will apply to aggregated ports; if the aggregated port does not exist (i.e., ports have not been aggregated), an error message will be displayed and configuration will be saved and will be restored until the ports are aggregated. Note such restoration will

be performed only once, if an aggregated group is ungrouped and aggregated again, the initial user configuration will not be restored. If it is configuration for modules, such as shutdown configuration, then the configuration to current port will apply to all member ports in the corresponding port group.

**Example:** Entering configuration mode for port-channel 1.

```
Switch(config)#interface port-channel 1
Switch(Config-If-Port-Channel1)#
```

## 6.3 lacp port-priority

**Command:** `lacp port-priority <port-priority>`  
`no lacp port-priority`

**Function:** Set the port priority of LACP protocol.

**Parameters:** *<port-priority>*: the port priority of LACP protocol, the range from 0 to 65535.

**Command mode:** Port Mode.

**Default:** The default priority is 32768 by system.

**Usage Guide:** Use this command to modify the port priority of LACP protocol, the no command restores the default value.

**Example:** Set the port priority of LACP protocol.

```
Switch(Config-If-Ethernet1/0/1)# lacp port-priority 30000
```

## 6.4 lacp system-priority

**Command:** `lacp system-priority <system-priority>`  
`no lacp system-priority`

**Function:** Set the system priority of LACP protocol.

**Parameters:** *<system-priority>*: The system priority of LACP protocol, ranging from 0 to 65535.

**Command mode:** Global Mode

**Default:** The default priority is 32768.

**Usage Guide:** Use this command to modify the system priority of LACP protocol, the no command restores the default value.

**Example:** Set the system priority of LACP protocol.

```
Switch(config)#lacp system-priority 30000
```

## 6.5 lacp timeout

**Command:** lacp timeout {short | long}  
no lacp timeout

**Function:** Set the timeout mode of LACP protocol.

**Parameters:** The timeout mode includes long and short.

**Command mode:** Port Mode

**Default:** Long.

**Usage Guide:** Set the timeout mode of LACP protocol.

**Example:** Set the timeout mode as short in LACP protocol.

```
Switch(Config-If-Ethernet1/0/1)#lacp timeout short
```

## 6.6 load-balance

**Command:** load-balance {src-mac | dst-mac | dst-src-mac | src-ip | dst-ip | dst-src-ip  
| ingress-port | dst-src-mac-ip}  
no load-balance

**Function:** Set load-balance mode for port-group, the no command return it to load-balance mode.

**Parameter:** src-mac performs load-balance according to the source MAC

dst-mac performs load-balance according to the destination MAC

dst-src-mac performs load-balance according to the source and destination  
MAC

src-ip performs load-balance according to the source IP

dst-ip performs load-balance according to the destination IP

dst-src-ip performs load-balance according to the destination and source IP

dst-src-mac-ip: performs load-balance according to the destination and  
source mac and destination, source IP

ingress-port: performs load-balance according to the port of receive flow.

**Command mode:** Global mode.

**Default:** Perform load-balance according to the source MAC.

**Usage Guide:** Use port-channel to implement load-balance, user can configure the load-balance mode according to the requirements. If the specific load-balance mode of the command line is different with the current load-balance mode of port-group, then modify the load-balance of port-group as the specific load-balance of command line; otherwise return a message to notice that the current mode is already configured.

**Example:** Set load-balance mode of port-group.

```
Switch(config)#interface port-channel 1
Switch(Config-If-Port-Channel1)#load-balance src-mac
```

## 6.7 port-group

**Command:** `port-group <port-group-number>`

`no port-group <port-group-number>`

**Function:** Creates a port group. The no command deletes that group.

**Parameters:** `<port-group-number>` is the group number of a port channel from 1~128.

**Default:** There is no port-group.

**Command mode:** Global Mode

**Notice:** it can create 16 port group at most

**Example:** Creating a port group.

```
Switch(config)# port-group 1
```

Delete a port group.

```
Switch(config)#no port-group 1
```

## 6.8 port-group mode

**Command:** `port-group <port-group-number> mode {active | passive | on}`

`no port-group`

**Function:** Add a physical port to port channel, the no operation removes specified port from the port channel.

**Parameters:** `<port-group-number>` is the group number of port channel, from 1~128; **active** enables LACP on the port and sets it in Active mode; **passive** enables LACP on the port and sets it in Passive mode; **on** forces the port to join a port channel without enabling LACP.

**Command mode:** Port Mode.

**Default:** Switch ports do not belong to a port channel by default; LACP not enabled by default.

**Usage Guide:** If the specified port group does not exist, then print a error message. All ports in a port group must be added in the same mode, i.e., all ports use the mode used by the first port added. Adding a port in “on” mode is a “forced” action, which means the local end switch port aggregation does not rely on the information of the other end, port aggregation will succeed as long as all ports have consistent VLAN information. Adding a port in “active” or “passive” mode enables LACP. Ports of at least one end must be added in “active” mode, if ports of both ends are added in “passive” mode, the ports will never

aggregate.

**Notice:** it can create 16 port group at most.

**Example:** Under the Port Mode of Ethernet1/0/1, add current port to “port-group 1” in “active” mode.

```
Switch(Config-If-Ethernet1/0/1)#port-group 1 mode active
```

## 6.9 show port-group

**Command:** show port-group [*<port-group-number>*] {brief | detail |}

**Function:** Display the specified group number or the configuration information of all port-channel which have been configured.

**Parameters:** *<port-group-number>* is the group number of port channel to be displayed, from 1~128; **brief** displays summary information; **detail** displays detailed information.

**Command mode:** All Configuration Mode.

**Usage Guide:** If the user does not input port-group-number, that means the information of all the existent port-group are showed; if the port channel corresponds to port-group-number parameter and is not exist, then print a error message, otherwise display the current port-channel information of the specified group number.

**Notice:** it can create 16 port group at most.

**Example:** 1. Display summary information for port-group 1.

```
Switch#show port-group brief
```

ID: port group number; Mode: port group mode such as on active or passive;

Ports: different types of port number of a port group,

the first is selected ports number, the second is standby ports number, and

the third is unselected ports number.

ID	Mode	Partner ID	Ports	Load-balance
1	active	0x8000,00-12-cf-4d-e1-a1	8,1,1	dst-src-mac
10	passive	0x8000,00-12-cf-4d-e1-b2	8,2,0	dst-src-ip
20	on		8,0,0	src-ip

2. Display the detailed information of port-group 1.

```
Switch#show port-group 1 detail
```

Flags: A -- LACP\_Activity, B -- LACP\_timeout, C -- Aggregation,  
 D -- Synchronization, E -- Collecting, F -- Distributing,  
 G -- Defaulted, H -- Expired



Port-group number: 1, Mode: active, Load-balance: dst-src-mac

Port-group detail information:

System ID: 0x8000,00-03-0f-0c-16-6d

Local:

Port	Status	Priority	Oper-Key	Flag
Ethernet1/0/1	Selected	32768	1	{ACDEF}
Ethernet1/0/2	Selected	32768	1	{ACDEF}
Ethernet1/0/3	Selected	32768	1	{ACDEF}
Ethernet1/0/4	Selected	32768	1	{ACDEF}
Ethernet1/0/5	Selected	32768	1	{ACDEF}
Ethernet1/0/6	Selected	32768	1	{ACDEF}
Ethernet1/0/7	Selected	32768	1	{ACDEF}
Ethernet1/0/8	Selected	32768	1	{ACDEF}
Ethernet1/0/20	Unselected	32768	1	{ACG}
Ethernet1/0/23	Standby	32768	1	{AC}

Remote:

Actor	Partner	Priority	Oper-Key	SystemID	Flag
Ethernet1/0/1	1	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/2	2	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/3	3	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/4	4	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/5	5	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/6	6	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/7	7	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/8	8	32768	1	0x8000,00-03-0f-01-02-04	{CDEF}
Ethernet1/0/23	23	32768	1	0x8000,00-03-0f-01-02-04	{C}

Switch#



# Chapter 7 Commands for MTU

## 7.1 mtu

**Command:** mtu [<mtu-value>]

**no mtu**

**Function:** Configure the MTU size of JUMBO frame, enable the jumbo receiving/sending function. The no command restores to the normal frame receiving function.

**Parameter:** mtu-value: the MTU value of frames that can be received, in byte, ranging from <1500-12270>. The corresponding frame size is <1518/1522-12288/12292>. Without setting is parameter, the allowed max frame size is 12288/12292.

**Default:** MTU function not enabled by default.

**Command Mode:** Global Mode

**Usage Guide:** Set switch of both ends mtu necessarily, or mtu frame will be dropped at the switch has not be set.

**Example:** Enable the mtu function of the switch.

```
Switch(config)#mtu
```

# Chapter 8 Commands for EFM OAM

## 8.1 clear ethernet-oam

**Command:** clear ethernet-oam [interface {ethernet |} <IFNAME>]

**Function:** Clear the statistic information of packets and link event on specific or all ports for OAM.

**Parameters:** <IFNAME>, the name of the port needs to clear OAM statistic information

**Command Mode:** Admin mode

**Default:** N/A.

**Usage Guide:** N/A.

**Example:** Clear the statistic information of OAM packets and link event on all ports.

```
Switch(config)#clear ethernet-oam
```

## 8.2 debug ethernet-oam error

**Command:** debug ethernet-oam error [interface {ethernet |} <IFNAME>]

**no debug ethernet-oam error [interface {ethernet |} <IFNAME>]**

**Function:** Enable the debugging of OAM error information, no command disables it.

**Parameters:** <IFNAME>: name of the port that the debugging will be enabled or disabled.

**Command Mode:** Admin mode

**Default:** Disable.

**Usage Guide:** N/A.

**Example:** Enable the debugging of OAM error information for ethernet1/0/1.

```
Switch#debug ethernet-oam error interface ethernet1/0/1
```

## 8.3 debug ethernet-oam fsm

**Command:** debug ethernet-oam fsm {all | Discovery | Transmit} [interface {ethernet |} <IFNAME>]

**no debug ethernet-oam fsm {all | Discovery | Transmit} [interface {ethernet |} <IFNAME>]**

**Function:** Enable the debugging of OAM state machine, no command disables it.

**Parameters:** <IFNAME>: name of the port that the debugging will be enabled or disabled

**Command Mode:** Admin mode

**Default:** Disable.

**Usage Guide:** N/A.

**Example:** Enable the debugging of Discovery state machine for ethernet1/0/1.

```
Switch#debug ethernet-oam fsm Discovery interface ethernet1/0/1.
```

## 8.4 debug ethernet-oam packet

**Command:** debug ethernet-oam packet [detail] {all | send | receive} [interface {ethernet | } <IFNAME>]

no debug ethernet-oam packet [detail] {all | send | receive} interface {ethernet | } <IFNAME>

**Function:** Enable the debugging of packets received or sent by OAM, no command disables the debugging.

**Parameters:** <IFNAME>: name of the port that the debugging will be enabled or disabled

**Command Mode:** Admin mode

**Default:** Disable.

**Usage Guide:** N/A.

**Example:** Enable the debugging of packets received or sent for ethernet1/0/1.

```
Switch#debug ethernet-oam packet detail all interface ethernet1/0/1
```

## 8.5 debug ethernet-oam timer

**Command:** debug ethernet-oam timer {all | pdu\_timer | local\_lost\_link\_timer} [interface {ethernet | } <IFNAME>]

no debug ethernet-oam timer {all | pdu\_timer | local\_lost\_link\_timer} [interface {ethernet | } <IFNAME>]

**Function:** Enable the debugging of refreshing information for specific or all timers, no this command disables the debugging.

**Parameters:** <IFNAME>: name of the port that the debugging will be enabled or disabled

**Command Mode:** Admin mode

**Default:** Disable.

**Usage Guide:** N/A.

**Example:** Enable the debugging of refreshing information for all timers of ethernet1/0/1.

```
Switch#debug ethernet-oam timer all interface ethernet1/0/1
```

## 8.6 ethernet-oam

**Command:** ethernet-oam

**no ethernet-oam**

**Function:** Enable ethernet-oam of ports, no command disables ethernet-oam of ports.

**Parameters:** None.

**Command Mode:** Port mode

**Default:** Disable.

**Usage Guide:** N/A.

**Example:** Enable ethernet-oam of Ethernet 1/0/4.

```
Switch(config)#interface ethernet 1/0/4
```

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam
```

## 8.7 ethernet-oam errored-frame threshold high

**Command:** ethernet-oam errored-frame threshold high {<high-frames> | none}

**no ethernet-oam errored-frame threshold high**

**Function:** Configure the high threshold of errored frame event, no command restores the default value.

**Parameters:** <high-frames>, the high detection threshold of errored frame event, ranging from 2 to 4294967295.

**none**, cancel the high threshold configuration.

**Command Mode:** Port mode

**Default:** none.

**Usage Guide:** During the specific detection period, serious link event is induced if the number of errored frame is larger than or equal to the high threshold and the device notifies the peer by sending Information OAMPDU of which the value of Link Fault flag in Flags field is 1. Note that the high threshold can not be less than the low threshold.

**Example:** Configure the high threshold of errored frame event on Ethernet 1/0/4 to be 3000.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame threshold high 3000
```

## 8.8 ethernet-oam errored-frame threshold low

**Command:** ethernet-oam errored-frame threshold low <low-frames>

**no ethernet-oam errored-frame threshold low**

**Function:** Configure the low threshold of errored frame event, no command restores the

default value.

**Parameters:** *<low-frames>*, the low detection threshold of errored frame event, ranging from 1 to 4294967295.

**Command Mode:** Port mode

**Default:** 1.

**Usage Guide:** During the specific detection period, errored frame event is induced if the number of errored frame is larger than or equal to the low threshold and the device notifies the peer by sending event notification OAMPDU. Note that the low threshold can not be larger than the high threshold.

**Example:** Configure the low threshold of errored frame event on Ethernet 1/0/4 to 100.  
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame threshold low 100

## 8.9 ethernet-oam errored-frame window

**Command:** ethernet-oam errored-frame window *<seconds>*  
no ethernet-oam errored-frame window

**Function:** Configure the detection period of errored frame event, no command restores the default value.

**Parameters:** *<seconds>* is the time for counting the specified frame number, its range from 5 to 300, unit is 200ms.

**Command Mode:** Port mode

**Default:** 5.

**Usage Guide:** Detect the errored frame number of the port after the time of specific detection period. If the number of errored frame is larger than or equal to the threshold, bring the corresponding event and notify the peer through OAMPDU.

**Example:** Configure the detection period of errored frame event on port1/0/4 to be 20s.  
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame window 100

## 8.10 ethernet-oam errored-frame-period threshold high

**Command:** ethernet-oam errored-frame-period threshold high {*<high-frames>* | none}

no ethernet-oam errored-frame-period threshold high

**Function:** Configure the high threshold of errored frame period event, no command restores the default value.

**Parameters:** *<high-frames>*, the high detection threshold of errored frame period event, ranging from 2 to 4294967295.

**none**, cancel the high threshold configuration.

**Command Mode:** Port mode

**Default:** none.

**Usage Guide:** During the specific detection period, serious link event is induced if the number of errored frame is larger than or equal to the high threshold and the device notifies the peer by sending Information OAMPDU of which the value of Link Fault flag in Flags field is 1. Note that the high threshold can not be less than the low threshold.

**Example:** Configure the high threshold of errored frame period event on port 1/0/4 to be 3000.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame-period threshold high 3000
```

## 8.11 ethernet-oam errored-frame-period threshold low

**Command:** ethernet-oam errored-frame-period threshold low *<low-frames>*

**no ethernet-oam errored-frame-period threshold low**

**Function:** Configure the low threshold of errored frame period event, no command restores the default value.

**Parameters:** *<low-frames>*, the low detection threshold of errored frame period event, ranging from 1 to 4294967295 frames.

**Command Mode:** Port mode

**Default:** 1.

**Usage Guide:** During the specific detection period, errored frame period event is induced if the number of errored frame is larger than or equal to the low threshold and the device notifies the peer by event notification OAMPDU. Note that the low threshold should not be larger than the high threshold.

**Example:** Configure the low threshold of errored frame period event on port 1/0/4 to be 100.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame-period threshold low 100
```

## 8.12 ethernet-oam errored-frame-period window

**Command:** ethernet-oam errored-frame-period window *<seconds>*

**no ethernet-oam errored-frame-period window**

**Function:** Configure the detection period of errored frame period event, no command restores the default value.

**Parameters:** *<seconds>* is the time for counting the specified frame number, its range from 1 to 300, unit is 200ms.



**Command Mode:** Port mode

**Default:** 5.

**Usage Guide:** Detect errored frame of the port after the time of specific detection period. If the number of errored frame is larger than or equal to the threshold, corresponding event is induced and the device notifies the peer through OAMPDU. When sending the packets, the maximum number of frames is filled as the value of window in errored frame period event. The conversion rule is maximum number of frames= interface bandwidth × detection period of errored frame period event(s) ÷ (64 × 8), of which the detection period is the number of seconds in window of the configuration.

**Example:** Configure the detection period of errored frame period event on port 1/0/4 to be 10s.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame-period window 50
```

## 8.13 ethernet-oam errored-frame-seconds threshold

### high

**Command:** ethernet-oam errored-frame-seconds threshold high {<high-seconds> | none}

**no ethernet-oam errored-frame-seconds threshold high**

**Function:** Configure the high threshold of errored frame seconds event, no command restores the default value.

**Parameters:** <high-seconds>, the high detection threshold of errored frame seconds event, ranging from 2 to 65535 seconds.

**none**, cancel the high threshold configuration.

**Command Mode:** Port mode

**Default:** none.

**Usage Guide:** During the specific detection period, serious link event is induced if the number of errored frame seconds is larger than or equal to the high threshold and the device notifies the peer by sending Information OAMPDU of which the value of Link Fault flag in Flags field is 1. Note that the high threshold should not be less than the low threshold. The definition of errored frame seconds is the second in which errored frame is received.

**Example:** Configure the high threshold of errored frame seconds event on port 1/0/4 to be 3000.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame-seconds threshold high 3000
```

## 8.14 ethernet-oam errored-frame-seconds threshold

### low

**Command:** ethernet-oam errored-frame-seconds threshold low <low-seconds>  
no ethernet-oam errored-frame-seconds threshold low

**Function:** Configure the low threshold of errored frame seconds event, no command restores the default value.

**Parameters:** <low-seconds>, the low detection threshold of errored frame seconds event, ranging from 1 to 65535 seconds.

**Command Mode:** Port mode

**Default:** 1.

**Usage Guide:** During the specific detection period, errored frame seconds event is induced if the number of errored frame seconds is larger than or equal to the low threshold and the device notifies the peer by sending event notification OAMPDU. Note that the low threshold should not be larger than the high threshold. The definition of errored frame seconds is the second in which errored frame is received.

**Example:** Configure the low threshold of errored frame seconds event on port 1/0/4 to be 100.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame-seconds threshold low 100
```

## 8.15 ethernet-oam errored-frame-seconds window

**Command:** ethernet-oam errored-frame-seconds window <seconds>  
no ethernet-oam errored-frame-seconds window

**Function:** Configure the detection period of errored frame seconds event, no command restores the default value.

**Parameters:** <seconds> is the time for counting the specified frame number, its range from 50 to 450, unit is 200ms.

**Command Mode:** Port mode

**Default:** 300.

**Usage Guide:** Detect errored frame seconds of the port after the time of specific detection period. If the number of errored frame seconds is larger than or equal to the threshold, corresponding event is induced and the device notified the peer through OAMPDU.

**Example:** Configure the detection period of errored frame seconds event on port 1/0/4 to be 120s.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-frame-seconds window 600
```

## 8.16 ethernet-oam errored-symbol-period threshold

### high

**Command:** ethernet-oam errored-symbol-period threshold high {<high-symbols> | none}

**no ethernet-oam errored-symbol-period threshold high**

**Function:** Configure the high threshold of errored symbol event, no command restores the default value.

**Parameters:** <high-symbols>, the high detection threshold of errored symbol event, ranging from 2 to 18446744073709551615 symbols.

**none**, cancel the high threshold configuration.

**Command Mode:** Port mode

**Default:** none.

**Usage Guide:** During the specific detection period, serious link event is induced if the number of errored symbols is larger than or equal to the high threshold and the device notifies the peer by sending Information OAMPDU of which the value of Link Fault flag in Flags field is 1. Note that the high threshold should not be less than the low threshold.

**Example:** Set the high threshold of errored symbol event on port 1/0/4 to none.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-symbol-period threshold high none
```

## 8.17 ethernet-oam errored-symbol-period threshold

### low

**Command:** ethernet-oam errored-symbol-period threshold low <low-symbols>

**no ethernet-oam errored-symbol-period threshold low**

**Function:** Configure the low threshold of errored symbol event, no command restores the default value.

**Parameters:** <low-symbols>, the low threshold of errored symbol event, ranging from 1 to 18446744073709551615 symbols.

**none**, cancel the high threshold configuration.

**Command Mode:** Port mode

**Default:** 1.

**Usage Guide:** During the specific detection period, errored symbol event is induced if the number of errored symbols is larger than or equal to the low threshold and the device notifies the peer by sending event notification OAMPDU. Note that the low threshold should not be larger than the high threshold.

**Example:** Set the low threshold of errored symbol event on port 1/0/4 to be 5.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-symbol-period threshold low 5
```

## 8.18 ethernet-oam errored-symbol-period window

**Command:** ethernet-oam errored-symbol-period window <seconds>

**no ethernet-oam errored-symbol-period window**

**Function:** Configure the detection period of errored symbol event, no command restores the default value.

**Parameters:** <seconds> is the time for counting the specified frame number, its range from 5 to 300, unit is 200ms.

**Command Mode:** Port mode

**Default:** 5.

**Usage Guide:** Detect errored symbols of the port after the time of specific detection period. If the number of errored symbols is larger than or equal to the threshold, corresponding event is induced and the device notified the peer through OAMPDU.

**Example:** Set the detection period of errored symbol event on port 1/0/4 to be 2s.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam errored-symbol-period window 10
```

## 8.19 ethernet-oam link-monitor

**Command:** ethernet-oam link-monitor

**no ethernet-oam link-monitor**

**Function:** Enable link monitor, no command disables the function.

**Parameters:** None.

**Command Mode:** Port mode

**Default:** Enable.

**Usage Guide:** Enable OAM to monitor local link errors. Generally link monitor is enabled when enabling OAM function of the port. When OAM link monitor is disabled, although local link error is not monitored, Event information OAMPDU from the peer is still normally received and processed.

**Example:** Enable the link monitor of port 1/0/4.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam link-monitor
```

## 8.20 ethernet-oam mode

**Command:** ethernet-oam mode {active | passive}

**no ethernet-oam mode**

**Function:** Configure the mode of OAM function, no command restores the default value.

**Parameters:** **active**, active mode

**passive**, passive mode

**Command Mode:** Port mode

**Default:** active mode.

**Usage Guide:** At least one of the two connected OAM entities should be configured to active mode. Once OAM is enabled, the working mode of OAM cannot be changed and you need to disable OAM function if you have to change the working mode.

**Example:** Set the mode of OAM function on ethernet 1/0/4 to passive mode.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam mode passive
```

## 8.21 ethernet-oam period

**Command:** ethernet-oam period <seconds>

**no ethernet-oam mode**

**Function:** Configure the transmission period of Information OAMPDU, no command restores the default value.

**Parameters:** <seconds>, sending period, ranging from 1 to 2 seconds.

**Command Mode:** Port mode

**Default:** 1s.

**Usage Guide:** Use this command to configure the transmission interval of Information OAMPDU which keep OAM connection normally.

**Example:** Set the transmission interval of Information OAMPDU for ethernet 1/0/4 to be 2s.

```
Switch(Config-If-Ethernet1/0/4)# ethernet-oam period 2
```

## 8.22 ethernet-oam remote-failure

**Command:** ethernet-oam remote-failure

**no ethernet-oam remote-failure**

**Function:** Enable remote failure indication of OAM, no command disables the function.

**Parameters:** None.

**Command Mode:** Port mode

**Default:** Enable.

**Usage Guide:** With remote failure indication is enabled, if critical-event or link fault event is occurred locally, it will notify the peer by sending Information OAMPDU, log the fault

information and send SNMP trap warning. When the remote failure indication is disabled, although local critical-event or link fault event is not monitored, failure indication information from the peer is still normally received and processed.

**Example:** Enable remote failure indication of ethernet 1/0/4.  
Switch(Config-If-Ethernet1/0/4)#ethernet-oam remote-failure

## 8.23 ethernet-oam remote-loopback

**Command:** ethernet-oam remote-loopback

**no ethernet-oam remote-loopback**

**Function:** Local OAM send remote-loopback request to enable remote to come in OAM loopback mode; the no command cancel remote-loopback.

**Parameters:** None.

**Command Mode:** port mode.

**Default:** Disable.

**Usage Guide:** Only OAM can send remote loopback request in auto mode, the OAM work in passive mode can not send remote loopback; when remote OAM working in loopback mode, all packets except OAM PDU packets will back local port according to the same route (Notice: during OAM loopback, it can not communicate), administrator can check the link delay of loopback, shake and throughput capacity. It can do loopback configuration after create OAM link, if OAM link is broken during loopback, the loopback will be cancel automatically. The command mutex with ethernet-oam remote-loopback supported.

**Example:** Enable the remote OAM of port 1/0/4 to remote loopback mode.

Switch(Config-If-Ethernet1/0/4)#ethernet-oam remote-loopback

Normal forwarding will be suspended during the remote-loopback, are you sure to start remote-loopback? [Y/N]

## 8.24 ethernet-oam remote-loopback supported

**Command:** ethernet-oam remote-loopback supported

**no ethernet-oam remote-loopback supported**

**Function:** Enable the support of port OAM loopback, the no command disable loopback support.

**Parameters:** None.

**Command Mode:** Port mode.

**Default:** Disable.

**Usage Guide:** The port that only enable loopback support function can receive OAM loopback request and in loopback mode. So when enable remote and in OAM loopback, please ensure remote configured loopback support. The command mutex with ethernet-oam remote-loopback.

**Example:** Enable OAM loopback support function of ethernet 1/0/4.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam remote-loopback supported
```

## 8.25 ethernet-oam timeout

**Command:** ethernet-oam timeout <seconds>

**no ethernet-oam timeout**

**Function:** Configure the timeout of OAM connection, no command restores the default value.

**Parameters:** <seconds>, the timeout ranging from 5 to 10 seconds.

**Command Mode:** Port mode

**Default:** 5s.

**Usage Guide:** OAM connection will be disconnected if no OAMPDU is received after specified timeout.

**Example:** Set the timeout of OAM connection for ethernet 1/0/4 to be 6 seconds.

```
Switch(Config-If-Ethernet1/0/4)#ethernet-oam timeout 6
```

## 8.26 show ethernet-oam

**Command:** show ethernet-oam [{local | remote} interface {ethernet |} <IFNAME>]

**Function:** Show Ethernet OAM connection of specified or all ports.

**Parameters:** Overview information of all Ethernet OAM connections will be shown if no parameters is input

**local**, show detailed information of local OAM connection

**remote**, show detailed information of remote OAM connection

**<IFNAME>**, the port that OAM connection information will be shown

**Command Mode:** Admin mode

**Default:** N/A.

**Usage Guide:** N/A.

**Example:** Show overview information of Ethernet OAM connection.

```
Switch#show ethernet-oam
```

Remote-Capability codes: L - Link Monitor, R - Remote Loopback  
 U - Unidirection, V - Variable Retrieval

```

-----
Interface      Local-Mode      Local-Capability      Remote-MAC-Addr      Remote-Mode
Remote-Capability
1/0/1          active          L R                    0003.0f02.2e5d       active                L R
1/0/2          active          L R                    0003.0f19.3a3e       avtive                L R
1/0/4          active          L R                    0003.0f26.480c       passive               L R
1/0/5          active          L R                    0003.0f28.020a       active                L R
    
```

Field	Description
Interface	port with Ethernet OAM enabled
Local-Mode	Working mode of the local port OAM.
Local-Capability	Functions are supported by local port OAM L - Link Monitor, R - Remote Loopback U - Unidirection, V - Variable Retrieval
Remote-MAC-Addr	MAC address of the peer
Remote-Mode	OAM working mode of the peer
Remote-Capability	Functions are supported by OAM of the peer L - Link Monitor, R - Remote Loopback U - Unidirection, V - Variable Retrieval

Show detailed information of local OAM entity for ethernet 1/0/2:

```
Switch#show ethernet-oam local interface ethernet1/0/2
```

Ethernet1/0/2 oam local Information:

```

oam_status=enable
local_mode=active
period=1s
timeout=8s
Loopback Supported=YES
Unidirectional Support=YES
Link Events=YES
Remote Failure=YES
local_pdu=INFO
local_mux_action=FWD
local_par_action=DISCARD
Max_OAMPDU_Size=1518
    
```



-----  
 OAM\_local\_flags\_field:

Link Fault=0      Dying Gasp=0      Critical Events=0  
 -----

Packet statistic:

Packets	Send	Receive
OAMPDU	553	21
Information	552	21
Event Notification	1	0
Loopback Control	0	0

-----

Field	Description
oam_status	Status of Ethernet OAM: enable, OAM is enabled; disable, OAM is not enabled.
local_mode	Working mode of Ethernet OAM: active, the port is set as active mode; passive, the port is set as passive mode.
Period	Transmission period of packets
Timeout	Timeout of connection
local_pdu	The way in which the local end processes Ethernet OAMPDUs: RX_INFO, the port only receives Information OAMPDUs and does not send any Ethernet OAMPDUs. LF_INFO, the port only sends Information OAMPDU packets without Information TLV and with their link error flag bits being set. INFO, the port only sends and receives Information OAMPDU packets. ANY, the port sends and receives any OAMPDU packets.
local_mux_action	Working mode of the local transmitter: FWD, the port can send any packets; DISCARD, the port only sends OAMPDU packets and discards others.
local_par_action	Working mode of the local receiver in the following: FWD, receiving any packets is allowed; DISCARD, only OAMPDU packets is received while others

	are discarded; LB, OAM remote loopback is enabled on the port. In this case, all the packets except OAMPDU packets received are returned to their sources along the ways they come.
Loopback Supported	Whether support remote loopback: YES for support and NO for not.
Unidirectional Support	Whether support unidirectional transmission: YES for support and NO for not.
Link Events	Whether support general link events: YES for support and NO for not.
Remote Failure	Whether support severe link events (remote failure indication): YES for support and NO for not.
Link Fault	Whether occur a Link Fault event: 0 for no and 1 for yes.
Dying Gasp	Whether occur a Dying Gasp event: 0 for no and 1 for yes.
Critical Event	Whether occur a Critical Event: 0 for no and 1 for yes.
Max_OAMPDU_Size	The maximum length of OAMPDU is supported.
OAMPDU	Show the number of the OAMPDU packets sent and received which is the sum of three kinds of packets.
Information	Show the number of the Information OAMPDU packets sent and received
Event Notification	Show the number of the Event Notification OAMPDU packets sent and received
Loopback Control	Show the number of the Loopback Control OAMPDU packets sent and received

Display detailed information of remote OAM entity for Ethernet 1/0/2

Switch#show ethernet-oam remote interface ethernet1/0/2

Ethernet1/0/2 oam remote Information:

Remote\_Mac\_Address=0003.0f19.3a3e

local\_mode=active

-----  
local\_pdu=INFO

local\_mux\_action=FWD

local\_par\_action=DISCARD

Loopback Supported=YES

Unidirectional Support=NO

Link Events=YES

Remote Failure=YES

Max\_OAMPDU\_Size=1518

-----  
 OAM Remote Flags Field:

Link Fault=0      Dying Gasp=0      Critical Event=0

Field	Description
Remote_Mac_Address	MAC address of remote OAM entity
local_mode	Working mode of Ethernet OAM: active, the port is set as active mode; passive, the port is set as passive mode.
local_pdu	The way in which the local end processes Ethernet OAMPDUs: RX_INFO, the port only receives Information OAMPDUs and does not send any Ethernet OAMPDUs. LF_INFO, the port only sends Information OAMPDU packets without Information TLV and with their link error flag bits being set. INFO, the port only sends and receives Information OAMPDU packets. ANY, the port sends and receives any OAMPDU packets.
local_mux_action	Working mode of the local transmitter: FWD, the port can send any packets; DISCARD, the port only sends OAMPDU packets and discards others.
local_par_action	Working mode of the local receiver in the following: FWD, receiving any packets is allowed; DISCARD, only OAMPDU packets is received while others are discarded; LB, OAM remote loopback is enabled on the port. In this case, all the packets except OAMPDU packets received are returned to their sources along the ways they come.
Loopback Supported	Whether support remote loopback: YES for support and NO for not.
Unidirectional Support	Whether support unidirectional transmission: YES for support and NO for not.
Link Events	Whether support general link events: YES for support and NO for not.
Remote Failure	Whether support severe link events: YES for support and NO

	for not.
Max_OAMPDU_Size	The maximum length of OAMPDU is supported.
Link Fault	Whether occur a Link Fault event: 0 for no and 1 for yes.
Dying Gasp	Whether occur a Dying Gasp event: 0 for no and 1 for yes.
Critical Event	Whether occur a Critical Event: 0 for no and 1 for yes.

## 8.27 show ethernet-oam events

**Command:** show ethernet-oam events {local | remote} [interface {ethernet |} <IFNAME>]

**Function:** Shows the statistic information of link events on specified or all ports with OAM enabled, including general link events and severe link events.

**Parameters:** **local**, show the detailed information of the local events;

**remote**, show the detailed information of the remote events;

**<IFNAME>**, the port that the statistic information of OAM link events needs to be shown, the statistic information of OAM link events for all ports will be shown if this parameter is not specified.

**Command Mode:** Admin mode

**Default:** N/A.

**Usage Guide:** N/A.

**Example:** Show the statistic information of link events on Ethernet 1/0/1.

```
Switch#show ethernet-oam events local interface 1/0/1
```

```
ethernet1/0/1 link-events:
```

```
OAM_local_errored-symbol-period-events:
```

```
-----
event time stamp: 3539                errored symbol window(200ms): 5
errored symbol low threshold: 1        errored symbol high threshold: none
errored symbol: 1200120                errored running total: 2302512542
event running total: 232
```

```
OAM_local_errored-frame-period-events:
```

```
-----
event time stamp: 3539                errored frame window(200ms): 50
errored frame low threshold: 1        errored frame high threshold: none
errored frame: 1200120                errored running total: 2302512542
event running total: 52
```

OAM\_local\_errored-frame-events:

```

-----
event time stamp: 3539                errored frame window(200ms): 5
errored frame low threshold: 1        errored frame high threshold: none
errored frame: 1200120                errored running total: 2302512542
event running total: 75
    
```

OAM\_local\_errored-frame-seconds-summary-events:

```

-----
event time stamp: 3520                errored frame seconds summary window(200ms): 300
errored frame low threshold: 1        errored frame high threshold: none
errored frame: 1200120                errored running total: 2302512542
event running total: 232
    
```

```

OAM_local_link-fault: 0
OAM_local_dying gasp: 0
OAM_local_critical event: 0
    
```

Field	Description
OAM_local_errored-symbol-period-events	Statistic information of the local errored symbol events
OAM_local_errored-frame-period-events	Statistic information of the local errored frame period events
OAM_local_errored-frame-events	Statistic information of the local errored frame events
OAM_local_errored-frame-seconds-summary-events	Statistic information of the local errored frame seconds events
event time stamp	Time stamp of the event
window	Detection period of the event
low threshold	Low threshold of events detection
high threshold	High threshold of events detection
errored frame	the number of errored frames
errored symbol	the number of errored symbols
errored running total	Total number of errors occurred since the reset of OAM function
event running total	Total number of error events occurred since the reset of OAM function
OAM_local_link-fault	The number of the local link-fault faults

OAM_local_dying gasp	The number of the local dying-gasp faults
OAM_local_critical event	The number of the local critical-event faults

## 8.28 show ethernet-oam link-events configuration

**Command:** show ethernet-oam link-events configuration [interface {ethernet | } <IFNAME>]

**Function:** Show configuration of link events on specified or all ports with OAM enabled, including detection period and threshold of the events and so on.

**Parameters:** <IFNAME>, the port that the statistic information of OAM link events needs to be shown, the statistic information of OAM link events for all ports will be shown if this parameter is not specified.

**Command Mode:** Admin mode

**Default:** N/A.

**Usage Guide:** N/A.

**Example:** Show configuration of link events on ethernet 1/0/1.

```
Switch#show ethernet-oam link-events configuration interface ethernet 1/0/1
```

Ethernet1/0/1 link-monitor configuration:

event	high-threshold	low-threshold	window(200ms)
Err-symbol-Period	none	1	2
Err-frame-Period	none	1	10
Err-frame	none	2	5
Err-frame-second-summary	none	2	600

Field	Description
Event	Event type
Err-symbol-Period	Errored symbol event
Err-frame-Period	Errored frame period event
Err-frame	Errored frame event
Err-frame-second-summary	Errored frame seconds event
high-threshold	High threshold
low-threshold	Low threshold
window(200ms)	Detection period, unit is 200ms

## 8.29 show ethernet-oam loopback status

**Command:** show ethernet-oam loopback status [interface {ethernet | } <IFNAME>]

**Function:** Display all or specified port OAM loopback status of switch.

**Parameters:** <IFNAME> means display the port of OAM loopback status information, if not appointed the parameters, it will display the OAM loopback status of all port.

**Command Mode:** Admin mode.

**Default:** None.

**Usage Guide:** None.

**Example:** Display the OAM loopback status of all port.

```
Switch(config)#show ethernet-oam loopback status
```

OAM Loopback Status:

ethernet1/0/1: disable

ethernet1/0/2: loopback\_enable\_waiting

ethernet1/0/3: loopback\_disable\_waiting

ethernet1/0/4: loopback\_control

ethernet1/0/5: loopback\_underControl

Field	Description
disable	Port does not enable OAM loopback support yet.
loopback_enable_waiting	Local is loopback control side, sending remote loopback request and wait remote loopback ensure packets.
loopback_disable_waiting	Local is loopback control side, sending cancel loopback request and wait remote to cancel the ensure packets of loopback.
loopback_control	During loopback and local is loopback control side.
loopback_undercontrol	During loopback and local is loopback controlled end.
no_loopback	Port enable OAM loopback support but not received loopback request.

Ethernet1/0/1: no\_loopback

# Chapter 9 Commands for PORT SECURITY

## 9.1 clear port-security

**Command:** clear port-security {all | configured | dynamic | sticky} [[address <mac-addr> | interface <interface-id>] [vlan <vlan-id> ]]

**Function:** Clear the secure MAC entries for the interfaces.

**Parameter: all:** All secure MAC entries on the interfaces

**configured:** The configured secure MAC

**dynamic:** The dynamic secure MAC learnt by the interface

**sticky:** The secure MAC of sticky

**mac-addr:** The specified secure MAC address

**interface-id:** The secure MAC entries of the specified interface

**vlan-id:** The specified VLAN

**Default:** None.

**Command Mode:** Admin mode

**Usage Guide:** None.

**Example:** Clear all secure MACs on the interface.

```
Switch#clear port-security all
```

## 9.2 show port-security

**Command:** show port-security [interface <interface-id>] [address | vlan]

**Function:** Show port-security configuration.

**Parameter: interface-id:** Show port-security configuration of the interface.

**address:** Show the secure address of the interface.

**vlan:** Show the maximum number of each VLAN configured on trunk/hybrid interface.

**Default:** None.

**Command Mode:** Any modes

**Usage Guide:** None.

**Example:** Show all secure MACs on the interfaces.

```
Switch# show port-security address interface ethernet 1/0/1
```



## 9.3 switchport port-security

**Command:** `switchport port-security`

`no switchport port-security`

**Function:** Configure port-security function for the interface, the no command disables port-security.

**Parameter:** None.

**Default:** Disable.

**Command Mode:** Port mode

**Usage Guide:** Clear all dynamic MACs after the interface enabled port-security, and all MACs learnt from the interfaces are tagged with FDB\_TYPE\_PORT\_SECURITY\_DYNAMIC. After disabling port-security of the interfaces, clear all secure MACs or change them into the dynamic MACs.

**Example:** Enable port-security on the interface.

```
Switch(config-if- ethernet1/0/1)#switchport port-security
```

## 9.4 switchport port-security aging

This command is not supported by the switch.

## 9.5 switchport port-security mac-address

**Command:** `switchport port-security mac-address <mac-address> [vlan <vlan-id>]`

`no switchport port-security mac-address <mac-address> [vlan <vlan-id>]`

**Function:** Configure the static secure MAC on the interface, the no command cancels the configuration.

**Parameter:** **mac-address:** Configure the specified MAC address as the static secure MAC.

**vlan-id:** The specified VLAN of the MAC address, it only takes effect on trunk and hybrid interfaces.

**Default:** No secure MAC is bound by the interface.

**Command Mode:** Port mode

**Usage Guide:** When configuring the static secure MAC, pay attention to the number of the current secure MAC whether exceed the maximum MAC limit allowed by the interface. If exceeding the maximum MAC limit, it will result in violation operation.

**Example:** Configure the secure MAC address on the interface.

```
Switch (config-if- ethernet1/0/1)# switchport port-security mac-address 00-00-00-00-00-01
```

## 9.6 switchport port-security mac-address sticky

This command is not supported by the switch.

## 9.7 switchport port-security maximum

**Command:** `switchport port-security maximum <value> [vlan <vlan-list>]`

**no switchport port-security maximum <value> [vlan <vlan-list>]**

**Function:** Configure the maximum number of the secure MAC allowed by the interface, if specifying VLAN parameter, it means the maximum number in the configured VLANs. The no command cancels the maximum number of the secure MAC configured by the interface.

**Parameter: value:** Configure the maximum number of the secure MAC allowed by the interface, its range between 1 and 128. It is determined by the maximum MAC number of the device.

**vlan-id:** Configure the maximum value for the specified VLAN, it only takes effect on trunk and hybrid interfaces.

**Default:** After enabling port-security, if there is no other configuration, the maximum number of the secure MAC is 1 on the interface. The interface number in VLAN is no limit by default

**Command Mode:** Port mode

**Usage Guide:** Pay attention to the coupling relation about the number between the interface and VLAN, set the maximum number configured by the interface as the standard firstly.

**Example:** Configure the maximum number of the secure MAC on the interface.

```
Switch(config-if- ethernet1/0/1)# switchport port-security maximum 100
```

## 9.8 switchport port-security violation

**Command:** `switchport port-security violation {protect | restrict | shutdown}`

**no switchport port-security violation**

**Function:** When exceeding the maximum number of the configured MAC addresses, MAC address accessing the interface does not belongs to this interface in MAC address

table or a MAC address is configured to several interfaces in same VLAN, both of them will violate the security of the MAC address.

**Parameter:** protect: Protect mode, it will trigger the action that do not learn the new MAC, drop the package and do not send the warning.

restrict: Restrict mode, it will trigger the action that do not learn the new MAC, drop the package, send snmp trap and record the configuration in syslog.

shutdown: Shutdown mode is the default mode. Under this condition, the interface is disabled directly, send snmp trap and record the configuration in syslog.

**Default:** Shutdown.

**Command Mode:** Port mode

**Usage Guide:** None.

**Example:** Configure violation mode as protect for the interface.

```
Switch(config-if-ethernet1/0/1)#switchport port-security violation protect
```

# Chapter 10 Commands for DDM

## 10.1 clear transceiver threshold-violation

**Command:** clear transceiver threshold-violation [interface ethernet <interface-list>]

**Function:** Clear the threshold violation of the transceiver monitoring.

**Parameter:** interface ethernet <interface-list>: The interface list that the threshold violation of the transceiver monitoring needs to be cleared.

**Command Mode:** Admin mode

**Default:** None.

**Usage Guide:** None.

**Example:** Clear the threshold violation of the transceiver monitoring on port 21, 25, 26, 28.

```
Switch#clear transceiver threshold-violation interface ethernet 1/0/21;25-26;28
```

## 10.2 debug transceiver

**Command:** debug transceiver {on | off}

**Function:** Enable/disable DDM debugging.

**Parameter:** on/off: Enable or disable the debugging.

**Command Mode:** Admin mode

**Default:** Off.

**Usage Guide:** Disable the DDM debugging with ctrl+o.

**Example:** Enable DDM debugging.

```
Switch#debug transceiver on
```

## 10.3 show transceiver

**Command:** show transceiver [interface ethernet <interface-list>] [detail]

**Function:** Show the monitoring of the transceiver.

**Parameter:** interface ethernet <interface-list>: The interface list that the monitoring of the transceiver needs to be shown.

**detail:** Show the detailed monitoring of the transceiver.

**Command Mode:** User mode, admin mode and global mode

**Default:** None.

**Usage Guide:** Temperature can be accurate to the integer, other values can be accurate to the second bit after the radix point. When the parameter exceeds the warning threshold, it is shown with 'W+' or 'W-', when the parameter exceeds the alarm threshold, it is shown with 'A+' or 'A-', no tagged parameter is normal.

**Example:** Show the brief DDM information of all ports.

Switch#show transceiver

Interface	Temp (°C)	Voltage (V)	Bias (mA)	RX Power (dBm)	TX Power (dBm)
1/0/25	33	3.31	6.11	-30.54(A-)	-6.01
1/0/26	33	5.00 (W+)	6.11	-20.54(W-)	-6.02

### 10.4 show transceiver threshold-violation

**Command:** show transceiver threshold-violation [interface ethernet <interface-list>]

**Function:** Show the transceiver monitoring.

**Parameter:** interface ethernet <interface-list>: The interface list that the transceiver monitoring needs to be shown.

**Command Mode:** Admin mode and global mode

**Default:** None.

**Usage Guide:** None.

**Example:** Show the transceiver monitoring.

Switch(config)#show transceiver threshold-violation interface ethernet 1/0/25-26

Ethernet 1/0/25 transceiver threshold-violation information:

Transceiver monitor is enabled. Monitor interval is set to 30 minutes.

The current time is Jan 02 12:30:50 2010.

The last threshold-violation time is Jan 01 1:30:50 2010.

Brief alarm information:

RX loss of signal

RX power low

Detail diagnostic and threshold information:

	Diagnostic			Threshold	
	Realtime Value	High Alarm	Low Alarm	High Warn	Low Warn
Temperature (°C)	33	70	0	70	0
Voltage (V)	7.31	10.00	0.00	5.00	0.00
Bias current (mA)	3.11	10.30	0.00	5.00	0.00
RX Power (dBm)	-30.54(A-)	9.00	-25.00 (-34)	9.00	-25.00
TX Power (dBm)	-1.01	9.00	-12.05	9.00	-10.00

Ethernet 1/0/26 transceiver threshold-violation information:  
Transceiver monitor is disabled. Monitor interval is set to 30 minutes.  
The last threshold-violation doesn't exist.

## 10.5 transceiver-monitoring

**Command:** `transceiver-monitoring {enable | disable}`

**Function:** Enable/ disable the transceiver monitoring.

**Parameter: enable/ disable:** Enable or disable the function.

**Command Mode:** Port mode

**Default:** Disable.

**Usage Guide:** None.

**Example:** Enable the transceiver monitoring of ethernet1/0/1.

```
Switch(config-if-ethernet1/0/1)#transceiver-monitoring enable
```

## 10.6 transceiver-monitoring interval

**Command:** `transceiver-monitoring interval <minutes>`

`no transceiver-monitoring interval`

**Function:** Set the interval of the transceiver monitoring. The no command sets the interval to be the default interval of 15 minutes.

**Parameter: <minutes>:** The interval of the transceiver monitoring needs to be set.

**Command Mode:** Global mode

**Default:** 15 minutes.

**Usage Guide:** None.

**Example:** Set the interval of the transceiver monitoring as 1 minute.

```
Switch(config)#transceiver-monitoring interval 1
```

## 10.7 transceiver threshold

**Command:** `transceiver threshold {default | {temperature | voltage | bias | rx-power | tx-power} {high-alarm | low-alarm | high-warn | low-warn} {<value> | default}}`

**Function:** Set the threshold defined by the user.

**Parameters: default:** Restore the threshold as the default threshold set by the manufacturer. If the monitoring index is not specified, restore all thresholds, if the monitoring index is specified, restore the corresponding threshold only.

**temperature:** The monitoring index—temperature

**voltage:** The monitoring index—voltage

**bias:** The monitoring index—bias current

**rx-power:** The monitoring index—receiving power

**tx-power:** The monitoring index—sending power

**high-alarm:** High-alarm of the monitoring index, namely there is alarm with A+ if exceeding the threshold.

**low-alarm:** Low-alarm of the monitoring index, namely there is alarm with A- if exceeding the threshold.

**high-warn:** High-warn of the monitoring index, namely there is warning with W+ if exceeding the threshold.

**low-warn:** Low-warn of the monitoring index, namely there is warning with W- if exceeding the threshold.

**Command Mode:** Port mode

**Default:** The threshold is set by the manufacturer.

**Usage Guide:** The range of the threshold parameters is shown for each monitoring index in the following:

Temperature: -128.00~128.00 °C

Voltage: 0.00~7.00 V

Bias current: 0.00~140.00 mA

x-power: -50.00~9.00 dBm

tx-power: -50.00~9.00 dBm

The maximum length of the threshold parameter configured by the user is 20 bits. After the user configured a parameter threshold, the threshold set by the manufacturer will be labeled with the bracket when showing the threshold, and decide whether give an alarm according to the user's configuration.

**Example:** Configure tx-power threshold of the fiber module, the low-warn threshold is configured as -12 on ethernet1/0/1.

```
Switch(config-if-ethernet1/0/1)#transceiver threshold tx-power low-warn -12
```

# Chapter 11 Commands for LLDP-MED

## 11.1 civic location

**Command:** `civic location {dhcp server | switch | endpointDev} <country-code>`  
**no civic location**

**Function:** Configure device type and country code of the location with Civic Address LCI format and enter Civic Address LCI address mode. The no command cancels all configurations of the location with Civic Address LCI format.

**Parameters:** dhcp server: Set device type to be DHCP server

- switch: Set device type to be Switch
- endpointDev: Set device type to be LLDP-MED Endpoint
- country-code: Set country code which consist of 2 letters, such as DE or US,

it should accord the country code of ISO 3166 standard.

**Default:** No location with Civic Address LCI format is configured on the port.

**Command Mode:** Port mode

**Usage Guide:** Configure device type and country code of the location with Civic Address LCI format and enter Civic Address LCI address mode to configure the more detailed location.

**Example:** Configure device type as switch and country code as US for the location with Civic Address LCI format on Ethernet 19.

```
Switch(Config-If-Ethernet1/0/19)# civic location switch US
Switch(Med-Civic)#
```

## 11.2 {description-language | province-state | city | county | street | locationNum | location | floor | room | postal | otherInfo}

**Command:** `{description-language | province-state | city | county | street | locationNum | location | floor | room | postal | otherInfo} <address>`

**no {description-language | province-state | city | county | street | locationNum | location | floor | room | postal | otherInfo}**

**Function:** Configure the detailed location after enter Civic Address LCI address mode of the port.



**Parameters:** description-language: language for describing location, such as 'English'  
province-state: state, canton, region, province prefecture, and so on, such as 'clara'  
city: city, such as 'New York'  
county: county, parish, such as 'santa clara'  
street: street, such as '1301 Shoreway Road'  
locationNum: house number, such as '9'  
location: name and occupant of a location, such as 'Carrillo's Holiday Market'  
floor: floor number, such as '13'  
room: room number, such as '1308'  
postal: postal/zip code, such as '10027-1234'  
otherInfo: Additional location information, such as 'South Wing'  
address: detailed address information, it cannot exceed 250 characters

**Default:** No detailed information of the location with Civic Address LCI is configured on the port.

**Command Mode:** Civic Address LCI address mode

**Usage Guide:** With this command, configure the detailed information of the location with Civic Address LCI on the port, it is able to configure 10 kinds of address types at most.

**Example:** Configure the detailed location information in Civic Address LCI address mode.

```
Switch(Med-Civic)# city Beijing  
Switch(Med-Civic)# street shangdi
```

## 11.3 ecs location

**Command:** `ecs location <tel-number>`

`no ecs location`

**Function:** Configure the location with ECS ELIN format on the port, the no command cancels the configured location.

**Parameter:** `<tel-number>`: location characters with ECS ELIN format, such as emergent telephone number, it is character string with the length between 10 and 25.

**Default:** No location with ECS ELIN format is configured.

**Command Mode:** Port mode

**Usage Guide:** Length range of the location character string between 10 and 25 with ECS ELIN format.

**Example:** Configure the location of ECS ELIN format on port 19.

```
Switch(Config-If-Ethernet1/0/19)# ecs location 880-445-3381
```

## 11.4 lldp med fast count

**Command:** `lldp med fast count <value>`

`no lldp med fast count`

**Function:** When the fast LLDP-MED startup mechanism is enabled, it needs to fast send LLDP packets with LLDP-MED TLV, this command sets the value of sending the packets fast, the no command restores the default value.

**Parameter:** value: The number of sending the packets fast, its range from 1 to 10, unit is entries.

**Default:** 4.

**Command Mode:** Global mode

**Usage Guide:** With this command, set the number for sending the packets fast.

**Example:**

```
Switch(config)#lldp med fast count 5
```

## 11.5 lldp med trap

**Command:** `lldp med trap {enable | disable}`

**Function:** Configure the specified port to enable or disable the function for sending TRAP message when LLDP-MED network topology is changed.

**Parameters:** enable: Enable LLDP-MED TRAP for the port

disable: Disable LLDP-MED TRAP for the port

**Default:** Disable LLDP-MED TRAP.

**Command Mode:** Port mode

**Usage Guide:** Enable or disable LLDP-MED TRAP of the port.

**Example:** Enable LLDP-MED TRAP of the port 19.

```
Switch(Config-If-Ethernet1/0/19)# lldp med trap enable
```

## 11.6 lldp transmit med tlv all

**Command:** `lldp transmit med tlv all`

`no lldp transmit med tlv all`

**Function:** Configure the specified port to send all LLDP-MED TLVs, the no command disables the function.

**Parameter:** None.

**Default:** Port does not enable the function for Sending LLDP-MED TLV.

**Command Mode:** Port mode

**Usage Guide:** After configuring this command, if the port is able to send LLDP-MED TLV, the sent LLDP packets with LLDP-MED TLV supported by all switches. However, LLDP packets sent by the port without any LLDP-MED TLV after the switch configured the corresponding no command.

**Example:** Port 19 enables the function for sending LLDP-MED TLV.

```
Switch(Config-If-Ethernet1/0/19)# lldp transmit med tlv all
```

## 11.7 lldp transmit med tlv capability

**Command:** lldp transmit med tlv capability

**no lldp transmit med tlv capability**

**Function:** Configure the specified port to send LLDP-MED Capability TLV. The no command disables the capability.

**Parameter:** None.

**Default:** The function is disabled for sending LLDP-MED Capability TLV.

**Command Mode:** Port mode

**Usage Guide:** After configuring this command, if the port is able to send LLDP-MED TLV, the sent LLDP packets with LLDP-MED Capability TLV. However, LLDP packets sent by the port without LLDP-MED Capability TLV after the switch configured the corresponding no command. Note: LLDP-MED Capability TLV is the important LLDP-MED TLV, if do not configure the port to send LLDP-MED Capability TLV firstly, other LLDP-MED TLV will not be sent.

**Example:** Port 19 enables the function for sending LLDP-MED Capability TLV.

```
Switch(Config-If-Ethernet1/0/19)# lldp transmit med tlv capability
```

## 11.8 lldp transmit med tlv extendPoe

**Command:** lldp transmit med tlv extendPoe

**no lldp transmit med tlv extendPoe**

**Function:** Configure the specified port to send LLDP-MED Extended Power-Via-MDI TLV. The no command disables the capability.

**Parameter:** None.

**Default:** The function is disabled for sending LLDP-MED Extended Power-Via-MDI TLV.

**Command Mode:** Port mode

**Usage Guide:** After configuring this command, if the port is able to send LLDP-MED TLV, LLDP packets with LLDP-MED Extended Power-Via-MDI TLV sent by the port. However, LLDP packets without LLDP-MED Extended Power-Via-MDI TLV sent by the port after the

switch configured the corresponding no command. Note: LLDP-MED Capability TLV sent by the port must be configured before sending LLDP-MED Extended Power-Via-MDI TLV, or else the configuration cannot be successful. If the device does not support PoE or PoE function of the port is disabled, although configuring this command, LLDP-MED Extended Power-Via-MDI TLV will not be sent.

**Example:** Port 19 enables the function for sending LLDP-MED Extended Power-Via-MDI TLV.

```
Switch(Config-If-Ethernet1/0/19)# lldp transmit med tlv extendPoe
```

## 11.9 lldp transmit med tlv inventory

**Command:** lldp transmit med tlv inventory

**no lldp transmit med tlv inventory**

**Function:** Configure the specified port to send LLDP-MED Inventory Management TLVs aggregation, TLVs aggregation includes 7 TLVs, they are Hardware Revision TLV, Firmware Revision TLV, Software Revision TLV, Serial Number TLV, Manufacturer Name TLV, Model Name TLV, Asset ID TLV. The no command disables the capability.

**Parameter:** None.

**Default:** The function is disabled for sending LLDP-MED Inventory Management TLVs.

**Command Mode:** Port mode

**Usage Guide:** After configuring this command, if the port is able to send LLDP-MED TLV, LLDP packets with LLDP-MED Inventory Management TLVs sent by the port. However, LLDP packets without LLDP-MED Inventory Management TLVs sent by the port after the switch configured the corresponding no command. Note: LLDP-MED Capability TLV sent by the port must be configured before sending LLDP-MED Inventory Management TLVs, or else the configuration cannot be successful.

**Example:** Port 19 enables the function for sending LLDP-MED Inventory Management TLVs.

```
Switch(Config-If-Ethernet1/0/19)# lldp transmit med tlv inventory
```

## 11.10 lldp transmit med tlv networkPolicy

**Command:** lldp transmit med tlv networkPolicy

**no lldp transmit med tlv networkPolicy**

**Function:** Configure the specified port to send LLDP-MED Network Policy TLV. The no command disables the capability.

**Parameter:** None.

**Default:** The function is disabled for sending LLDP-MED Network Policy TLV.

**Command Mode:** Port mode

**Usage Guide:** After configuring this command, if the port is able to send LLDP-MED TLV, LLDP packets with LLDP-MED Network Policy TLV sent by the port. However, LLDP packets without LLDP-MED Network Policy TLV sent by the port after the switch configured the corresponding no command. Note: LLDP-MED Capability TLV sent by the port must be configured before sending LLDP-MED Network Policy TLV, or else the configuration cannot be successful.

**Example:** Port 19 enables the function for sending LLDP-MED Network Policy TLV.

```
Switch(Config-If-Ethernet1/0/19)# lldp transmit med tlv networkPolicy
```

## 11.11 network policy

**Command:** `network policy {voice | voice-signaling | guest-voice | guest-voice-signaling | softphone-voice | video-conferencing | streaming-video | video-signaling} [status {enable | disable}] [tag {tagged | untagged}] [vid {<vlan-id> | dot1p}] [cos <cos-value>] [dscp <dscp-value> ]`

`no network policy {voice | voice-signaling | guest-voice | guest-voice-signaling | softphone-voice | video-conferencing | streaming-video | video-signaling}`

**Function:** Configure the network policy of the port, including VLAN ID, the supported application (such as voice and video), the application priority and the used policy, and so on.

**Parameters:** voice, voice-signaling, guest-voice, guest-voice-signaling, softphone-voice, video-conferencing, streaming-video and video-signaling: the application types are supported by the port.

status: Whether the network policy is usable.

enable: Network Policy of the specified application type has been defined, enable is the default value of the network policy.

disable: Network Policy of the specified application type is unknown, the fields (such as VLAN ID, L2 priority and DSCP) are ignored, network connection device will not send TLV of the specified application type.

tag: Configure the specified application to uses **tagged** or **untagged** VLAN method.

tagged: Configure the flow of the specified application to use the tagged vlan method, here, the fields (such as VLAN ID, Layer2 priority and DSCP value) are take effect.

untagged: Configure the flow without tag for the specified application, the

fields (such as VLAN ID, Layer2 priority) are ignored, only DSCP value field takes effect. Untagged is the default value of VLAN method.

**vid:** Configure VLAN ID that the specified application belongs to. When the peer sends the flow of the specified application, it will tag the notified VLAN ID, or else the vlan-id value is 1.

**vlan-id:** Configure the value of VLAN ID, its range from 1 to 4094.

**dot1p:** Configure the specified application to tag the flow by using 802.1p priority, at the same time, use vlan 0 to load the flow.

**cos:** Configure the priority of Ethernet frame for VLAN.

**cos-value:** Configure the value of Ethernet frame priority for VLAN, its range from 0 to 7, the default value is 5.

**dscp:** Configure DSCP of VLAN.

**dscp-value:** DSCP value input by the user, its range from 0 to 63, the default value is 46.

**Default:** No network policy is configured on the port.

**Command Mode:** Port mode

**Usage Guide:** User is able to configure the network policy of many kinds on a port, but their application types cannot repeat, and a kind of network policy corresponds to a LLDP-MED network policy TLV. If user configures multi-policy for a port, it will send multi-LLDP-MED network policy TLV to a LLDP packet. If user does not configure any network policy, no LLDP-MED network policy TLV is sent to LLDP packet.

**Example:** Configure the network policy with the application type of voice on port 19.

```
Switch(Config-If-Ethernet1/0/19)# network policy voice tag tagged vid 2 cos 6 dscp 23
```

## 11.12 show lldp

**Command:** show lldp

**Function:** Show the global LLDP and LLDP-MED configuration.

**Parameter:** None.

**Default:** None.

**Command Mode:** Admin mode

**Usage Guide:** None.

**Example:** Show the global LLDP and LLDP-MED configuration.

```
Switch#show lldp
```

```
-----LLDP GLOBAL INFORMATIONS-----
```

```
LLDP has been enabled globally.
```

```
LLDP enabled port : Ethernet1/0/19
```

```
LLDP interval :5
```

```
LLDP txTTL :20
LLDP NotificationInterval :5
LLDP txDelay :1
LLDP-MED FastStart Repeat Count :4
-----END-----
```

## 11.13 show lldp [interface ethernet <IFNAME>]

**Command:** show lldp [interface ethernet <IFNAME>]

**Function:** Show LLDP and LLDP-MED configurations on the current port.

**Parameter:** [interface ethernet <IFNAME>]: Port name

**Command Mode:** Admin mode

**Default:** None.

**Usage Guide:** None.

**Example:** Show LLDP and LLDP-MED configuration of the port 19.

```
Switch#show lldp interface ethernet 1/0/19
```

```
Port name :Ethernet1/0/19
```

```
LLDP Agent Adminstatus : Both
```

```
LLDP Operation TLV : default
```

```
LLDP Trap Status : disable
```

```
LLDP maxRemote :100
```

```
LLDP Overflow handle : discard
```

```
LLDP interface remote status : Free
```

```
MED Optional TLV : capabilities networkPolicy location power inventory
```

```
MED Trap Status:Enable
```

```
MED TLV Transmit Status:Disable
```

```
MED Fast Transmit Status:Disable
```

## 11.14 show lldp neighbors

**Command:** show lldp neighbors [interface ethernet <IFNAME>]

**Function:** Show LLDP and LLDP-MED information of the neighbors for the port.

**Parameter:** None.

**Default:** None.

**Command Mode:** Admin mode

**Usage Guide:** With this command, checking LLDP and LLDP-MED information of the neighbors after the port received LLDP packets sent by the neighbors.

**Example:** Show the neighbor information on port 1.

Switch #show lldp neighbors interface ethernet 1/0/1

Port name : Ethernet1/0/1

Port Remote Counter : 1

TimeMark :20

ChassisIdSubtype :4

ChassisId :00-03-0f-00-00-02

PortIdSubtype :Local

PortId :3

PortDesc :Ethernet1/0/1

SysName :switch

SysDesc :switch Device, Compiled Feb 12 17:39:53 2011

SoftWare Version 6.2.30.0

BootRom Version 4.0.1

HardWare Version

Device serial number

Copyright (C) 2001-2011 by Vendor.

All rights reserved



# Chapter 12 Commands for bpdu-tunnel

## 12.1 bpdu-tunnel-protocol

**Command:** `bpdu-tunnel-protocol{stp| gvrp| dot1x| user-defined-protocol <name>}  
no bpdu-tunnel-protocol {stp| gvrp| dot1x| user-defined-protocol  
<name>}`

**Function:** Enable bpdu-tunnel-protocol function of some protocol in port.

**Parameter:** stp: enable bpdu-tunnel-protocol of stp function in port.

gvrp: enable bpdu-tunnel-protocol of avrp function in port.

dot1x: enable bpdu-tunnel-protocol of dot1x function in port.

name: enable bpdu-tunnel-protocol of neme function in port, the protocol name range from 1 to 32 bytes, and it made up with character, data, underline and the head and tail character can not be underline.

**Default:** None.

**Command Mode:** Port Mode.

**Usage Guide:** When finished configure bpdu-tunnel-protocol destination MAC address of some protocol, users can enable bpdu-tunnel-protocol function of protocol in port. Stp, gvrp or dot1x function mutex with bpdu-tunnel-protocol function in port, namely, if configured stp, gvrp or dot1x function in port, the bpdu-tunnel-protocol function of the protocol configured failed; if configured bpdu-tunnel-protocol function of this protocol in port, stp, gvrp or dot1x function can not configured in port.

**Example:** Configure bpdu-tunnel-protocol to enable stp protocol in port 1/0/1.

```
Switch(Config-lf-Ethernet1/0/1)# bpdu-tunnel-protocol stp
```

## 12.2 bpdu-tunnel-protocol group-mac

**Command:** `bpdu-tunnel-protocol {stp| gvrp| dot1x} {group-mac <mac> |  
default-group-mac}`

`no bpdu-tunnel-protocol {stp| gvrp| dot1x}`

**Function:** Configure bpdu-tunnel-protocol address of specified protocol. After switch received protocol packets, if receive port enable bpdu-tunnel-protocol function, for configured this command packets, it will change destination mac address to specified bpdu-tunnel-protocol mac address. If input port of transfer protocol packets enables bpdu-tunnel-protocol function, it will receive destination mac address of packets to

configure address for the command, and change mac of protocol packets to itself mac of protocol packets.

**Parameters:** stp: configure bpdu-tunnel-protocol mac of stp protocol;

Gvrp: configure bpdu-tunnel-protocol mac of gvrp protocol;

dot1x: configure bpdu-tunnel-protocol mac of dot1x protocol;

<mac>: bpdu-tunnel-protocol mac address must be multicast address and it can not be protocol saved address, namely address between 01-80-c2-00-00-00 and 01-80-c2-00-00-30;

default-group-mac: the default mac address is 01-00-0c-cd-00-02.

**Default:** None.

**Command Mode:** Global Mode.

**Usage Guide:** This command must be configured before configure bpdu-tunnel-protocol in port.

**Example:** Configure 01-01-00-0c -00-02 bpdu-tunnel-protocol of stp protocol.

```
Switch(Config)# bpdu-tunnel-protocol stp group-mac 01-01-00-0c -00-02
```

## 12.3 bpdu-tunnel-protocol protocol-mac

**Command:** `bpdu-tunnel-protocol user-defined-protocol <name> protocol-mac <mac> {group-mac <mac> | default-group-mac}`

`no bpdu-tunnel-protocol user-defined-protocol <name>`

**Function:** Configure mac address to identify characteristics of agreement and satisfy the protocol of bpdu-tunnel-protocol mac.

**Parameters:** **name:** it is the protocol name and the protocol name includes 1 to 32 characters, and it makes up with character, data and underline, the head and tail character can not be underline;

**protocol-mac <mac>:** it is the mac address of protocol;

**group-mac <mac> :** it is the address of bpdu-tunnel-protocol mac and it must be multicast address, and it is not protocol saved address, namely the address between 01-80-c2-00-00-00 and 01-80-c2-00-00-30;

**default-group-mac:** The default mac address is 01-00-0c-cd-00-02.

**Default:** None.

**Command Mode:** Global Mode.

**Usage Guide:** The command must be configured before bpdu-tunnel-protocol in port.

**Example:** Configure 01-01-00-0c-00-03 to be the bpdu-tunnel-protocol of mrpp protocol.

```
Switch(Config)# bpdu-tunnel-protocol user-defined-protocol mrpp protocol-mac 00-03-0f-00-00-02 group-mac 01-01-00-0c -00-03
```

## 12.4 bpdu-tunnel-protocol ethernetii

**Command:** `bpdu-tunnel-protocol user-defined-protocol <name> protocol-mac <mac> encaps-type ethernetii protocol-type <type> {group-mac <mac> | default-group-mac}`

`no bpdu-tunnel-protocol user-defined-protocol <name>`

**Function:** Configure protocol feature that aimed at mac address and protocol type, the encapsulation type of the protocol is EthernetII and appointed the bpdu-tunnel-protocol mac of the protocol.

**Parameters:** **name:** it is the protocol name and the protocol name includes 1 to 32 characters, and it makes up with character, data and underline, the head and tail character can not be underline;

**protocol-mac <mac>:** it is the mac address of protocol;

**<type>:** the value of protocol and the format is xx-xx.

**group-mac <mac> :** it is the address of bpdu-tunnel-protocol mac and it must be multicast address, and it is not protocol saved address, namely the address between 01-80-c2-00-00-00 and 01-80-c2-00-00-30;

**default-group-mac:** The default mac address is 01-00-0c-cd-00-02.

**Default:** None.

**Command Mode:** Global Mode.

**Usage Guide:** The command must be configured before bpdu-tunnel-protocol in port.

**Example:** Configure 01-01-00-0c-00-04 to be the bpdu-tunnel-protocol of lldp protocol.

```
Switch(Config)# bpdu-tunnel-protocol user-defined-protocol lldp protocol-mac
01-80-c2-00-00-0e encaps-type ethernetii protocol-type 88-cc group-mac 01-01-00-0c
-00-04
```

## 12.5 bpdu-tunnel-protocol snap

**Command:** `bpdu-tunnel-protocol user-defined-protocol <name> protocol-mac <mac> encaps-type snap {oui <oui>| } protocol-type <type> {group-mac <mac> | default-group-mac}`

`no bpdu-tunnel-protocol user-defined-protocol <name>`

**Function:** Configure protocol feature that aimed at mac address, oui and protocol type, the encapsulation type of the protocol is 802.3/802.2 SNAP or 802.3/802.2 SNAP RFC 1042 (Not configure OUI) and appointed the bpdu-tunnel-protocol mac of the protocol.

**Parameters:** **name:** it is the protocol name and the protocol name includes 1 to 32

characters, and it makes up with character, data and underline, the head and tail character can not be underline;

**protocol-mac <mac>**: it is the mac address of protocol;

**<oui>**: the value of oui and the format is xx-xx-xx;

**<type>**: the value of protocol and the format is xx-xx.

**group-mac <mac>** : it is the address of bpdu-tunnel-protocol mac and it must be multicast address, and it is not protocol saved address, namely the address between 01-80-c2-00-00-00 and 01-80-c2-00-00-30;

**default-group-mac**: The default mac address is 01-00-0c-cd-00-02.

**Default:** None.

**Command Mode:** Global Mode.

**Usage Guide:** The command must be configured before bpdu-tunnel-protocol in port.

**Example:** Configure 01-01-00-0c-00-05 to be the bpdu-tunnel-protocol of Apple Talk protocol.

```
Switch(Config)# bpdu-tunnel-protocol user-defined-protocol lldp protocol-mac
00-03-c2-00-00-05 encap-type snap oui 08-00-07 protocol-type 80-9b group-mac
01-01-00-0c -00-05
```

## 12.6 bpdu-tunnel-protocol llc

**Command:** `bpdu-tunnel-protocol user-defined-protocol <name> protocol-mac <mac> encap-type llc dsap <dsap> ssap <ssap> {group-mac <mac> | default-group-mac}`

`no bpdu-tunnel-protocol user-defined-protocol <name>`

**Function:** Configure protocol feature that aimed at mac address, dsap and ssap type, the encapsulation type of the protocol is 802.3/802.2 LLC and appointed the bpdu-tunnel-protocol mac of the protocol.

**Parameters:** **name:** it is the protocol name and the protocol name includes 1 to 32 characters, and it makes up with character, data and underline, the head and tail character can not be underline;

**protocol-mac <mac>**: it is the mac address of protocol;

**<dsap>**: The dsap value of protocol and it ranges from 0 to 255;

**<ssap>**: The ssap value of protocol and it ranges from 0 to 255;

**group-mac <mac>** : it is the address of bpdu-tunnel-protocol mac and it must be multicast address, and it is not protocol saved address, namely the address between 01-80-c2-00-00-00 and 01-80-c2-00-00-30;

**default-group-mac**: The default mac address is 01-00-0c-cd-00-02.

**Default:** None.

**Command Mode:** Global Mode.

**Usage Guide:** The command must be configured before bpdu-tunnel-protocol in port.

**Example:** Configure 01-01-00-0c-00-06 to be the bpdu-tunnel-protocol of NetBIOS protocol.

```
Switch(Config)# bpdu-tunnel-protocol user-defined-protocol lldp protocol-mac  
00-03-c2-00-00-06 encap-type llc dsap 240 ssap 224 group-mac 01-01-00-0c -00-06
```

# Chapter 13 Commands for EEE Energy-saving

## 13.1 eee enable

**Command:** eee enable  
no eee enable

**Function:** Configure the port to enable eee energy-saving function; the no command deletes it.

**Parameters:** None.

**Command Mode:** Port Mode.

**Default:** None.

**Usage Guide:** It supports that configure EEE energy-saving function for the appointed port. There is not the EEE energy-saving function on port as default. After configuring the port to enable EEE energy-saving function, the port will enter the energy-saving state if stop to send packets to the port, the state of port is down. When sending packets to the port, the mode will changed from power saving mode to normal mode.

**Example:** Enable EEE energy-saving function:

```
Switch(config-if-ethernet1/0/1)#eee enable
```

# Chapter 14 Commands for LED shut-off

## 14.1 LED shut-off

**Command:** port-led shutoff time-range <time-range-name>

**no port-led shutoff**

**Function:** Configure all the LEDs to be off in the appointed time-range. The no command recovers it.

**Parameters:** time-range-name: it is the name of the time-range defined by user, it is made up by 1 to 64 characters including letters, numbers, underlines. The first and last characters cannot be the underlines.

**Command Mode:** Global Configuration Mode.

**Default:** None.

**Usage Guide:** The LED shut-off function of the port can make all the LEDs off according to the configured time-range by user no matter what the link-act status is. It can save power. When there is no configured time-range, the default is all the times; when the range is exceeded, the port LED can be on according to the link-act status.

**Example:** Configure all the LEDs to be off in t1.

```
switch(config)#: port-led shutoff time-range t1
```