

IGMP-Snooping Configuration Commands

Table of contents

CHAPTER 1 IGMP-SNOOPING CONFIGURATION COMMANDS	3
1.1.1. igmp-snooping	3
1.1.2. igmp-snooping static	4
1.1.3. igmp-snooping immediate-leave	5
1.1.4. igmp-snooping mrouter	5
1.1.5. igmp-snooping policy	6
1.1.6. igmp-snooping dlf-drop	7
1.1.7. igmp-snooping router age	7
1.1.8. igmp-snooping response time	8
1.1.9. igmp-snooping querier	8
1.1.10. igmp-snooping querier querier-timer	9
1.1.11. igmp-snooping filter	9
1.1.12. igmp-snooping clear-group	10
1.1.13. igmp-snooping quick-query	10
1.1.14. igmp-snooping decrease-query-report-for-mvc	11
1.1.15. igmp-snooping no-send-special-query	11
1.1.16. igmp-snooping forward-l3-to-mrouter	12
1.1.17. igmp-snooping sensitive	13
1.1.18. igmp-snooping v3-leave-check	13
1.1.19. igmp-snooping forward-wrongiif-within-vlan	14
1.1.20. igmp-snooping policy	14
1.1.21. igmp-snooping limit	15
1.1.22. show ip igmp-snooping	16
1.1.23. show ip igmp-snooping timer	17
1.1.24. show ip igmp-snooping groups	17
1.1.25. show ip igmp-snooping statistics	18
1.1.26. debug ip igmp-snooping packet	18
1.1.27. debug ip igmp-snooping timer	19
1.1.28. debug ip igmp-snooping error/event	19

CHAPTER 1 IGMP-SNOOPING COMMANDS

CONFIGURATION

The IGMP-Snooping configuration commands include:

- `igmp-snooping`
- `igmp-snooping static`
- `igmp-snooping immediate-leave`
- `igmp-snooping mrouter`
- `igmp-snooping policy`
- `igmp-snooping dlf-drop`
- `igmp-snooping router age`
- `igmp-snooping response time`
- `igmp-snooping querier`
- `igmp-snooping querier querier-timer`
- `igmp-snooping filter`
- `igmp-snooping clear-group`
- `igmp-snooping quick-query`
- `igmp-snooping decrease-query-report-for-mvc`
- `igmp-snooping no-send-special-query`
- `igmp-snooping forward-l-to-mrouter`
- `igmp-snooping sensitive`
- `igmp-snooping v-leave-check`
- `igmp-snooping forward-wrongiif-within-vlan`
- `igmp-snooping policy`
- `igmp-snooping limit`
- `show ip igmp-snooping`
- `show ip igmp-snooping timer`
- `show ip igmp-snooping groups`
- `show ip igmp-snooping statistics`
- `debug ip igmp-snooping packet`
- `debug ip igmp-snooping timer`
- `debug ip igmp-snooping error/event`

1.1.1. igmp-snooping

Syntax

```
ip igmp-snooping [ vlan vlan_id ]
```

```
no ip igmp-snooping [ vlan vlan_id ]
```

To enable or disable the IGMP-snooping function, run `ip igmp-snooping [vlan vlan_id]`. To resume the corresponding default settings, run `no ip igmp-snooping [vlan vlan_id]`.

Parameters

Parameter	Description
<i>vlan id</i>	Stands for the ID of a VLAN. Value range: 1-4094

Default value

The IGMP-Snooping function of the designated VLAN is shut down by default.

Usage guidelines

If the `vlan` parameter is not designated, all VLANs in the system will be enabled or disabled after you run this command (IGMP-snooping supports at most 16 VLANs simultaneously).

Example

The following example shows how to enable the IGMP snooping function of VLAN1.

```
switch_config# ip igmp-snooping vlan 1
switch_config#
```

1.1.2. igmp-snooping static

Syntax

```
ip igmp-snooping vlan vlan_id static A.B.C.D interface intf
no ip igmp-snooping vlan vlan_id static A.B.C.D interface intf
```

Parameters

Parameter	Description
<i>vlan id</i>	Stands for the ID of a VLAN. Value range: 1-4094
<i>A.B.C.D</i>	IP address of the multicast
<i>intf</i>	Port

Default value

None

Usage guidelines

This command is used to configure the static multicast address of VLAN. Its negative form is used to cancel the static multicast address.

Example

The following example shows how to add static multicast address 234.5.6.7 to interface FastEthernet0/5 of VLAN 2.

```
switch_config# ip igmp-snooping vlan 2 static 234.5.6.7 interface GigaEthernet0/5
switch_config#
```

Note:

224.0.0.0-224.0.0.255 stands for irroutable multicast addresses which cannot be registered on each port.

1.1.3. igmp-snooping immediate-leave

Syntax

To configure the immediate-leave attribute of VLAN, run `ip igmp-snooping vlan vlan_id immediate-leave`. To resume the Default value, run `no ip igmp-snooping vlan vlan_id immediate-leave`.

```
ip igmp-snooping vlan vlan_id immediate-leave
```

```
no ip igmp-snooping vlan vlan_id immediate-leave
```

Parameters

Parameter	Description
<i>vlan id</i>	Stands for the ID of a VLAN. Value range: 1-4094

Default value

The immediate-leave attribute is shut down by default.

Usage guidelines

None

Example

The following example shows how to enable the immediate-leave attribute of VLAN1.

```
switch_config# ip igmp-snooping vlan 1 immediate-leave
switch_config#
```

1.1.4. igmp-snooping mrouter

Syntax

```
ip igmp-snooping vlan vlan_id mrouter interface intf
```

```
no ip igmp-snooping vlan vlan_id mrouter interface intf
```

Parameters

Parameter	Description
<i>vlan id</i>	Stands for the ID of a VLAN. Value range: 1-4094
<i>intf</i>	Port

Default value

None

Usage guidelines

The command is used to set the static routing port of VLAN. Use the no form of this command to delete the routing port.

Example

The following example shows how to add gigabit Ethernet port 0/5 to the static routing port of VLAN 2.

```
switch_config# ip igmp-snooping vlan 2 mrouter interface GigaEthernet0/5
switch_config#
```

1.1.5. igmp-snooping policy**Syntax**

```
ip igmp-snooping policy word
no ip igmp-snooping policy
```

Parameters

Parameter	Description
<i>Word</i>	IP ACL name

Default value

None

Usage guidelines

The command is used to set the to be detected IP ACL list of igmp-snooping when adding multicast forwarding table. Use the no form of this command to cancel the detection of the list.

Example

The following example is to detect the IP ACL whose name is 123 when adding multicast forwarding table.

```
switch_config# ip igmp-snooping policy 123
```

```
switch_config#
```

1.1.6. igmp-snooping dlf-drop

Syntax

```
ip igmp-snooping dlf-drop  
no ip igmp-snooping dlf-drop
```

Default value

None

Usage guidelines

This command is used to set the multicast packets whose destination multicast addresses are not registered to the filtration mode. The negative form of this command is used to resume the default settings.

Example

The following example shows how to drop the multicast packets with unregistered destination addresses in all VLANs.

```
switch_config# ip igmp-snooping dlf-drop  
switch_config#
```

1.1.7. igmp-snooping router age

Syntax

```
ip igmp-snooping timer router-age time_value  
no ip igmp-snooping timer router-age
```

Parameters

Parameter	Description
<i>time value</i>	Queries the time of the timer. Value range: 10-2147483647

Default value

260 seconds

Usage guidelines

This command is used to query the time of the timer of IGMP-Snooping. The negative form of this command is used to resume the Default value.

Example

The following example shows how to set the query time of the router to 300 seconds.

```
switch_config# ip igmp-snooping timer router-age 300  
switch_config#
```

1.1.8. igmp-snooping response time

Syntax

To configure the maximum response time of IGMP snooping, run `ip igmp-snooping timer response-time timer_value`. To resume the Default value of IGMP snooping, run `no ip igmp-snooping timer response-time timer_value`.

ip igmp-snooping timer response-time *time_value*

no ip igmp-snooping timer response-time

Parameters

Parameter	Description
<i>time value</i>	Queries the time of the timer. Value range: 1-2147483647

Default value

15 seconds

Usage guidelines

None

Example

The following example shows how to set the query response time of IGMP snooping to 20 seconds.

```
switch_config# ip igmp-snooping timer response-time 20
```

```
switch_config#
```

1.1.9. igmp-snooping querier

Syntax

To activate the IGMP-snooping querier mechanism, or set the source IP address of the automatic query packet, run `ip igmp-snooping querier [address <ip_addr>]`. To resume the Default value, run `no ip igmp-snooping querier [address <ip_addr>]`.

ip igmp-snooping querier [address <ip_addr>]

no ip igmp-snooping querier [address]

Parameters

Parameter	Description
<i>ip_addr</i>	IP address of a normal unicast

Default value

By default, the querier function is not enabled and the source IP address is 10.0.0.200.

Usage guidelines

None

Example

The following example shows how to activate IGMP Querier to serve as a multicast router if no multicast router is working.

```
switch_config# ip igmp-snooping querier
switch_config#
```

1.1.10. igmp-snooping querier querier-timer

Syntax

To configure the forward interval of forwarding query packets by the local querier, run the first one of the above commands. To return to the default setting, use the no form of this command.

```
ip igmp-snooping querier querier-timer time_value
no ip igmp-snooping querier querier-timer
```

Parameters

Parameter	Description
<i>time_value</i>	local querier interval

Default value

The default interval is 200 seconds in enabling Querier.

Usage guidelines

None

Example

The following command shows how to configure the query period of the local querier to 140s.

```
switch_config# ip igmp-snooping querier querier-timer 140
switch_config#
```

1.1.11. igmp-snooping filter

Syntax

To configure the multicast group list, run the following command. To return to the default setting, use the no form of this command.

```
ip igmp-snooping filter [ IPACL name ]  
no ip igmp-snooping filter [ IPACL name ]
```

Parameter

Parameter	Description
<i>ip_addr</i>	Multicast ip address

Default value

By default all multicast groups can be allowed to add hardware forwarding.

Usage guidelines

None

Example

The following example shows how to enable the multicast requirement of 225.0.0.1 adding to the hardware table.

```
Switch_config#ip access-list standard 1  
Switch_config_std#deny 225.0.0.1  
switch_config_tg0/1# ip igmp-snooping filter 1  
switch_config_tg0/1#
```

1.1.12. igmp-snooping clear-group

Syntax

To clear all multicast groups in igmp-snooping, run the following command.

```
ip igmp-snooping clear-group
```

Default value

None

Usage guidelines

None

Example

The following example shows how to delete all layer-2 multicast forwarding table.

```
switch_config# ip igmp-snooping clear-group  
switch_config#
```

1.1.13. igmp-snooping quick-query

Syntax

To forward igmp query packets if there is a port is up, run the following command. To return to the default setting, use the no form of this command.

ip igmp-snooping quick-query

no ip igmp-snooping quick-query

Default value

By default DUT will not forward query packets if the port is up.

Usage guidelines

None

Example

The following example shows how to forward igmp query packets if there is a port is up

```
switch_config# ip igmp-snooping quick-query
```

```
switch_config#
```

1.1.14. igmp-snooping decrease-query-report-for-mvc

Syntax

To configure the following command and igmp-snooping will not forward igmp protocol packets if mvc is enabled.

ip igmp-snooping decrease-query-report-for-mvc

no ip igmp-snooping decrease-query-report-for-mvc

Default value

By default igmp-snooping and mvc will forward igmp protocol packets collaboratively and the number of packets will increase.

Usage guidelines

None

Example

The following example shows how to configure the following command and igmp-snooping will not forward igmp protocol packets if mvc is enabled.

```
switch_config# ip igmp-snooping decrease-query-report-for-mvc
```

```
switch_config#
```

1.1.15. igmp-snooping no-send-special-query

Syntax

ip igmp-snooping no-send-special-query

no ip igmp-snooping no-send-special-query

To configure this command and if querier is not enabled locally, it will not forward special query locally after receiving leave packets.

Default value

By default the switch will forward special query after receiving leave packets.

Usage guidelines

None

Example

The following example shows how to not locally forward special query after enabling querier and receiving packets.

```
switch_config# ip igmp-snooping no-send-special-query
switch_config#
```

1.1.16. igmp-snooping forward-l3-to-mrouter

Syntax

To send the data packets to the multicast routing port, run `ip igmp-snooping forward-l3-to-mrouter`. To resume the default settings, use the “no” form of this command.

ip igmp-snooping forward-l3-to-mrouter

no ip igmp-snooping forward-l3-to-mrouter

Parameters

None

Default value

If the `forward-l3-to-mrouter` command is not enabled, the data packets will not be sent to the related multicast routing port.

Usage guidelines

This command is mainly to send the data packets to the IGMP JOIN port and meanwhile to the multicast routing port. Especially in case of L3 multicast cascading, the upstream L3 switches cannot receive the IGMP JOIN packets from a relative group and hence cannot learn the information about the relative group, and then the data packets will be sent to all physical ports in the L3 egress VLAN. After this command is run, the data packets will only be sent to the multicast routing port, which is registered on PIM-SM.

Example

The following example shows how to activate IGMP `forward-l3-to-mrouter` and make the upstream multicast data packets be sent to the multicast routing port:

```
switch_config# ip igmp-snooping forward-l3-to-mrouter
switch_config#
```

1.1.17. igmp-snooping sensitive

Syntax

To activate the IGMP-snooping sensitive mechanism or set the value of the sensitive parameter, run `ip igmp-snooping sensitive [value int<3-30>]`. To resume the Default value, use the "no" form of this command.

ip igmp-snooping sensitive [value int<3-30>]

no ip igmp-snooping sensitive [value]

Parameters

Parameter	Description
<i>int</i>	30-3

Default value

The sensitive function is disabled by default.

Usage guidelines

This command is mainly used to modify the router-age of the mrouter port in active state and deliver the new query packets rapidly when a port in trunk mode is shut down.

Example

The following example shows how to activate IGMP sensitive and set the route-age of mrouter to be a converged one.

```
switch_config# ip igmp-snooping sensitive
```

```
switch_config# ip igmp-snooping sensitive value 10
```

1.1.18. igmp-snooping v3-leave-check

Syntax

To send the special query packets after the v3-leave packet is received, run `ip igmp-snooping v3-leave-check`; to resume the default settings, run the "no" form of this command.

ip igmp-snooping v3-leave-check

no ip igmp-snooping v3-leave-check

Default value

v3-leave-check is disabled and the special query packet will not be sent after v3-leave packet is received.

Usage guidelines

None

Example

The following example shows how to activate IGMP v3-leave-check and send the special query packet after the v3-leave packet is received.

```
switch_config# ip igmp-snooping v3-leave-check
switch_config#
```

1.1.19. igmp-snooping forward-wrongiif-within-vlan

Syntax

To send the multicast data packets, received from the wrongiif port, to the relative physical ports in the local vlan, run `ip igmp-snooping forward-wrongiif-within-vlan`; to resume the Default value, run the “no” form of this command.

ip igmp-snooping forward-wrongiif-within-vlan

no ip igmp-snooping forward-wrongiif-within-vlan

Default value

This command is enabled by default and the multicast packets from the wrongiif port will be sent to the relative physical ports.

Usage guidelines

The command takes its importance only when the L3 multicast is enabled. After this command is enabled, the multicast packets, entering from the wrongiif port, will be sent to the physical ports that are added into the group of vlan; otherwise, the multicast packets will be dropped.

Example

The following example shows how to activate IGMP forward-wrongiif-within-vlan, and how to send the multicast packets from the wrongiif port to the relative physical ports in the local VLAN:

```
switch_config# ip igmp-snooping forward-wrongiif-within-vlan
switch_config#
```

1.1.20. igmp-snooping policy

Syntax

ip igmp-snooping policy *word*

no ip igmp-snooping policy

Parameters

Parameter	Description
<i>Word</i>	IP ACL name

Default value

None

Usage guidelines

Enable IPACL function of IGMP-snooping and determine the packets of some multicast IP address are to be deleted or ignored.

Configuration Mode

Port Configuration

Example

The following example is to detect the IP ACL whose name is 123 when dealing with the packets.

```
switch_config_G0/1# ip igmp-snooping policy 123
switch_config_G0/1#
```

1.1.21. igmp-snooping limit

Syntax

```
ip igmp-snooping limit value
no ip igmp-snooping limit
```

Parameters

Parameter	Description
<i>value</i>	1-2048

Default value

2048

Usage guidelines

The command configures the max multicast IP address number in the port of IGMP-snooping. The command will estimate whether the applied groups have reached the configuration number when IGMP-snooping generating the forward table. Otherwise, the table of the port is no longer generated.

Configuration Mode

Port Configuration

Example

The following example shows how to set the max number of the joining group as 1000.

```
switch_config_G0/1# ip igmp-snooping limit 1000
switch_config_G0/1#
```

1.1.22. show ip igmp-snooping**Syntax****show ip igmp-snooping****Parameters**

None

Default value

None

Usage guidelines

This command is used to display the information about IGMP-snooping configuration.

Example

The following example shows how to display each VLAN where IGMP-snooping is running.

```
switch_config# show ip igmp-snooping
```

Global IGMP snooping configuration:

```
-----
```

Globally enable : Enabled

VLAN nodes : 1,50,100,200,400,500

Dif-frames filtering : Disabled

Sensitive : Disabled

Querier : Enabled

Querier address : 10.0.0.200

Querier interval : 140 s

Router age : 260 s

Response time : 15 s

vlan_id	Immediate-leave	Ports	Router Ports
1	Disabled	5-10	SWITCH(querier);
50	Disabled	1-4	SWITCH(querier);
100	Disabled	NULL	SWITCH(querier);G0/1(static);
200	Disabled	NULL	SWITCH(querier);
400	Disabled	NULL	SWITCH(querier);
500	Disabled	NULL	SWITCH(querier);

```
-----
```

```
switch_config#
```


1.1.23. show ip igmp-snooping timer

Syntax

```
show ip igmp-snooping timer
```

Parameters

None

Default value

None

Usage guidelines

This command is used to display the information about the IGMP-snooping clock.

Example

The following example shows how to display the information about the IGMP-snooping clock.

```
switch_config# show ip igmp-snooping timer
vlan 1 mrouter on port 3 : 251
switch_config#
```

1.1.24. show ip igmp-snooping groups

Syntax

```
show ip igmp-snooping groups
```

Parameters

None

Default value

None

Usage guidelines

This command is used to display the information about the multicast group of IGMP-snooping.

Example

The following example shows how to display the information about the multicast group of IGMP-snooping.

```
switch_config# show ip igmp-snooping groups
The total number of groups      2
Vlan Group      Type Port(s)
-----
1 226.1.1.1     IGMP G0/1                G0/3
```

```
1 225.1.1.16 IGMP G0/1 G0/3
switch_config#
```

1.1.25. show ip igmp-snooping statistics

Syntax

```
show ip igmp-snooping statistics
```

Parameters

None

Default value

None

Usage guidelines

This command is used to display the information about IGMP-snooping statistics.

Example

The following example shows how to display the information about IGMP-snooping statistics.

```
switch_config# show ip igmp-snooping statistics
vlan 1
-----
v1_packets:1
v2_packets:2
v3_packets:0
general_query_packets:1
special_query_packets:2
join_packets:0
leave_packets:0
send_query_packets:0
err_packets:0
switch_config#
```

1.1.26. debug ip igmp-snooping packet

Syntax

```
debug ip igmp-snooping packet
no debug ip igmp-snooping packet
```

Parameters

None

Default value

None

Usage guidelines

This command is used to enable or disable the igmp-snooping packet.

Example

The following example shows how to enable the packet debugging switch of IGMP-snooping.

```
switch # debug ip igmp-snooping packet
switch #
```

1.1.27. debug ip igmp-snooping timer

Syntax

```
debug ip igmp-snooping timer
no debug ip igmp-snooping timer
```

Parameters

None

Default value

None

Usage guidelines

This command is used to enable or disable the timer debugging switch of IGMP-snooping.

Example

The following example shows how to enable the timer debugging switch of IGMP-snooping.

```
switch # debug ip igmp-snooping timer
switch #
```

1.1.28. debug ip igmp-snooping error/event

Syntax

```
debug ip igmp-snooping error
no debug ip igmp-snooping error
debug ip igmp-snooping event
no debug ip igmp-snooping event
```

Parameters

None

Default value

None

Usage guidelines

This command is used to enable or disable the event debugging switch of IGMP-snooping.

Example

The following example shows how to enable the error/event debugging switch of IGMP-snooping.

```
switch # debug ip igmp-snooping error
```

```
switch # debug ip igmp-snooping event
```